

RS 200
BS VI



THE WORLD'S
FAVOURITE
INDIAN

RS 200
BS VI

Bajaj Auto Limited

Akurdi, Pune - 411 035, India.

Tel : +91 20 27472851

Fax : +91 20 27407385

Customer Care : +91 7219821111

Website : www.bajajauto.com

CIN L65993PN2007PLC130076

Spare Parts Catalogue



All information contained in this manual is based on the latest product information at the time of publication. Bajaj Auto Limited accepts no liability for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible. All procedures and specifications subject to change without prior notice. The right is reserved to make such changes at any time without prior notice and without incurring an obligation to make such changes to product manufactured previously. Contact your authorized Bajaj Dealer for the latest information on product improvements incorporated after this manual was issued.

DOC. NO.: 71120157

REV. 11 OCT 24

Copy rights : All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, Or transmitted in any form or by any means, electronic mechanical photocopying, recording or otherwise, without the prior written permission of Bajaj Auto LTD.

We have pleasure in presenting the Spare Parts Catalogue for 'Pulsar RS200 BS VI' Motorcycle. This catalogue has been specially designed to assist you in selecting the correct parts for procurement to maintain 100% availability.

The Bajaj spares are subjected to the stringent quality control standards to ensure longer life of the vehicle. It is therefore necessary that only the Genuine Bajaj Spares are used.

In a continual effort to improve Performance and Efficiency of the vehicles, Specifications, Diagrams, Illustrations and Part Numbers can change without notice. Consequently, the description in this Spare Parts Catalogue cannot therefore be final and binding on us.

The modifications / alterations which are carried out after the issue of this catalogue, will be conveyed to you through our Service Circulars. You are requested to make necessary corrections in the Parts Catalogue as per the circulars so as to keep your catalogue up-to-date. This will ensure the appropriate and speedy delivery of the Spare Parts as the order placed will bear the latest part numbers.

In case, if you need any technical assistance contact the concerned Regional Office or write to us on the following address :

Bajaj Auto Limited
Service Department
 Akurdi, Pune 411 035 India

- 1. How to Read the Catalogue :** Open the catalogue and from the pictorial index locate the group in which the part you want to find is present. Turn over to the concerned page number (as given by pictorial index). Now find out the figure of the part you wish to order. Write down the part number against that particular figure number from the text.

In case, if you have the part number and you need the other details, the part index can be used. The part index (at the end of the catalogue) will give you the figure and page number of the part you wish to order.

- 2. How to Order Spare Parts :** The part number and the description of the part required should be invariably mentioned in the order as per the catalogue text.

The latest part number as conveyed through our service circulars should only appear on the order. In case of ordering painted components, colour shade of the components should be mentioned.

The quantity shown against the part number is the quantity per vehicle for that group so that particular quantity should be multiplied by the number of sets required.

- 3. Part Number System :** We have used 8 digit system for part numbers. The model or hardware item is indicated by first two digits or alphanumeric, the next two or four digits indicate main group and the last four or two digits indicate serial number in main group or serial number or subgroup of fastener respectively. Thus the part numbers will be indicated by 2-2-4 or 2-4-2 digit system. Understanding this system will enable you to identify the spare parts easily.

- 4. Abbreviations :** The following abbreviations are used in this catalogue.

Assly	Assembly	V	Volts
N.I.	Not illustrated	W	Watts
C'case	Crankcase	Accl.	Accelerator
Cyl	Cylinder	Comp.	Complete
O/s	Over size	Fr.	Front
Rr.	Rear	Std.	Standard
L	Length	A/t.	Alternate
R.H.	Right hand	L.H.	Left hand
Hex.	Hexagonal	AR	As required

Revision No. &
Change Details



REV. NO., MM YY	PART NUMBER	SHORT DESCRIPTION	QTY.	SR. NO.	PAGE NO.	A: Add D: Delete C: Change	Reason for change

Revision No. &
Change Details



REV. NO., MM YY	PART NUMBER	SHORT DESCRIPTION	QTY.	SR. NO.	PAGE NO.	A: Add D: Delete C: Change	Reason for change

Plate No.	Description	Page No.
1	Cover Cylinder Head	2
2	Cylinder Head	4
3	Valve	6
4	Camshaft / Tensioner	8
5	Cylinder and Piston	10
6	Crankshaft	12
7	Transmission	14 - 16
8	Change Drum / Shift Fork	18
9	Gear Change Mechanism	20
10	Engine Assembly / Crankcase RH	22 - 24
11	Crankcase LH	26
12	Balancer Idler Gear / Water Pump	28
13	Oil Pump	30
14	Radiator	32 - 34
15	Cover Clutch	36
16	Cover Magneto	38
17	Clutch Assembly	40
17A	Clutch Assembly - FCC make	40A
18	Throttle Body	42
19	Air Cleaner Complete	44
20	EVAP Mechanism	46
21	Silencer Assembly	48 - 50
22	Starter Assembly	52
23	Magneto, Regulator & EMS	54
24	H.T. Coil	56
25	Seat Assembly / Seat Lock	58
26	Engine Mountings	60
27	Frame & Frame Fittings	62
28	Swing Arm, Rear Shock Absorber	64
29	Pillion Foot Rest, Holder	66 - 68
30	Mudguard - Front & Rear	70

Plate No.	Description	Page No.
31	Stand Assembly	72
32	Tube, Tyre, Rim	74
33	Front Hub	76
34	Master Cylinder - Front Disc Brake	78
35	Caliper Assembly - Front Disc Brake	80
36	Rear Hub	82
37	Rear Disc Brake Assembly	84
38	Rear Brake Pedal	86
39	Anti Lock Braking System (Single Channel)	88
40	Anti Lock Braking System (Twin Channel)	90
41	Handlebar Assembly	92
42	Front Fork	94 - 96
43	Petrol Tank, Cap Tank, Gauge Fuel	98
44	Fittings - Petrol Tank Cover	100 - 102
45	Fittings - Side Covers & Cover Seat	104
46	Meter Assembly	106
47	Control Cables	108
48	Chain Case	110
49	Head Lamp & Fairing	112 - 114
50	Indicator Light Assembly	116
51	Tail Lamp Assembly, Front Number Plate	118
52	Electrical Equipments	120 - 122
53	Tool Kit	124
54	Accessories / Grab Handle	126
55	Painted Parts & Decals	125 - 130
56A	Painted Parts and Decals - New C&G Oct 20	131 - 134
56B	Painted Casting Parts - C&G Scheme from October 2020	135 - 136
57	Consumable Parts	137 - 140
	Kits List	141 - 146

PLATE NO. : 1 COVER CYLINDER HEAD	PAGE NO. 1
--------------------------------------	---------------



PLATE NO. : 2 CYLINDER HEAD	PAGE NO. 3
--------------------------------	---------------




PLATE NO. : 3 VALVE	PAGE NO. 5
------------------------	---------------



PLATE NO. : 4 CAMSHAFT / TENSIONER	PAGE NO. 7
---------------------------------------	---------------



PLATE NO. : 5 CYLINDER & PISTON	PAGE NO. 9
------------------------------------	---------------




PLATE NO. : 6 CRANKSHAFT	PAGE NO. 11
-----------------------------	----------------




PLATE NO. : 7 TRANSMISSION	PAGE NO. 13 - 15
-------------------------------	---------------------



PLATE NO. : 8 CHANGE DRUM / SHIFT FORK	PAGE NO. 17
---	----------------



PLATE NO. : 9 GEAR CHANGE MECHANISM	PAGE NO. 19
--	----------------



PLATE NO. : 10 ENGINE ASSLY & CRANKCASE RH	PAGE NO. 21 - 23
---	---------------------




PLATE NO. : 11 CRANKCASE LH	PAGE NO. 25
--------------------------------	----------------




PLATE NO. : 12 BALANCER IDLER GEAR/WATER PUMP	PAGE NO. 27
--	----------------



PLATE NO. : 13 OIL PUMP	PAGE NO. 29
----------------------------	----------------




PLATE NO. : 14 RADIATOR	PAGE NO. 31 - 33
----------------------------	---------------------




PLATE NO. : 15 COVER CLUTCH	PAGE NO. 35
--------------------------------	----------------




PLATE NO. : 16 COVER MAGNETO	PAGE NO. 37
---------------------------------	----------------



Pictorial Index

RS 200 BS VI

PLATE NO. : 17 CLUTCH ASSEMBLY	PAGE NO. 39
-----------------------------------	----------------




PLATE NO. : 18 THROTTLE BODY	PAGE NO. 41
---------------------------------	----------------





PLATE NO. : 19 AIR CLEANER COMPLETE	PAGE NO. 43
--	----------------



PLATE NO. : 20 EVAP Mechanism	PAGE NO. 45
----------------------------------	----------------



Pictorial Index

RS 200 BS VI

PLATE NO. : 21 SILENCER ASSEMBLY	PAGE NO. 47 - 49
-------------------------------------	---------------------




PLATE NO. : 22 STARTER ASSEMBLY	PAGE NO. 51
------------------------------------	----------------



PLATE NO. : 23 MAGNETO, REGULATOR & EMS	PAGE NO. 53
--	----------------



PLATE NO. : 24 H.T. COIL	PAGE NO. 55
-----------------------------	----------------




PLATE NO. : 25 SEAT ASSEMBLY / SEAT LOCK	PAGE NO. 57
---	----------------




PLATE NO. : 26 ENGINE MOUNTINGS	PAGE NO. 59
------------------------------------	----------------




PLATE NO. : 27 FRAME & FRAME FITTINGS	PAGE NO. 61
--	----------------




PLATE NO. : 28 SWINGARM / REAR SHOCK ABSORBER	PAGE NO. 63
--	----------------




PLATE NO. : 29 PILLION FOOT REST / HOLDER	PAGE NO. 65 - 67
--	---------------------




PLATE NO. : 30 MUDGUARD - FRONT & REAR	PAGE NO. 69
---	----------------




PLATE NO. : 31 STAND ASSEMBLY	PAGE NO. 71
----------------------------------	----------------



PLATE NO. : 32 TUBE / TYRE / RIM	PAGE NO. 73
-------------------------------------	----------------



PLATE NO. : 33 FRONT HUB	PAGE NO. 75
-----------------------------	----------------




PLATE NO. : 34 MASTER CYLINDER - FRONT DISC BRAKE	PAGE NO. 77
---	----------------





PLATE NO. : 35 CALIPER ASSEMBLY - FRONT DISC BRAKE	PAGE NO. 79
--	----------------




- PISTON SEAL
- DUST SEAL
- BLEEDER CAP
- PROTECTION BOOT
- INSULATOR
- CALIPER PISTON
- BLEEDER SCREW
- PAD SPRING

PLATE NO. : 36 REAR HUB	PAGE NO. 81
----------------------------	----------------



PLATE NO. : 37 REAR DISC BRAKE ASSEMBLY	PAGE NO. 83
--	----------------



- PISTON SEAL
- DUST SEAL
- BLEEDER CAP
- PROTECTION BOOT
- INSULATOR
- CALIPER PISTON
- BLEEDER SCREW
- PAD SPRING

PLATE NO. : 38 REAR BRAKE PEDAL	PAGE NO. 85
------------------------------------	----------------




PLATE NO. : 39 ANTI LOCK BRAKING SYSTEM (SINGLE CHANNEL)	PAGE NO. 87
--	----------------



PLATE NO. : 40 ANTI LOCK BRAKING SYSTEM (TWIN CHANNEL)	PAGE NO. 89
--	----------------



PLATE NO. : 41 HANDLEBAR ASSEMBLY	PAGE NO. 91
--------------------------------------	----------------

PLATE NO. : 42 FRONT FORK	PAGE NO. 93 - 95
------------------------------	---------------------

PLATE NO. : 43 PETROL TANK, CAP TANK & GAUGE FUEL	PAGE NO. 97
---	----------------

PLATE NO. : 44 FITTING PETROL TANK COVER	PAGE NO. 99 - 101
---	----------------------

PLATE NO. : 45 FITTINGS - SIDE COVERS & COVER SEAT	PAGE NO. 103
--	-----------------

PLATE NO. : 46 METER ASSEMBLY	PAGE NO. 105
----------------------------------	-----------------

PLATE NO. : 47 CONTROL CABLES	PAGE NO. 107
----------------------------------	-----------------

PLATE NO. : 48 CHAIN CASE	PAGE NO. 109
------------------------------	-----------------

PLATE NO. : 49 HEAD LAMP & FAIRING	PAGE NO. 111 - 113
	

PLATE NO. : 50 INDICATOR LIGHT ASSEMBLY	PAGE NO. 115
	

PLATE NO. : 51 TAIL LAMP Assembly, FRONT NUMBER PLATE	PAGE NO. 117
	

PLATE NO. : 52 ELECTRICAL EQUIPMENTS	PAGE NO. 119 - 121
	

PLATE NO. : 53 TOOL KIT	PAGE NO. 123
	


PLATE NO. : 54 ACCESSORIES / GRAB HANDLE	PAGE NO. 125
	


PLATE NO. : 55 PAINTED PARTS & DECALS	PAGE NO. 127 - 131
	



PLATE NO. : 55A Painted Casting Parts - C&G Scheme from October 2020	PAGE NO. 133 - 137
	

PLATE NO. : 55B Painted Casting Parts - C&G Scheme from October 2020	PAGE NO. 139
	


PLATE NO. : 56 CONSUMABLE PARTS	PAGE NO. 139
	

PLATE NO. : 56 CONSUMABLE PARTS	PAGE NO. 141
	

Cover Cylinder Head




No.	Part No.	Description	Qty.	Remarks
1	JG 5110 22	Bolt Special	4	
2	JG 5110 21	Washer	4	
3	JL 5110 41	Cover Cylinder Head	1	
4	JL 5110 42	Gasket Head Cover	1	




Cylinder Head

No.	Part No.	Description	Qty.	Remarks
1	JG 5410 68	Hex Flange Head Bolt M10	4	Refer Kit List
2	LD A000 08	Washer 11.2*20*2T	4	
3	JL 5110 09	M6 Stud Bolt	2	
4	DT 5110 97	Assly Cylinder Head	1	
5	JL 3518 11	Oil Pressure Switch	1	
6	DK 1013 40	'O' Ring	1	For OBD2
7	JG 3514 00	Coolant Water Temp Sensor	1	
8	JG 5110 46	Stud (M8*1.25)	2	
9	KA EQ06 20	Bolt - Flange M6	2	
10	JL 5110 29	Cover Thermostat	1	
11	JL 6012 37	Thermostat Assembly	1	Bottom side
	JP 6012 13	Unit Thermostat	1	
12	39 2608 01	Grub Screw	1	
13	JL 5111 12	Sleeve Spark Plug	1	
14	KJ AC18 24	'O' Ring Sleeve	1	
15	39 1283 21	'O' Ring Sleeve	1	
16	JL 5110 22	Gasket Cylinder Head	1	
17	LB C000 02	Screw CSK Cross M6	3	
18	JL 5810 39	Pipe Intake	1	
19	JG 5814 07	O-Ring Pipe Intake	1	
20	LC L000 02	Nut Hex	1	
21	KD DB06 12	Washer Spring	1	




Valve

No.	Part No.	Description	Qty.	Remarks
1	39 2017 19	Seal - Oil	4	Precoated
2	JL 5110 10	Valve Intake	2	
3	JL 5110 11	Valve Exhaust	2	
4	DT 5112 61	Assly Rocker Arm Intake	1	
5	DT 5112 62	Assly Rocker Arm Exhaust	1	
6	JL 5111 14	Shaft Rocker Arm	2	
7	JL 5111 15	Plate Stopper	1	
8	LA E000 42	Bolt Flanged M6	2	
9	DG 1010 29	Cotter Valve	8	
10	36 JL00 11	Valve Repair Kit	1	
11	DH 1012 95	Wave Washer	2	
12	39 2440 11	Washer (Spring Steel)	4	



Camshaft / Tensioner


No.	Part No.	Description	Qty.	Remarks
1	JL 5112 71	Camshaft Assembly	1	
2	LP B000 07	Bearing Ball-12 x 28 x 8 x C3L	1	Not Serviceable
3	LP B000 04	Bearing Ball - 15 x 35 x 11-C3L	1	Not Serviceable
4	KE BB35 15	Circlip Internal	1	
5	JL 5112 50	Spacer Camshaft	1	
6	JL 5112 31	Sprocket Camshaft	1	Vendor LGB
	JL 5112 20	Sprocket Camshaft	1	Silent Chain
7	JG 5112 69	Bolt Special Flanged	1	
8	JL 5112 22	Timing Chain	1	Vendor Borgwarner
	JL 5112 30	Timing Chain	1	Silent Chain- LGB
9	JC 1010 34	Tensioner Assembly	1	
10	39 2669 21	Ring - O (Tensioner Bolt)	1	
11	KA EQ06 20	Bolt Hexagonal	2	
12	CS 1011 28	Gasket	1	
13	JG 5112 70	Bolt Flanged M6x1x6 L-Special	1	
14	DH 1013 92	Chain Guide Pivot Bolt	1	
15	36 JL00 01	Kit Cam Chain Guide	1	




Cylinder and Piston

No.	Part No.	Description	Qty.	Remarks
1	36 JL00 07	Kit Block & Piston	1	
2	36 JU00 01	Kit Piston Ring	1	
3	JU 5212 10	Pin Piston	1	
4	JU 5212 12	Ring Snap	2	
5	39 2181 06	Pin - Hollow Dowel 14 X 20	2	
6	JG 5210 08	Gasket Block Cylinder	1	

Crankshaft




No.	Part No.	Description	Qty.	Remarks
1	36 JU00 36	Kit Crank Shaft Assembly	1	Refer Kit List
2	39 1931 20	Bearing - Ball 28 X 68 X 18	1	
3	39 1931 20	Ball Bearing 28 X 68 X 18	1	
4	JG 5310 40	Nut	1	
5	LD H000 02	Belleville Washer	1	
6	JG 5310 41	Balancer Drive Gear	1	
7	LC D000 01	Nut Sprocket Drive Lock	1	
8	39 2200 11	Washer - Plain	1	
9	JG 5310 27	Sprocket Crankshaft	1	
10	JL 5310 06	Sprocket Crankshaft	1	Silent chain - LGB
10	36 DT00 55	Kit Primary Gear Drive+Driven	1	Refer Kit List
11	JG 5310 31	Spacer Crankshaft	1	
12	31 1011 73	Key-Woodruff Clutch Side	3	
	KF AB40 50	Key-Woodruff	3	From Sept 21
13	JF 5310 14	Bolt Conrod	2	
14	JU 5310 21	Bush Big End	2	
15	39 2203 07	Parallel Pin	2	
16	JF 5310 07	Conrod Assly Compl	1	
17	JG 5512 16	Gear Primary Drive 22T	1	




Transmission

No.	Part No.	Description	Qty.	Remarks
1	JG 5510 27	Shaft Input T/M Comp	1	
2	39 2158 11	Washer - Plain	1	
3	JG 5510 13	Bush 6th Drive / Bush 2nd Driven	2	
4	JG 5512 13	Gear 6th Drive	1	
5	JG 5510 20	Washer Splined	3	
6	JP 5510 12	Washer - ID16 x OD26 x Thk1	1	
7	JG 5512 14	Gear Drive Multiple 3&4	1	
8	JG 5512 20	Gear 5th Drive	1	
9	JG 5512 27	Gear 2nd Drive	1	
10	JG 5510 22	Washer - Plain	1	
11	JU 5510 03	Shaft Output - plug	1	
12	DH 1012 35	Circlip	2	
13	39 2166 11	Washer Plain	1	
14	JU 5512 01	Gear Driven Second	1	
15	BF 5510 37	Ring - Snap	4	
16	JP 5512 25	Gear 5th Driven	1	
17	JP 5512 24	Gear 3rd Driven	1	
18	39 2159 11	Washer - Plain	1	
19	JP 5510 11	Collar	1	
20	JG 5512 15	Gear 4th Driven	1	




Transmission

No.	Part No.	Description	Qty.	Remarks
21	JP 5512 26	Gear 6th Driven	1	
22	JG 5510 00	Bush 1st Driven	1	
23	JG 5512 25	Gear 1st Driven	1	
24	DK 1013 52	O-Ring Spkt. Collar(17.5*1.5)	1	
25	JG 5510 31	Collar Sprocket	1	
26	DJ 1013 12	Plate Drive Sprocket	1	
27	LA E000 17	Bolt Flanged - M6x1x10L - Precoated	2	




Change Drum / Shift Fork

No.	Part No.	Description	Qty.	Remarks
1	JG 5610 11	Drum Complete Gear Shift	1	
2	EC 5610 23	Spring Gear Switch Indicator	1	
3	39 2606 07	Pin - Parallel	1	
4	JG 5610 10	Spacer-Guide Gear Shift	1	
5	JG 5612 22	Guide Gear Shift	1	
6	DH 1013 89	Bolt Socket - M6 x 1 x 20L	1	
7	JG 5610 12	Fork Gear Shift Input	1	
8	JP 5610 03	Fork Gear Shift Output	2	
9	JG 5610 16	Shaft Gear Shift Fork	1	
10	JG 5612 25	Shaft Gear Shift Fork Output	1	
11	JG 5612 15	Compression Spring	2	



Gear Change Mechanism


No.	Part No.	Description	Qty.	Remarks
1	DT 5614 08	Lever Complete Change	1	New C&G from Oct 20
2	DT 5614 09	Assembly Lever Change Arm	1	
	DT 5614 16	Arm Assembly Change	1	
3	KA DD06 22	Bolt Flanged	1	
4	KC AM06 05	Nut Hex Thick - M6 x 1	1	
5	LC B000 03	NUT (LM6 x 1)	1	New C&G from Oct 20
6	DT 5612 05	Damper	1	
7	DT 5612 01	Assembly Lever Gear Change	1	
	DT 5614 14	Lever Assembly Change	1	
8	JL 5614 09	Bolt Gear Change Lever	1	
9	01 1009 05	'O' Ring	2	New C&G from Oct 20
10	JL 5614 10	Washer - Steel	1	
11	DT 5612 06	Lever Gear Shift Assy Comp.	1	
12	JG 5612 15	Compression Spring	1	
13	JG 5612 17	Bush-Torsion Spring	1	
14	JG 5612 32	Spring Torsion	1	New C&G from Oct 20
15	JG 5612 16	Washer 14 x 30 x 1.5	1	
16	52 DT11 69	Torque Rod	1	




Engine Assembly / Crankcase RH

No.	Part No.	Description	Qty.	Remarks
1	DT 5010 30	Engine Assembly	1	For OBD2 Refer Kit List
	DT 5010 52	Engine Assembly	1	
2	36 DT00 79	Kit Asly Crankcase RH	1	
3	39 1931 20	Ball Bearing 28 X 68 X 18	1	
4	JY 5410 47	Stopper I/P Shaft Bearing	1	
5	LA D000 77	Bolt Flanged M6x16	1	
6	JG 6010 07	Special Shaft Seal Ring (oil)	2	
7	JL 5312 05	Assembly Balancer Integral	1	
8	39 2602 20	Bearing - Ball 6202/HN3	1	
9	AA 1014 37	Screw Precoated	1	
10	JG 5410 59	Plate Stopper Bearing Drum	1	
11	39 2601 20	Bearing Ball 61905 (25X42X9)	1	
12	LB B000 06	Screw Pan head	3	
13	JU 5410 05	Breather Plate	1	
14	59 2000 28	Bearing Ball RH	1	
15	JG 5612 04	Bolt Drum Stopper	1	
16	JG 5612 05	Washer	1	
17	JG 5610 09	Stopper Drum Complete	1	
18	LD B000 50	Washer	1	
19	JG 5612 26	Spring	1	
20	39 2562 20	Bearing - Needle Roller	1	

Engine Assembly / Crankcase RH




No.	Part No.	Description	Qty.	Remarks
21	LB B000 07	Screw Pan Cross M6	1	
22	JG 5410 45	Input Shaft Bearing Stopper	1	
23	DP 1011 91	Bolt Shifter	1	
24	JG 5710 14	Oil Filter	1	
25	JG 5710 16	O-Ring	1	
26	JL 5710 01	Cap Oil Filter	1	
27	KA EQ06 16	Bolt Flange Small - M6	2	
28	JL 6010 10	Water Seal Double Lip	1	




Crankcase LH

No.	Part No.	Description	Qty.	Remarks
1	36 DT00 85	Kit Assembly Crankcase LH	1	Refer Kit List
2	AA 1014 37	Screw Pre-Coated	2	
3	39 2562 20	Needle Bearing	1	
4	JU 5410 18	Bracket Harness Upper	1	
5	JG 5410 44	Bracket Harness Lower	1	
6	KA DP05 16	Bolt Flange - M5	2	For Twin Channel ABS
7	DT 3518 06	Sensor Assembly Pick Up	1	For Twin Channel ABS
	DT 3510 16	Sensor Assembly Pick Up	1	For OBD2
8	39 1043 19	Seal Oil	1	Gear Change lever
9	KE BB37 15	Circlip Internal	1	Output Shaft
10	JY 5410 58	Oil Seal Output Shaft	1	
11	59 2000 06	Bearing Ball	1	Output Shaft
12	JG 5410 15	Needle Bearing	1	Drum
13	BF 5610 20	Bearing Plain	1	
14	JY 5710 30	Mesh Oil Filter Assembly	1	
14A	LJ A000 04	'O' Ring Strainer	1	
15	JA 5410 48	Strainer Cap with 'O' Ring	1	
16	JG 5410 41	Gasket Crankcase	1	
17	59 2100 23	O - Ring	1	
18	JG 5410 58	Chain Guard	1	
19	LB B000 07	Screw Pan Cross M6x1xL12	4	
20	JG 5410 43	Retainer Gear Starter	1	
21	LA E000 42	Bolt Flange M6x1xL16	1	
22	KA EQ06 40	Bolt Flange Small M6x1xL40	10	
23	LA E000 10	Bolt Flange M5 x 13L	2	
24	LA D000 81	Bolt Flanged	4	



Balancer Idler Gear / Water Pump


No.	Part No.	Description	Qty.	Remarks
1	JL 5312 05	Assembly Balancer Integral	1	
2	KP BF62 03	Bearing Ball-C3 Clearance-HN3	2	
3	JL 5312 03	Sleeve Balancer Driven	1	
4	JG 5312 29	O Ring Balancer Driven	1	
5	JG 5312 15	Washer (2.5MM)	1	
6	JG 6010 05	Dome Nut	1	
7	JG 5312 07	Gear Balancer Driven	1	
8	DS 1011 54	Key	1	
9	LD B000 51	Washer Plain	1	
10	LA C000 86	Bolt Socket	1	
11	36 JL00 39	Kit Water Pump Rotor & Seal	1	
12	JL 6010 05	Cover Water Pump	1	
13	JG 6010 12	O-Ring (Water Pump Cover)	1	
14	KA EW06 22	Bolt Flange Small - M6	5	
15	39 1665 11	Washer - Seal	1	
16	39 2606 07	Pin - Parallel	2	
17	LA E000 17	Bolt Flanged	1	
	LA E000 48	Bolt Flanged	1	From Sept 21
18	39 1665 11	Plain Washer (non Ferrous)	1	




Oil Pump

No.	Part No.	Description	Qty.	Remarks
1	JU 5710 00	Oil Pump Assy Comp	1	
2	36 JG00 04	Shaft Oil Pump Assy	1	
3	JG 5710 18	Gear Oil Pump Drive	1	
4	KE AB10 10	Circlip External	1	
5	39 0999 06	Pin - Hollow Dowel	2	
6	LA E000 18	Bolt Flanged M6X1X30L	3	

Radiator




No.	Part No.	Description	Qty.	Remarks
1	DT 1810 01	Cowl Radiator	1	
2	DT 1810 28	Plug Push Pull	4	
3	JG 1710 31	Clip Nut - M5	4	
4	39 2141 24	Washer Nylon	4	
5	LB U000 23	Screw	4	
6	DT 6012 32	Radiator Core	1	
7	JP 6012 35	Fan Radiator	1	
8	JL 6012 16	Rubber Damper Radiator Mounting	2	
9	39 2704 11	Washer	4	
10	JG 5810 14	Silent Block (M6)	2	
11	LC G000 29	Nut Hex Flange - M6	4	
12	KD BA06 13	Washer Plain	1	
13	KB UF06 12	Screw Truss	1	
14	DT 6012 26	Expansion Tank	1	
15	DT 6012 28	Tube Connecting	1	
16	DT 6012 10	Tube Drain	1	
17	JG 6012 11	Cap Expansion Tank	1	
18	JG 6012 30	O-Ring Cap	1	
19	JG 6012 35	Radiator Cap	1	
20	JG 6012 34	Clamp	2	
21	JL 6012 22	Hose Thermosat to Radiator	1	
22	JL 6012 23	Hose Radiator to T pipe	1	
23	JL 6012 28	Coolant Pipe T Assembly	1	
24	BF 6010 13	Clamp Hose	2	




Cover Clutch

No.	Part No.	Description	Qty.	Remarks
1	52 JL08 92	Assly CI Cover	1	Refer Kist List
	36 JL02 27	Assly CI Cover Satin Black	1	From Oct 20 New C&G
2	39 1990 20	Bearing - Needle	1	
3	LD B000 20	Washer 12.5X24X0.8T	1	
4	JG 5510 17	Spring	1	
5	DT 5410 19	Shaft Clutch Release Assembly	1	
6	JU 5514 01	Rod Push	1	
7	JG 5412 30	Cap Oil Filling	1	
7A	KJ AA14 24	'O' Ring	1	
8	JL 5412 27	Window Oil Gauge	1	
9	DS 1012 15	Clip - Wire	1	
10	39 1041 19	Seal - Oil	1	
11	39 0999 06	Pin - Hollow Dowel	2	
12	JL 5412 07	Gasket Clutch Cover	1	
	JL 5412 77	Gasket Clutch Cover	1	From Sept 21
13	DT 5410 18	Bracket Clutch Cable	1	
14	KA EQ06 30	Bolt Flange Small - M6	11	
15	39 1046 19	Seal - Oil	1	
16	JG 5412 31	Plate -position	1	
17	AA 1014 37	Screw Pre-Coated	2	
18	JL 5412 22	Decal Triple Spark	1	
19	JL 5412 18	Jet Oil Clutch Cover	1	
20	JL 5412 30	Damper Clutch Cover	1	
21	JL 5412 31	Plate Damper Clutch Cover	1	
22	DH 1013 88	Bolt Flange	5	



Cover Magneto

No.	Part No.	Description	Qty.	Remarks
1	52 DT04 54	Assembly Cover Magneto	1	
	36 DT01 12	Kit Assly Magneto Cover Satin Black	1	From Oct 20 New C&G
2	JA 5412 33	Cap TDC Finder	1	
3	30 1011 95	Ring - O	1	
4	39 0999 06	Pin - Hollow Dowel	2	
5	JG 5412 11	Gasket Cover Magneto	1	
6	KA EQ06 30	Bolt Flange Small - M6x1xL30	9	
7	JL 5412 03	Cover LH RR	1	
8	KA EQ06 45	Bolt Flange Small	1	
9	JF 2330 36	Label Gear Shift 6 Speed	1	
10	JL 5412 23	Decal 'Bajaj logo'	1	
11	DT 5412 10	Jet Oil Stator	1	
12	BA 1020 04	Plug	1	



Clutch Assembly


No.	Part No.	Description	Qty.	Remarks
1	DT 5514 09	Clutch Assy Comp	1	Refer Kit List
2	DT 5514 12	Collared Bush	1	
3	36 DT00 55	Kit Primary Gear Drive+Driven	1	
4	JG 5514 28	Washer Clutch	1	
5	DT 5514 02	Plate Clutch Pressure	1	
6	JG 5514 48	Friction Plate	4	
	JG 5514 55	Friction Plate	2	
7	DT 5514 08	Clutch Plate Steel	5	
8	JG 5514 43	Clutch Holder	1	
9	DT 5514 01	Center Clutch	1	
10	DT 5514 03	Spring Clutch	4	
11	JG 5514 51	Bolt	4	
12	JL 5514 07	Spring Bellville	1	
13	DH 1016 48	Nut Clutch Center Lock	1	
14	JG 5514 23	Clutch Lifter Bearing	1	




Clutch Assembly - FCC

No.	Part No.	Description	Qty.	Remarks
1	JL 5514 24	Clutch Assy Comp	1	
2	DT 5514 12	Collared Bush	1	
3	36 DT00 55	Kit Gear Primary Drive + Driven	1	
4	JG 5514 28	Washer Clutch	1	
5	YJ P880 14	Plate Clutch Pressure	1	
6	36 JP01 49	Kit Friction Plate	1	
7	YJ R050 12	Clutch Plate	5	
8	YJ P880 18	Clutch Lifter Plate	1	
9	YJ P880 09	Center Clutch	1	
10	YJ R050 19	Spring Clutch	3	
11	YJ P880 19	Bolt 6*22	3	
12	JL 5514 07	Spring Bellville	1	
13	DH 1016 48	Nut Clutch Center Lock	1	
14	JG 5514 23	Clutch Lifter Bearing	1	
15	YJ R050 17	Seat Judder Spring	1	
16	YJ R050 18	Spring Judder	1	

Throttle Body




No.	Part No.	Description	Qty.	Remarks
1	DT 6112 10	Assembly Throttle Body EVAP	1	
	JL 6112 05	Assembly Throttle Body	1	For Aisan pump
2	JG 6110 07	Fuel Injector	1	
3	DT 6112 08	Injector Cap With Quick Conn.	1	
	JL 6110 01	Injector Cap With Quick Conn.	1	For Aisan pump
4	JG 5814 24	Fixing Screw M5 x 12	5	
5	JG 6112 06	Stepper Motor (IACV)	1	
6	JG 3518 05	Sensor TMAP	1	
7	DS 1611 56	Plug Seat	1	
8	DT 3518 03	Sensor Throttle Position	1	
9	JG 5814 23	Fixing Screw M4 x 12	2	
10	JG 6110 06	Injector Clip	1	
11	JG 5814 19	Bracket Throttle Cable	1	




EVAP Mechanism

No.	Part No.	Description	Qty.	Remarks
1	JY 1710 77	Canister	1	
2	DT 1716 13	Pipe Connector - Canister	1	
3	JU 1716 06	Valve Purge	1	
4	JY 1710 69	Spring Band Clamp 15 x 10	1	
5	JL 1711 02	Clamp Band Spring 12.5 x 8	3	
6	DT 1716 12	Pipe Valve Purge - Connector	1	
7	JG 1710 86	Connector Tube EVAP	2	
8	DT 1718 47	Tube Connector To Throttle Body	1	
9	JY 1710 70	Spring Band Clamp 9 x 8.4	4	
10	JY 1138 42	Connector Y Shape	1	
11	DT 1718 46	Tube Y Connector To Canister	1	
12	JF 1716 07	Tube Connector To Plug	1	
13	JY 1718 25	Plug Fuel Drain	1	
14	JL 1718 36	Tube Tank To Y Connector	1	
15	JZ 1710 55	Strap Canister	2	
16	DT 1138 41	Bracket Canister Mounting	1	
17	JD 1710 59	EVAP Cap Rubber Bush Sealing	1	
18	JF 1718 07	Tube Canister Drain	1	
19	DT 1718 21	Clamp Ear	3	
20	JL 1711 01	Clamp Band Spring 9.5 x 8.4	2	



EVAP Mechanism


No.	Part No.	Description	Qty.	Remarks
21	JG 1710 29	Clamp	3	
22	DT 1718 52	Clamp Ear	1	
23	DT 1716 11	Pipe Connector - Valve Purge	1	
24	JF 1710 64	Band Cable	1	
25	KA DA06 12	Bolt Flanged	2	
26	DT 1138 64	Bracket Valve Purge	1	
27	KC GA06 06	Nut Hex Flanged	1	
28	KA AD06 10	Bolt	1	



FWD Front Wheel Direction


Silencer Assembly

No.	Part No.	Description	Qty.	Remarks
1	JL 5913 24	Pipe Assembly A	1	From 15.12.2020
	JL 5913 88	Pipe Assembly A	1	
2	JG 5910 70	Gasket Exhaust	1	
3	JP 5910 65	Sensor Oxygen	1	
	JB 5910 98	Sensor Oxygen	1	
4	JG 5910 38	Band Clip	1	For Varroc ECU Model
5	JG 5910 39	Gasket Muffler Pipe-a	1	
6	DT 5913 40	Assembly Muffler	1	
6A	JL 5911 57	Sleeve Bottom	2	
7	DT 5911 16	Assembly Heat Shield	1	
8	DT 5911 18	Grommet Heat Shield	1	
9	PD 5911 01	Truss Screw	2	
10	52 DT01 53	Assembly End Chamber	1	
11	DT 5910 72	Band Clip End Chamber	1	
12	JL 5910 45	Spacer Pipe A Proto 1	1	
13	JL 5911 65	Damper Silencer Mtg. Lower	4	
14	JL 5911 56	Sleeve Top	4	
15	LC G000 06	Nut Hex	2	
16	39 1850 04	Bolt Flanged	1	
17	39 2425 11	Washer	2	
18	DH 1611 57	Tube Silencer Mtg.	1	
19	DH 1611 55	Damper Silencer	1	
20	DD 1610 71	U nut M10	1	




Silencer Assembly

No.	Part No.	Description	Qty.	Remarks
21	JL 5911 48	Bolt Flange	2	Taper End
22	KA DA06 30	Bolt M6x30	2	
23	DT 5911 31	Chamber LH	1	
24	DT 5911 32	Chamber RH	1	
25	LA C000 62	Bolt Socket M5 x 0.8 x L33	3	
26	JG 5910 68	Rubber Bush G2	1	
27	LA D000 36	Bolt Flanged M8x1.25xL43	1	
28	LD A000 09	Washer Plain	1	
29	LB U000 22	Screw Truss	5	
30	DJ 1810 65	Clip Nut	2	
31	DT 5911 33	Chamber End Cap	1	




Starter Assembly

No.	Part No.	Description	Qty.	Remarks
1	JL 3516 00	Starter Motor Assly.	1	
1A	KA DQ06 25	Bolt M6-Motor mtg.	2	
2	JG 6214 13	Gear Starter Counter 2 Assy	1	
3	JG 6214 12	Gear Starter Counter 1	1	
4	JG 5310 41	Balancer Drive Gear	1	
5	LD H000 02	Washer Conical	1	
6	JG 5310 40	Nut Balancer	1	
7	JG 6214 17	Assembly Gear Starter Clutch	1	With NRB
8	LD B000 10	Plain Washer	1	
9	52 JY01 85	Bolt Flange Pre-coated	1	M10 x 1.25 x L50
10	JG 3510 19	Body Complete Starter Clutch	1	
11	JY 5514 02	Clutch One Way Assly	1	
12	LD F000 01	Washer - Lock Toothed	4	
13	DH 10 13 89	Pre-coated Screw	4	
14	JA 3516 27	'O' Ring Starter Motor	1	
15	JG 5410 43	Retainer Gear Starter	1	
16	LA E000 42	Bolt Flange	1	
17	BF 6214 02	Needle Bearing (25X32X16)	1	
18	DT 4022 34	Harness Pigtail Magneto To RR	1	




Magneto & H.T. Coil

No.	Part No.	Description	Qty.	Remarks
1	JY 3510 19	Rotor Without Clutch Assy	1	Precoated
2	DT 3510 15	Stator Assembly	1	
3	LA C000 03	Bolt Socket - M5 x 0.8 x L40	3	
4	KA DD05 08	Bolt Flanged	2	
5	JG 5412 23	Bracket Harness - G2	1	
6	KA DD06 20	Bolt flanged	4	
7	JE 3512 56	HT Coil 1 With Cable	1	
8	DK 1110 11	Cap Spark Plug	1	
9	DH 1110 13	Grommet - Spark Plug	2	
10	JL 3512 18	Plug Spark	1	
11	JL 3512 52	HT Coil 2 With Cable	1	
12	DD 1110 12	Grommet For H. T. Cable	3	
13	JD 3512 07	Spark Plug Cap	1	
14	AN 1110 15	Spark Plug Cap	1	
15	DH 1110 16	Grommet - Sleeve Spark Plug	1	
16	DD 1110 11	Grommet - Spark Plug Cap	1	
17	DK 1110 28	Spark Plug RG6HCC	2	
18	AN 1013 48	Clip Hose Rotatable	1	
19	DT 1138 55	Clamp HT Coils	1	




Seat Assembly / Seat Lock

No.	Part No.	Description	Qty.	Remarks
1	DT 1910 06	Seat Assembly - Front	1	
2	JG 1910 08	Collar-seat	2	
3	FD 2110 06	Grommet Seat	2	
4	DK 2110 09	Damper For Seat	2	
5	JZ 1910 10	Damper Seat	2	
6	DT 1910 12	Damper Seat Front	1	
7	DS 1612 87	Bolt	2	
8	DT 1910 09	Seat Assembly - Rear	1	
9	DS 2110 04	Damper Seat	4	
10	DS 1611 56	Plug Seat Lock Cable	1	
11	KA DA06 22	Bolt Flange	2	
12	DT 2326 05	Lock Rear Seat	1	
13	DT 2326 06	Set Lock	1	
14	JL 2326 04	Cover Seat Lock	1	
15	DT 1910 22	Grommet Rear Seat Rear	1	
16	JG 2326 03	Bracket Seat Lock Barrel	1	
17	JG 2326 06	Seat Lock Cable	1	




Engine Mountings

No.	Part No.	Description	Qty.	Remarks
1	52 JL01 56	Engine Stay Assembly LH	1	Black Color
2	52 JL01 57	Eng Stay Assembly RH	1	Black Color
3	DT 1134 08	Bolt - Flanged Small	4	
4	JL 1110 54	Engine Mtg Bolt Front	1	
5	JA 1134 03	Flanged Bolt M10X110	2	
6	KC GD10 10	Nut Hex Flanged	3	
7	DT 1138 42	Cover Seal Heat	1	




Frame and Frame Fittings

No.	Part No.	Description	Qty.	Remarks
1	DT 1112 14	Frame Assembly	1	
2	36 JG00 11	Kit Steering head bearing	1	
3	DT 1812 65	Grommet Side Cover	2	
4	JL 1710 20	Grommet Tank Rear	1	
5	DS 2110 04	Damper Seat I	2	
6	JZ 1813 22	Side Cover Grommet	2	
7	DT 1138 58	Tape Frame	3	
	JG 2330 01	Tape Frame	4	From Oct 20 New C&G
8	DK 1810 51	Cage Bearing Steering Bottom	1	
9	DT 1813 23	Plug 1	1	
10	DT 1710 76	Damper Tank Cover	2	
11	DT 1138 46	Frame Beading RH	2	
12	DT 1813 21	Pad Tank Cover Resting	1	
13	JB 1812 23	Beading LH	2	
14	DT 1111 06	Frame Rubber Pad LH	1	
15	DT 1111 07	Frame Rubber Pad RH	1	
16	DT 1318 75	Clamp Brake Hose	1	
17	DK 1810 50	Cage Bearing Steering Top	1	
18	JL 1138 41	Clamp Tie Cable	10	
19	DG 1810 04	Seal Oil	1	
20	DG 1810 03	Washer	1	



Swing Arm / Rear Shock Absorber


No.	Part No.	Description	Qty.	Remarks
1	DT 1220 19	Shock Absorber Mono	1	From Oct 20 New C&G
	DT 1220 32	Shock Absorber Mono	1	
2	LA C000 19	Bolt Socket M10 X 1.25 X 55	2	
3	DT 1220 29	Arm Assembly Swing	1	
4	DG 1710 16	Sleeve	2	
5	DG 1710 18	Bearing - Needle	2	
6	DG 1710 19	Seal - Oil	4	
7	JL 1220 02	Cap Swing Arm Tube	2	
8	JL 1220 01	Adjuster Chain LH	1	
9	JL 1220 09	Adjuster Chain RH	1	
10	JL 1220 03	Slider Chain	1	
11	39 0454 11	Washer - Plain	2	
12	39 0553 02	Screw - Self Tapping	2	
13	JL 1220 04	Spacer Chain Adjuster	2	
14	JL 1220 08	Spacer Central Swing Arm	2	
15	JL 1812 24	Grommet I	1	
16	JL 1812 25	Grommet II	1	
17	JL 1220 26	Shaft - Swing Arm	1	
18	DT 1138 48	Cap - Swing Arm pivot	2	
19	39 1053 15	Nut Hexagon with Flange M14	1	
20	JL 2330 19	Label Tyre Info	1	




Pillion Foot Rest / Holder

No.	Part No.	Description	Qty.	Remarks
1	56 DT3Y 1Y	Holder Step RH Slate Gray	1	
2	DT 1130 29	Step Assy Main RH	1	
3	JL 1130 12	Spring Torsion	2	
4	LA C000 45	Bolt Socket - M8	4	
5	56 DT3X 1Y	Holder Step LH Slate Gray	1	
6	DT 1130 28	Step Assembly Main LH	1	
7	LA C000 74	Bolt Socket M8X35	4	
8	56 DT4J 1Y	Step Holder- Pillion LH S Gray	1	
9	56 JF18 1Y	Step Pillion LH S Gray	1	
10	36 JL00 15	Kit Pillion Hardware	2	
11	56 JF19 1Y	Step Pillion RH S Gray	1	
12	56 DT4K 1Y	Step Holder- Pillion RH S Gray	1	
13	JL 1318 41	Bracket Reservoir Mtg.	1	
14	KA DD06 12	Bolt Flanged	1	
15	JZ 1130 61	Rubber Pad Footrest	2	
16	JL 1130 36	Rubber Pad Footrest	2	
17	DT 1130 14	Lock Plate LH	1	
18	DT 1130 15	Lock Plate RH	1	
19	36 JL00 41	Kit Main Step Hardware	2	

Pillion Foot Rest / Holder




No.	Part No.	Description	Qty.	Remarks
22	KH AA25 20	Pin Cotter	4	
23	KD AA08 16	Washer Plain Small	4	
24	JL 1130 37	Pin Foot Step	4	
25	LD A000 13	Washer Plain	1	
26	GF 1611 43	Spring Pillion Footrest	1	
27	DT 1130 35	Tape Holder Step LH	1	
28	LA A000 09	Bolt - M6 x 1 x L10	1	
29	JL 1130 06	Rubber Main Step	2	



Mudguard - Front & Rear

No.	Part No.	Description	Qty.	Remarks
1	DT 1318 37	Bracket -Hose Clamp	1	
2	DT 1814 33	Plug Front Fender	1	
3	DT 1814 35	Grommet Front Fender	2	
4	DT 1814 37	Bracket Brace Fender	1	
5	JL 1813 25	Plug	1	
6	JG 1134 07	Bolt Flange M8	4	
7	KA CF05 30	Bolt - Hexagon Socket M6	2	
8	DT 1814 34	Cup Washer	2	
9	DT 1814 39	Spacer Fender Front	2	
10	FD 2210 19	Bolt Flanged M8	3	
11	DT 1812 56	Seat Cowl Central Bottom	1	
12	39 1907 01	Screw M5	8	
13	39 2141 24	Washer Non Metallic	8	
14	DJ 2011 73	Grommet For Cables	2	
15	DJ 1610 91	Grommet - Front Fender	4	
16	JL 1812 20	Grommet - 2 Seat Cowl	3	
17	KA DT06 14	Bolt Flanged M6 x L14	2	




Stand Assembly

No.	Part No.	Description	Qty.	Remarks
1	DT 1132 04	Assembly Side Stand	1	(Side Stand Switch)
2	DT 1132 05	Bracket Side Stand.	1	
3	JZ 4036 01	Magnet Holder	1	
4	JL 1132 09	Spring Side Stand	1	
5	DH 1611 46	Cover Spring Side Stand	1	
6	DF 1611 02	Bolt	1	
7	LC H000 01	Nut Nyloc - M10	1	
8	DT 1132 02	Bolt Spl-stand Mtg	1	
9	LA D001 35	Bolt Flange - M8	1	
10	KA DA05 16	Bolt Flanged	1	
11	JF 4014 05	Side Stand Switch	1	
12	JL 1138 18	Cover Side Stand Switch	1	
13	KD BB08 18	Washer Plain	1	




Tube / Tyre / Rim

No.	Part No.	Description	Qty.	Remarks
1	DT 1310 18	Tyre Tubeless Front 100/80-17	1	Not Serviceable
2	DK 1510 26	Valve Tubeless Tyre	2	
3	JL 1310 04	Wheel Rim 2.5X17	1	
	56 DT2Z 5N	Wheel Rim Front Blue Colour	1	
4	JL 1312 09	Wheel Rim 3.5X17	1	
5	DT 1312 22	Tyre Tubeless Rear 130/70-17	1	Not Serviceable




Front Hub

No.	Part No.	Description	Qty.	Remarks
1	JL 1310 01	Axle	1	Wheel Front 1
2	DT 1310 17	Collar Assembly Wheel Front	1	
3	KP BC62 02	Bearing - Ball	2	
4	JL 1310 04	Wheel Front	1	
5	JG 1310 01	Spacer Assembly Front Wheel	1	
6	DG 1510 05	Seal - Oil	1	
7	DT 1318 02	Disc 300 mm	1	
8	JU 1318 01	Sensor Disc Front	1	
9	JD 1318 11	Special Bolt M8	6	
10	JL 1310 00	Collar	1	
11	LD B000 29	Washer	1	
12	LC J000 02	Nut - U M14	1	
13	DK 2011 64	Sensor speed wheel	1	
14	KA DT06 14	Bolt Flanged - M6	1	
15	DT 1318 78	Clamp W ABS Hose	1	
16	KE BA35 15	Circlip Internal	1	For Dt14




Master Cylinder - Front Disc Brake

No.	Part No.	Description	Qty.	Remarks
1	DJ 1910 57	Lever Front Brake	1	
2	DJ 1910 29	Bolt Front Brake Lever	1	
3	DJ 1910 30	Nut	1	
4	36 DH19 02	Oil Window Kit	1	
	DE 1910 36	Oil Window Kit	1	
5	DJ 1910 31	Screw	2	
6	DE 1910 29	Cover - Reservoir	1	
7	DE 1910 28	Diaphragm	1	
8	DT 1318 31	Master Cylinder with lever	1	
9	36 DT00 36	Kit Switch Front M Cylinder	1	
	DJ 2011 09	Front Brake Switch (Minda)	1	
10	DE 1910 10	Washer - Copper	8	
11	DK 1510 69	Bolt - Banjo	4	
12	DK 1810 52	Clamp - Holder : RH	1	
13	DJ 1910 28	Bolt Flanged M8X1X50	2	
14	36 DT00 34	Major Kit M Cylinder - ABS	1	
14A	36 DT00 35	Minor Kit M Cylinder - ABS	1	




Caliper Assembly - Front Disc Brake

No.	Part No.	Description	Qty.	Remarks
1	DT 1318 53	Caliper Assy Brake Front	1	
2	DE 1510 46	Screw Bleeder	1	
3	DE 1510 47	Bleeder Cap	1	
4	JL 1318 07	Boot	1	
5	JL 1318 32	Disc Pad	1	
6	JL 1318 31	Minor Kit	1	
7	JL 1318 30	Major Kit	1	
8	DH 1510 39	Bolt Flange :- Re-coated (M8)	2	Caliper Mounting




Rear Hub

No.	Part No.	Description	Qty.	Remarks
1	DK 2011 64	Sensor speed wheel	1	
2	KA DD06 14	Bolt Flanged	1	
3	JL 1312 03	Axle Rear	1	
4	LD B000 29	Washer Rear Axle RH	2	
5	LC L000 04	Nut U Flange - M8	6	
6	JL 1312 11	Spacer for Coupling	1	
7	DK 1510 12	Seal Oil	1	
8	KP AC60 05	Bearing Ball Ordinary Clearance	1	
9	JL 1312 25	Coupling - 6 Plug	1	
10	LA A000 19	Bolt - D	6	
11	DK 1510 15	Sleeve	1	
12	JL 1312 32	Damper Coupling	1	
13	KP BC62 02	Bearing - Ball - C3 Clearance	1	
14	JL 1312 09	Wheel Rear 3.5 x 17	1	
15	JL 1312 16	Collar Bearing Assy	1	
16	KP BC63 02	Bearing - Ball - C3 Clearance	1	
17	30 1510 82	Seal Oil	2	
18	JL 1319 30	Disc Rear Dia - 230 mm	1	
19	DH 1510 40	Bolt Socket - M6 x 1 x L16	6	
20	JU 1318 02	Sensor Disc Rear	1	
21	JG 1312 20	Screw Pan Cross - M6 x 1 x L12	3	
22	DK 1510 82	Spacer II	1	
23	DK 1510 81	Spacer I	1	
24	LC J000 02	Nut - U - M14	1	
25	36 DT00 07	Kit Chain Sprocket	1	1Refer Kit List
26	KE BA42 17	Circlip Internal	1	For Dt14




Rear Disc Brake Assembly

No.	Part No.	Description	Qty.	Remarks
1	DT 1318 26	Assembly Caliper	1	Golden Colour
	JF 1318 58	Assembly Caliper	1	Black Colour
2	DT 1318 17	Assembly Master Cyl. Rear	1	
	JL 1319 90	Assembly Master Cyl. Rear	1	Black Colour
3	KB BA05 12	Screw	1	
4	DK 1510 69	Banjo Bolt	2	
5	JG 1318 21	Reservoir Rear Brake	1	Without Cap
6	JL 1312 20	Hose - Reservoir	1	
7	DK 1510 63	Clip Reservoir	1	Cap Reservoir
8	DE 1910 10	Copper Washer	4	Banjo Bolt
9	DE 1510 47	Cap Bleeder Screw	1	
10	DE 1510 46	Bleeder Screw	1	
11	YJ L040 05	Kit Major Caliper	1	
12	YJ L040 06	Kit Minor Caliper	1	
13	DK 1510 85	Set Disc Pad	1	
14	30 1910 38	Pin	1	
15	KD AA06 11	Washer	1	
16	KH AA20 15	Pin Cotter	1	
17	36 DT00 39	Kit Major M Cylinder	1	
18	36 DT00 40	Kit Minor M Cylinder	1	
	DK 1510 74	Master Cyl. Minor Kit	1	N.I.
19	DK 1510 45	Cap Reservoir	1	
19A	DK 1510 72	Diaphragm Reservoir	1	Not illustrated
20	36 JG00 83	Reservoir with Cap	1	
21	39 1944 04	Bolt Flanged	1	
22	JG 1812 39	Collar	1	
23	36 DT00 52	Bracket Caliper	1	
24	LA D000 77	Bolt Flange - M6 x 1	2	
25	JL 1318 78	Bracket Reservoir cap	1	




Rear Brake Pedal

No.	Part No.	Description	Qty.	Remarks
1	DT 1610 01	Brake Pedal	1	
2	KA DD08 30	Bolt Flanged	1	
3	DT 1610 00	Shaft Assy Brake Lever	1	
4	JB 2312 08	Step Bolt	1	
5	JL 4014 06	Switch - Rear Brake	1	
6	DT 1610 04	Spring Rear Brake Switch	1	
7	DT 1130 34	Tension-Spring	1	
8	KJ AA14 24	O Ring	2	




Anti Lock Braking System (Twin Channel)

No.	Part No.	Description	Qty.	Remarks
1	DT 1318 91	Unit ABS	1	ABS 9.1 Unit For OBD2
	DT 1318 92	Unit ABS	1	
	DT 1319 03	Unit ABS Wet	1	
2	36 DT00 44	Hose Cylinder Master Fr to Unit ABS	1	For Dt14
	36 DT00 90	Hose Cylinder Master Fr to Unit ABS	1	
3	36 DT00 43	Hose Caliper Front to Unit ABS	1	For Dt14
	36 DT00 92	Hose Caliper Front to Unit ABS	1	
4	DT 1138 62	Bracket Unit ABS	1	
5	LA E000 21	Bolt Flanged	3	
6	KA ED06 12	Bolt Flanged	1	
7	KA ED06 08	Bolt Flanged	1	
8	DT 1318 49	Clamp Brake Hose	1	
9	DT 1318 72	Bracket Clamp Hose	1	
10	DE 1910 10	Copper Washer	16	
11	DK 1510 69	Benjo Bolt	8	
12	KA EA06 22	Flanged Bolt	4	
13	KA DA06 12	Flanged Bolt	2	
14	DT 1318 37	Bracket Hose Clamp ABS	1	
15	DT 1318 78	Clamp W ABS Hose - Speed Sensor	5	
16	36 DT00 86	Hose Cylinder Master Rr to Unit ABS	1	For Dt14
	36 DT00 88	Hose Cylinder Master Rr to Unit ABS	1	
17	36 DT00 87	Hose Caliper Rear to Unit ABS	1	For Dt14 From Jan 2024
	36 Dt00 89	Hose Caliper Rear to Unit ABS	1	
	36 JL02 45	Hose Caliper Rear to Unit ABS	1	
18	DT 1318 75	Clamp	6	
19	KA AD06 18	Bolt	2	
20	LA E000 06	Bolt Flanged Small	1	
21	JB 1130 07	Plain Washer	3	
22	JL 1319 92	Bracket Hose Rear	1	




Handle Bar Assembly

No.	Part No.	Description	Qty.	Remarks
1	DT 1510 10	Handle Bar Tube LH Assembly	1	
2	56 DT31 33	Holder Handle LH Matt Black	1	
3	JL 1510 38	O Ring	4	
4	39 1180 11	Washer - Plain	2	
5	LA C000 20	Bolt Socket M8X1.25Px55L	2	
6	DT 1510 39	Plug Handle Holder	2	
7	56 DT32 33	Holder Handle RH Matt Black	1	
8	DT 1510 12	Handlebar Tube Assy RH	1	
9	JL 1510 35	Handlebar Weight	2	
10	KA CC06 50	Bolt Socket - M6	2	
11	DT 1610 07	Assembly Lever - Holder LH	1	
11A	DT 1610 10	Holder Assly LH Support Lever	1	
12	JG 1610 08	Lever Clutch	1	
13	DT 4014 08	Clutch Switch	1	
13A	LB U000 12	Screw	2	
14	JL 1610 03	Handle Grip LH	1	
15	DT 1610 05	Grip Hand Assy RH	1	
16	JG 1510 22	Pipe - Throttle	1	
17	DT 2326 06	Lock Set 3 In 1 - EVAP	1	
18	DK 2011 62	Switch Control LH	1	
19	DK 2011 63	Switch Control RH	1	
20	56 DT33 33	Bracket Upper Matt Black	1	
21	KA CF08 30	Blot Socket - M8	4	
22	LA D000 77	Bolt Flange - M6	2	
23	DS 1910 52	Lever Boot LH	1	
24	JG 1610 10	Lever RH	1	
25	JZ 1610 28	Lever Pivot Bolt	1	



Front Fork

No.	Part No.	Description	Qty.	Remarks
1	DT 1210 49	Fork Assembly- Front	1	
2	DT 1210 52	Tube Outer LH	1	
3	DT 1210 53	Tube Outer RH	1	
4	DK 1810 06	Socket Headed Bolt -M10	2	
5	DK 1810 07	Copper Washer	2	
6	DK 1810 21	Inner Dust Seal	2	
7	DK 1810 18	Washer Seal	2	
8	DK 1810 19	Oil Seal	2	
9	DK 1810 17	Guide Bush	2	
10	DK 1810 20	Oil Seal Stopper	2	
11	DK 1810 15	Washer	2	
12	DT 1210 36	Spacer Tube	2	
13	DT 1510 40	Fork Pipe Inner	2	
14A	DK 1810 09	Cap Oil Lock	2	
14B	DK 1810 10	Seat Pipe	2	
14C	DK 1810 12	Piston Ring	2	
14D	DK 1810 13	Rebound Spring	2	
15	DT 1210 37	Spring Main Spring	2	
16	DT 1510 42	Fork Bolt	2	
17	DK 1810 23	O' Ring	2	
18	DT 1210 35	Under Bkt Assy Complete	1	
19	JC 1810 20	Spring Washer	2	
20	DK 1810 28	Bolt	2	



Front Fork


No.	Part No.	Description	Qty.	Remarks
21	DT 1210 31	Steering Top Bolt	1	
22	DT 1210 32	Cap Steering Top Bolt	1	
23	DT 1510 43	Cap Fork Top Bolt	2	
24	DK 1810 75	Nut Steering	1	
25	DK 1810 76	Cup Steering	1	
26	DT 1510 46	Damper Steering Top Bolt Cap	1	
27	LA C000 68	Bolt Socket	3	
28	DT 1318 72	Bkt ABS Brake Hose Clamp	1	
29	JH 4010 31	Reflector Reflex Side	2	



Petrol Tank, Cap Tank and Gauge Fuel


No.	Part No.	Description	Qty.	Remarks
1	DT 1710 92	Assembly Fuel Tank	1	
	DT 1711 07	Assembly Fuel Tank	1	For Aisan pump
2	DT 2326 06	Lock Set 3 In 1 + Tank Cap	1	
3	KA CD05 16	Screw Allen	6	
4	LA D001 54	Bolt	6	
5	DT 1718 39	Plate Pressure Fuel Pump Mtg	1	
	JR 1718 20	Plate Pressure	1	For Aisan pump
6	JL 1718 52	Fuel Pump Assembly	1	
	AA 2013 75	Fuel Pump	1	For Aisan pump
6A	YA U020 01	Strainer Fuel Pump	1	For Aisan pump
7	JY 4022 35	Pigtail Fuel Pump	1	
8	DT 6112 08	Tube Filter to Injector	1	
9	DT 1710 89	Assy. Tube Filter To Regulator	1	
10	DT 1710 87	Tube Fuel Pump To Fuel Filter	1	
11	DT 1718 14	Inline Fuel Filter	1	
12	JL 1710 19	Sleeve Tank Mounting Rear	2	
13	DT 1710 61	Drain Pipe	1	
14	DG 1410 28	Clamp	1	
15	DT 1710 55	Foam Fuel Tank	2	
17	LA D001 51	Bolt Flange - M8	3	
18	DT 1710 75	Sleeve Tank Mtg Front	3	
19	DT 1710 78	Grommet Tank Mounting	1	
20	JL 1710 20	Grommet Tank Mounting Rear	2	
21	36 DT00 06	Kit Tank Damper	1	
22	JH 1718 03	Gasket Fuel Pump	1	For Aisan pump
23	DT 4026 00	Fuel Level Sensor	1	For Aisan pump

Fittings - Petrol Tank Cover



No.	Part No.	Description	Qty.	Remarks
1	LA C000 22	Bolt	2	
2	LB U000 27	Screw	2	
3	DT 1710 53	Grommet	4	
4	DT 1710 80	Collar	2	
5	JW 1710 16	Screw	2	
6	KB UA05 16	Screw Truss	6	
7	DT 1812 74	Collar Side Cover	2	
8	KD BF06 13	Washer Plain	9	
9	KB UF06 12	Screw Truss	6	
10	JW 1710 16	Screw	2	
11	DT 1812 15	Side Fairing Enclosure LH	1	
12	DT 1812 28	Side Fairing Enclosure RH	1	
13	LD A000 07	Washer Plain Small	14	
14	LB R000 02	Self Tapping Screw-	14	
15	DT 1812 91	Bracket Side Fairing Front LH	1	
16	DT 1812 92	Bracket Side Fairing Front RH	1	
17	DT 1812 93	Bracket Side Fairing Rear	2	
18	JG 1710 31	Clip Nut M5	2	
19	GL 1810 43	Clip Snap	2	
20	KB UF05 16	Screw Truss - M5 x 0.8 x L16	8	
21	39 2141 24	Washer Non Metallic	4	
22	DT 1812 73	Step Bolt Tank Cover Top	2	
23	DT 1812 44	Fairing Structure Middle LH	1	

Fittings - Petrol Tank Cover




No.	Part No.	Description	Qty.	Remarks
24	DT 1812 46	Fairing Structure Middle RH	1	
25	KA DD06 10	Bolt Flanged	4	
26	JG 1138 06	Grommet Coolant Ex Tank	1	
27	DT 1138 15	Bracket Fairing Mtg Lower LH	1	
28	DT 1138 30	Bracket Fairing Mtg Lower RH	1	
29	DT 1812 65	Grommet Side Cover	2	
30	KA EA06 12	Bolt Flanged	2	
31	DT 1710 30	Foam Tank Cover	1	
32	DT 1710 82	Beading Tank Cover	1	
33	36 DT00 03	Kit Hardware P Tank Cover	1	
34	DT 1810 34	Foam Tank Cover	2	
35	DT 1710 73	Grommet Tank Cover Assly	2	N.I.
36	DT 1810 30	Tape Anti - Abrasive 3M	8	
37	JG 1710 31	Clip Nut M5	4	
38	DT 1813 26	Foam Side Fairing Inner	2	



Fittings - Side Covers & Cover Seat


No.	Part No.	Description	Qty.	Remarks
1	LD B000 23	Washer Plain	6	N.I.
2	JW 1710 16	Mushroom Head Screw M6x18	2	
3	KB UF06 14	Screw Truss M6 x 14	6	
4	DT 1812 10	Seat Cowl Central Top	1	
5	JG 1710 31	Clip Nut M5	12	
6	LB U000 23	Screw M5	2	
7	KB RA42 13	Screw Tapping Pan Cross	8	
8	LD A000 07	Washer Plain Small	8	
9	KD BA06 13	Washer Plain	6	
10	DT 1812 07	Flange Seat Cover LH	1	
11	DT 1812 65	Grommet Side Cover	2	
12	JZ 1813 22	Grommet Side Cover	2	
13	36 DT00 02	Kit Hardware S Cowl & S Cvr	1	
14	DT 1810 13	Damper Side Cover	2	

Meter Assembly




No.	Part No.	Description	Qty.	Remarks
1	DT 4024 23	Speedometer	1	For OBD2
	DT 4024 26	Instrument Cluster	1	
2	JG 1812 38	Grommet Dashboard	3	N.I.
3	LD B000 07	Washer Plain	3	
4	KC AA05 04	Nut Hex Thick	3	
5	DT 1812 33	Speedo Flap	1	
6	DT 1812 55	Damper Speedo Flap	2	
7	KA Cd05 16	Bolt-Socket-Dia-05 L-14	2	
8	DT 1810 10	Trust Screw	4	
9	39 2141 24	Washer non Metallic	4	
10	YD T020 04	Spdomtr Top Cover & 'O' ring	1	
11	DT 1810 11	Tape Front Fairing	4	
12	DT 4024 15	Foam Speedomter	1	
13	GL 1810 43	Clip Snap	3	

Control Cables




No.	Part No.	Description	Qty.	Remarks
1	DT 1612 04	Cable Throttle	1	
2	DT 1612 03	Cable Clutch	1	
3	JG 5814 19	Bracket Throttle Cable	1	

Chain Case




No.	Part No.	Description	Qty.	Remarks
1	JL 1812 05	Cover Assembly Chain	1	
2	JG 1220 28	Extruded Washer	2	
3	DK 9026 26	Bolt	2	
4	DT 1814 14	Assembly Hugger Rear	1	
5	DT 1810 00	Tube Rear Hugger Mtg	1	
6	DT 1814 15	Cover 1- Hugger Rear	1	
7	JL 1814 08	Cover 2- Hugger Rear	1	
8	KB UF04 08	Screw Truss	6	
9	LA C000 37	Bolt Soc-special Head	3	
10	KD DF08 15	Spring Washer	2	
11	LA C001 28	Bolt Socket - M8 x 1.25 x L42	2	
12	JL 1814 10	Collar Hugger Rear	2	
13	JL 1812 53	Chain Cover RH Side	1	
14	LA C000 54	Bolt Socket M6 x 1 x L16	2	
15	KD AD06 11	Washer Plain Small	2	
16	JL 1812 97	Collar	2	
17	DS 2210 01	Plug	2	
18	DT 1814 16	Assembly Rear Hugger Comp	1	

Head Lamp & Fairing



No.	Part No.	Description	Qty.	Remarks
1	DT 4010 09	Front Position Lamp LH	1	
1A	DT 4010 10	Front Position Lamp RH	1	
2	DT 1812 42	Fairing Structure	1	
3	LA D001 20	Bolt Flange M8 X 45L	2	
4	39 2535 15	Hex Nut Flange M8	2	
5	DT 1813 10	Trust Washer	4	
6	DT 1813 11	Spacer Structure Mtg Front	4	
7	DT 4010 08	Low Beam Projector	1	
7A	DT 4010 12	Bulb H11 (12 55W)	1	
7B	YD T020 02	Low Beam Projector W/O bulb	1	
8	DT 4010 11	High Beam	1	
8A	DT 4010 24	Bulb H9 (12V 65W)	1	
8B	YD T020 03	High Beam Projector W/O bulb	1	
9	DT 4010 17	Pivot Screw M6	2	
10	KC EA06 05	Nut Domed Cap Single Piece	2	
11	DT 4010 18	Adjusting Bolt	2	
12	DT 4010 19	Adjusting Bolt M10	2	
13	LD A000 07	Washer Plain Small	5	
14	KB UF05 16	Screw Truss - M5	4	
15	LB R000 02	Self Tapping Screw	8	
16	JG 1710 31	Clip Nut M5	4	
17	KC EE05 04	Nut Dome Cap Single Piece	2	
18	DT 1812 32	Visor	1	
19	JG 1812 36	Well Nut M5	6	

Head Lamp & Fairing




No.	Part No.	Description	Qty.	Remarks
20	39 2141 24	Washer Non Metallic	10	
21	JZ 1812 06	M5 X 21 L Ss Bolt	6	
22	56 DT36 6B	Front Bezel - Moon Light Silver	1	
23	DT 1812 67	Outer Mask LH	1	
24	DT 1812 68	Outer Mask RH	1	
25	DT 1812 75	Fairing Structure Middle	1	
26	DT 1812 85	Cover Fairing Mtg Lower	1	
27	DT 1812 94	Fairing Structure Lower LH	1	
28	DT 1813 25	Lower Fairing Structure RH	1	
29	KA DF06 16	Bolt	2	
30	DT 1810 11	Tape Front Fairing	2	
31	DT 1810 30	Tape Anti - Abrasive 3M	6	
32	KD BA06 13	Washer Plain	3	
33	JW 1710 16	Round Head Screw	2	
34	KE CA60 08	Circlip Type - E	4	
35	KB UF06 14	Screw Truss M6 x 1 x L14	3	
36	JN 1810 31	Foam Fairing	4	
37	YD T020 05	Grommet Project	6	




Indicator Light Assembly

No.	Part No.	Description	Qty.	Remarks
1	DT 4010 02	Indicator Assy Front LH	1	
2	DT 4010 03	Indicator Assy Front RH	1	
3	LC L000 01	Nut Hex Flange - M10	2	
4	DT 1138 19	Spacer Blinker Mtg	2	
5	DT 4010 04	Indicator Assy Rear LH	1	
6	DT 4010 05	Indicator Assy Rear RH	1	
7	PA 4022 04	Band (Length 110 MM)	2	
8	KC GA10 10	Nut Hex Flanged	2	




Tail Lamp Assembly / Front Number Plate

No.	Part No.	Description	Qty.	Remarks
1	JU 2328 00	Front Number Plate	1	
2	LB U000 09	Screw Mushroom Head	2	
3	39 2141 24	Washer None Metallic	2	
4	DT 2328 15	Bracket Plate Number Front	1	
5	DT 4010 01	Lamp Tail Assembly	1	
6	DT 1138 07	Bracket Rear Blinker Mtg	1	
7	DT 1138 18	Screw M-5	4	
8	DP 1611 45	Rear Number Plate	1	
9	JG 4010 36	Reflector - Reflex	1	
10	DT 1138 13	Bracket-Reflector Reflex Mtg	1	
11	DT 2328 16	Bracket Plate Number Rear	1	
12	22 1611 93	Strip Foam	1	
13	KC GA06 06	Nut Hex Flanged	2	
14	KC GA05 05	Nut Hex Flanged	1	
15	39 2476 04	Bolt Hex Head with Flange	2	
16	DT 1138 24	Sleeve	4	
17	DT 1138 17	Grommet	4	
18	DT 2328 04	Damper	2	



Electrical Equipments

No.	Part No.	Description	Qty.	Remarks
1	DT 4022 46	Harness Wiring - ABS Twin Channel	1	For Varroc ECU Model
	DT 4022 56	Harness Wiring - ABS Single Channel	1	
	DT 4022 66	Harness Wiring (W/O capacitor & diode)	1	
	DT 4022 67	Harness Wiring (For capacitor & diode)	1	
	DT 4022 71	Harness Wiring (For OBD2 version)	1	
	DT 4022 72	Harness Wiring (For OBD2 version)	1	
2	JL 4030 00	Relay Interlock	6	For Varroc ECU Model
	JF 4030 00	Relay Interlock	6	
3	36 DT00 04	Kit Band Wiring Harness	1	
4	DT 4020 08	LED Flasher	1	
5	DT 4022 18	Cable Assy Relay To Motor	1	
6	DT 4022 23	Cable Earth	1	
7	JL 4032 00	Termination Unit	1	For Varroc ECU model
	JL 4032 01	Termination Unit	1	
8	PA 4016 00	Horn	1	
9	39 0230 11	Washer - Plain	1	
10	KA DA08 14	Hex Head Bolt - Flanged M8	1	
11	JP 4030 00	Starter Relay	1	Without Damper
12	JG 4030 03	Damper Relay Starter	1	
13	DT 4022 27	Fuse - 5A	4	For Varroc ECU Model
	DT 4022 26	Fuse - 7.5A	5	
	JG 4022 28	Fuse - 10A	2	
	JG 4022 29	Fuse 15A	6	
	JG 4022 30	Fuse 30A	2	
14	JP 3514 39	ECU	1	For Varroc ECU Model
15	PD 3514 25	ECU	1	
16	KA DA06 30	Bolt Flanged	1	
17	JY 4036 04	Sensor Roll Over	1	
18	JF 1138 42	Bracket Roll Over Sensor Mtg	1	
19	LA C000 08	Screw Button Head - M6	2	
20	KC HC06 08	Nut Nyloc	2	
21	36 JU00 15	12V 8Ah Battery	1	
22	JF 1812 73	Assembly Battery Case	1	
23	KA EA06 22	Bolt	4	




Front Wheel Direction


Electrical Equipments

No.	Part No.	Description	Qty.	Remarks
24	JL 1138 25	Band Battery Case Vertical	1	
25	DT 1810 22	Band Battery Case	1	
26	DT 1138 49	Strap ECU harness	1	
27	JY 1138 64	Bracket Ecu Mtg Top C Sample	1	Without Pad
28	JY 1710 07	Pad Rubber New ECU	2	
29	JY 1138 74	Damper ECU C Sample Mtg Top	1	
30	JY 1138 77	Damper ECU Locator	1	
31	KC GA06 06	Nut Hex Flanged	2	
32	PA 4022 04	Band (Length 110 mm)	5	
33	JF 1812 82	Bracket ECU Lower	1	Without Pad
34	JY 1138 72	Pad Resting Ecu C Sample LH	1	
35	JY 1138 73	Pad Resting Ecu C Sample RH	1	
36	DT 1138 51	Bracket Fuse Box Mtg Loose	1	
37	KC GA06 06	Nut Hex Flanged	4	
38	JF 1813 08	Rubber Battery Case	1	
39	DT 1138 02	Bracket Regulator Mtg Loose	1	
40	DT 4020 09	Regulator with inbuilt capacitor	1	
41	KA EA06 25	Bolt Flanged Small	2	
42	DT 1138 60	Bracket Relay Interlock	1	
43	DT 1138 65	Bracket Relay Starter	1	
44	KA DA06 08	Bolt Flanged	1	
45	DT 1813 16	Sleeve Battery Case	4	
46	DT 1813 17	Grommet Battery Case	4	
47	52 JF03 28	Bkt Ecu Mtg Lower Sub Assly	1	
48	DT 1138 69	Bracket ECU	1	For Varroc ECU Model
49	DT 1138 72	Damper	1	For Varroc ECU Model
50	DT 1138 71	Damper	1	For Varroc ECU Model
51	DT 1138 70	Pad	1	For Varroc ECU Model
52	BF 4014 43	Diode Unit	1	For Varroc ECU Model
53	DT 4020 03	Capacitor Assembly	1	For Varroc ECU Model
54	DK201188	Transil Unit	1	

Tool Kit




No.	Part No.	Description	Qty.	Remarks
1	DT 2310 02	Kit Tool	1	Not Serviceable
2	DT 2310 00	Box Tool Kit	1	
3	KA EA06 12	Bolt Flanged	1	
4	KD AB06 11	Washer Plain	1	



Accessories / Grab Handle


No.	Part No.	Description	Qty.	Remarks
1	DT 2314 04	Grab Handle Assy LH	1	
2	DT 2314 05	Grab Handle Assy RH	1	
3	KA CA08 30	Bolt Socket M8 X 1.25	4	
4	JL 2312 02	Guard Saree	1	
5	KA CA06 18	Bolt Master KAC	3	
6	DT 2316 11	Mirror Assembly LH	1	
7	DT 2316 12	Mirror Assembly RH	1	
8	LA C000 22	Bolt	4	
9	DT 1812 84	Pad Mirror Mounting	2	
10	DT 1812 99	Pad Mirror Base Mtg.	2	
11	DT 2316 07	Bolt Mirror Mtg LH Thread	1	
12	DT 2316 08	Bolt Mirror Mtg RH Thread	1	
13	DT 2316 06	Plug Mirror Mtg.	2	
14	LD H000 08	Conical Washer	4	
15	39 0200 11	Plain Washer	4	
16	DT 2316 09	Bracket Mirror Mounting LH	1	
17	DT 2316 10	Bracket Mirror Mounting RH	1	
18	JD 1710 18	Duel Lock Tape 3M	1	
19	JL 2312 09	Plug Saree Gaurd	3	

Painted Parts and Decals




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
1	52 DT04 62	Front Fairing Racing Red	1	1	
	52 DT04 64	Front Fairing M Black Gray	1	1	
	52 DT04 63	Front Fairing S Blue	1	1	
2	52 DT04 76	Tank Cover Top Racing Red	1	1	
	52 DT04 78	Tank Cover Top M Black Gray	1	1	
	52 DT04 77	Tank cover with S Blue	1	1	
2A	DT 1710 42	Tank Side Assembly	1	1	
3	52 DT04 59	Side Fairing RH S Blue	1	1	
	52 DT04 57	Side Fairing RH Racing Red	1	1	
	52 DT04 61	Side Fairing RH Black Gray	1	1	
4	52 DT04 56	Side Fairing LH-Racing Red	1	1	
	52 DT04 60	Side Fairing LH Black Gray	1	1	
	52 DT04 58	Side fairing LH S Blue	1	1	
5	52 DT04 67	Seat Cowl LH Racing Red	1	1	Ser Bulletin 2015-35
	52 DT04 71	Seat Cowl LH Black Gray	1	1	
	52 DT04 69	Seat cowl LH S Blue	1	1	
6	52 DT04 68	Seat cowl RH Racing Red	1	1	Ser Bulletin 2015-35
	52 DT04 72	Seat cowl RH Black Gray	1	1	
	52 DT04 70	Seat cowl RH S Blue	1	1	
7	52 DT04 79	Fender front - Racing red	1	1	
	52 DT04 80	Front fender S Blue	1	1	
	52 DT04 81	Front fender Black Gray	1	1	
	52 JL09 23	Front Fender Mat pewt grey+Red Dcal	1	1	
	52 JL09 32	Front Fender Mat pewt grey+Blk Dcal	1	1	
	52 JL09 41	Front Fender Mat pgrey+White Dcal	1	1	
	52 JL09 85	Front Fender + Yel Dcal	1	1	

Painted Parts and Decals




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
8	52 DT04 66	Side Fairing Flap RH	1	1	
9	52 DT04 65	Side Fairing Flap LH	1	1	
10	56 DT12 4X	Side Cover LH	1	1	
11	56 DT13 4X	Side Cover RH	1	1	
12	DT 1812 86	Lower Fairing LH	1	1	
13	DT 1813 24	Lower Fairing RH	1	1	
14	DT 1812 10	Seat Cowl Central Top	1	1	
15	36 DT00 68	Kit Dcl Fairing-B Gray	1	1	
	36 DT00 57	Kit Dcl Fairing-Pa Red	1	1	
	36 DT00 62	Kit Dcl Fairing-S Blue	1	1	
16	36 DT00 58	Kit Side Fairing LH-Red	1	1	
	36 DT00 63	Kit Side Fairing LH-S Blue	1	1	
	36 DT00 67	Kit Side Fairing LH-B Gray	1	1	
17	36 DT00 59	Kit Side Fairing RH-Red	1	1	
	36 DT00 64	Kit Side Fairing RH-S Blue	1	1	
	36 DT00 69	Kit Side Fairing RH-B Gray	1	1	
18	36 DT00 61	Kit Dcl S Cowl-Red	1	1	
	36 DT00 66	Kit Dcl S Cowl-S Blue	1	1	
	36 DT00 71	Kit Dcl S Cowl-B Gray	1	1	
19A	DT 2331 86	3D Dcl Pulsar	2	2	
19B	36 DT00 60	Kit Dcl Tank Top Red	1	1	
	36 DT00 65	Kit Dcl Tank Top S Blue	1	1	
	36 DT00 70	Kit Dcl Tank Top B Gray	1	1	

Painted Parts and Decals




No.	Part No.	Description	Qty.		Remarks
			ABS	NON ABS	
20	36 DT00 72	Kit Dcl Fender ABS- P Red	1	--	
	36 DT00 73	Kit Dcl Fender ABS- S Blue	1	--	
	36 DT00 74	Kit Dcl Fender ABS- M Gray	1	--	
21	DT 1812 14	Side Faring Mesh LH	1	1	
22	DT 1812 21	Side Faring Mesh RH	1	1	
24	DT 2331 72	Decal Wheel Rim	4	4	



Painted Parts and Decals - New C&G Oct 20


No.	Part No.	Description	Qty.	Remarks
1	56 DT65 B1	Front Fairing C Black+Sparkling Black	1	
	56 DT65 B7	Front Fairing P White+Sparkling Black	1	
	56 DT65 4Y	Front Fairing Burnt Red+Sparkling Black	1	
2	52 DT11 06	Fender Front Satin Black+Decal	1	
	52 DT11 13	Side Fairing LH Burnt Red+Decal	1	
	52 DT11 25	Side Fairing LH Pewter Grey+Decal	1	
	52 DT11 27	Side Fairing LH P Met White+Decal	1	
4	52 DT11 17	Side Fairing RH Burnt Red+s Black+Decal	1	
	52 DT11 26	Side Fairing RH Pewter Grey+Decal	1	
	52 DT11 28	Side Fairing RH P Met White+Decal	1	
5	56 DT22 4Z	Tank Cover TOP Burnt Red	1	
	56 DT22 32	Tank Cover Top Pewter Grey	1	
	56 DT22 42	Tank Cover Top Pearl Met White	1	
6	56 DT36 X3	Front Bezel Lower Ebony Black	1	
7	56 DT07 4X	DT Fairng Flap Satin Black LH	1	
8	56 DT08 4X	DT Fairng Flap RH Satin Black	1	
9	56 DT12 4X	Side Cover - LH	1	
10	56 DT13 4X	Side Cover - RH	1	
11	52 DT11 32	Seat Cowl RH Satin Black+Red Decal	1	
	52 DT11 33	Seat Cowl RH S Black+Grey Decal	1	
	52 DT11 34	Seat Cowl RH S Black+white Decal	1	
12	52 DT1129	Seat Cowl LH SA BLACK+Red Decal	1	
	52 DT1130	Seat Cowl LH S Black+Grey Decal	1	
	52 DT1131	Seat Cowl LH S Black+white Decal	1	
	56 DTD7 4X	Seat Cowl Central Top Satin Blk	1	

Painted Parts and Decals - New C&G Oct 20



No.	Part No.	Description	Qty.	Remarks
14	36DT0098	Kit Decal Fairing Blue	1	
	36DT0110	Kit Decal Fairing	1	
	36DT0111	Kit Decal Fairing Gray	1	
15	36DT0100	Kit Decal Cowl Seat Red	1	
	36DT0101	Kit Decal Cowl Seat Black	1	
	36DT0102	Kit Decal Cowl Seat Blue	1	
16	36DT0103	Kit Decal Front Wheel Yellow	1	
	36DT0104	Kit Decal Front Wheel Red	1	
	36DT0105	Kit Decal Front Wheel Blue	1	
	DT 2332 43	Decal Wheel Front Pewter Grey LH	2	From Aug. 2021
	DT 2332 44	Decal Wheel Front Pewter Grey RH	2	From Aug. 2021
17	DT233227	Decal Pulsar	1	
18	DT233225	Decal Fender ABS LH	1	
18	DT233226	Decal Fender ABS RH	1	
19	JF233310	Decal Cover Magneto	1	
19	JL233347	Decal Cover Clutch	1	
20	DT181286	Lower Fairing LH	1	
21	DT181324	Lower Fairing RH	1	
22	DT181214	Side Faring Mesh LH	1	
23	DT181221	Side Faring Mesh RH	1	
24	DT171042	Tank Side Assembly	1	

Painted Casting Parts - New C&G Scheme from October 2020



No.	Part No.	Description	Qty.	Remarks
1	JL 1319 51	Caliper Assembly Front	1	
2	DT 1610 13	Pedal Brake	1	
3	DT 5614 16	Arm Assembly Change	1	
4	DT 5614 14	Lever Assembly Change	1	
5	52 DT11 69	Rod Tie Gear Change	1	
6	56 DT3T 4X	Step Rider RH Satin Black	1	
7	56 DT3Y 4X	Holder Step RH Satin Black	1	
8	56 DT3X 4X	Holder Step LH Satin Black	1	
9	56 JL3S 4X	Step Rider LH Satin Black	1	
10	56 DT4J 4X	Step Holder Pillon LH Satin Black	1	
11	56 JL18 4X	Step Pillion LH Satin Black	1	
12	56 DT4K 4X	Step Holder Pillon RH Satin Black	1	
13	56 JL19 4X	Step Pillion RH Satin Black	1	
14	56 JL2Z 7S	Front Wheel Satin Urban White	1	
15	56 JL8U 7S	Rear Wheel Satin Urban White	1	
16	56 DT09 C8	Frame S Urban White+Schwartz Black	1	
17	56 DT31 33	Holder Handle LH Matt Black	1	
18	56 DT32 33	Holder Handle RH Matt Black	1	
19	56 DT33 33	Bracket Upper Matt Black	1	
20	56 DTD8 6B	Cap Steri Top Bolt Moon LIG.SIL	1	
21	56 DTD9 6B	Cap Fork Top Bolt Moon LIG.SIL	1	
22	56 DTE1 4X	Chamber LH Satin Black	1	
23	56 DTE2 4X	Chamber RH Satin Black	1	
24	DT 59 11 33	Chamber End Cap	1	

1		2		3	
4		5		6	
7		8		9	
10		11		12	




Front Wheel Direction

Plate No.: 54

Consumable Parts

No.	Part No.	Description	Supply Unit	Application
1	83 0205 50 83 0205 53	Bajaj Genuine Oil 20W50 BS VI BGO 20W50 BS VI	1 Ltr. 100 ML	Top up
2	36 0010 58	Bajaj Coolant Koolex*	1 Ltr.	Coolant Top-up/Replace
3	36 DH40 61	Brake Fluid DOT4	100 ml	Disc Brake Top-up/Replace
4	36 DH40 52	Silicon grease	3 gm	Caliper Pin
5	83 0204 73 36 DK00 45	Grease Petamo GHY 441 Grease Molycoat	3 gm 200 gm	Water Pump Seals For Starter Clutch Lubrication
6	36 JL01 81	Limaplex HTX 3 Grease	10 gm	Steering Race
7	83 0201 73	Multi Purpose Grease* (Local Purchase)	--	Lubrication of Clutch Lever, Brake Lever, Brake Pedal & Side Stand
8	36 0010 55	Chain Lubricant HP Make	1 kg	Non - Sealed Chain Lubrication
9	36 0010 62	Liquid gasket L5910	50 ml	Crankcase Joining
10	36 3140 04 36 JG00 87	Fork oil Fork oil 480 ml (Dominar UG)	160 ml 480 ml	Front Fork Top-up/Replace\ Front Fork Top-up/Replace\
11	36 DH40 29	Kit Spray Chain Lub	100 ml	Sealed Drive Chain
12	36 DH40 71	Wonderfill Chain Spray	100 ml	Sealed Drive Chain

* Marked items to be arrange from vendor or local market. Not applicable against chassis number.

13		14		15	
16		17		18	
19		20		21	
22		23		24	



Consumable Parts

No.	Part No.	Description	Supply Unit	Application
13	36 DH40 72	Rust Remover Spray Make - Zorric 88 & Wonder fill easiner	100 ml	For Removing Rust from Components
14	76 0109 36	Loctite Thread locker 243*	50 ml	For Screws & Bolts
15	76 0109 37	Loctite retaining compound 638*	50 ml	For Screws & Bolts
16	37 0043 52	Touch up paint slate grey*	440 ml	Touch up of Frame, Swing Arm & Step Holder
17	37 0043 53	Touch up paint Matte Silk black*	440 ml	Touch up of Grab Handle, Handle Bar & Handle Holder
18	36 0010 60	Kibatsu touch up paint*	400 cc	Touch up of Cylinder head, Block & Alloy Wheels
19	37 2240 18	Paint Bottle Schwartz Black*	--	P-200NS Frame Touch-up
20	75 6802 36 NA	Petroleum Jelly (Local Purchase) Distilled Water (Local Purchase)	-- 1 Ltr.	For Battery Terminals For Battery Level Top-up
21	NA	SAE 90 oil (Local Purchase)	-	
22	62 3050 84	WD40 Spray (Local Purchase)	400 ml	Electrical Contact Cleaning Spray
23	36 0010 56	Carburetor Cleaning Spray*		For Cleaning Carburetor/ Throttle Body
24	37 2540 39	Corrosion Protection Spray* Proto quick LTP902	--	For Preventing vehicle parts from rusting

* Marked items to be arrange from vendor or local market. Not applicable against chassis number.

Kit List

RS 200 BS VI

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
1	36DT0032	KIT ASSEMBLY CYL HEAD	JL511045 JG511046	HEAD CYLINDER COMP STUD (M8*1.25)	1 2
2	36DT0055	KIT GEAR PRIMARY DRIVE & DRIVEN	JG551216 DT551410	GEAR PRIMARY DRIVE 22T HOUSING CLUTCH ASSY COMP	1 1
3	36JL0001	KIT CHAIN GUIDE	JL531004 JL531005	GUIDE CHAIN (SLACK SIDE) CHAIN GUIDE TIGHT SILENT	1 1
4	36DT0007	KIT CHAIN SPROCKET	DV101048 DT141004 DT141005	SPROCKET OUTPUT (14T) SPROCKET 41T CHAIN 110 LINK	1 1 1
5	36DT0008	KIT ENGINE GASKET	JG541041 JL541207 JL541208 JL521002 JL511022 CS101128 JL511042 JG591070	GASKET CRANKCASE GASKET CLUTCH COVER GASKET MAGNETO COVER GASKET CYLINDER BLOCK GASKET CYLINDER HEAD GASKET GASKET HEAD COVER GASKET EXHAUST	1 1 1 1 1 1 1 1
6	36JL0011	KIT VALVE REPAIR	JF511215 39201719 JF511214 JF511217 DG101029	SEAT VALVE SPRING SEAL VALVE STEM RETAINER VALVE SPRING VALVE SPRING COTTER VALVE	4 4 4 4 8
7	36JL0007	KIT BLOCK PISTON	JL521004 JL521200	CYLINDER BLOCK WITH NIPPLE PISTON ASSEMBLY COMPL	1 1
8	36JU0001	KIT PISTON RING SET	JU521206 JU521207 JU521208	RING PISTON TOP RING PISTON SECOND RING PISTON OIL	1 1 1
9	36DT0079	KIT ASSLY C'CASE RH 200	--- 39256220	CRANKCASE RH BEARING - NEEDLE ROLLER	1 1

Kit List

RS 200 BS VI

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
			JG541061 BA102003	PIPE BREATHER PLUG - OIL HOLE	1 3
10	36JL0003	KIT ASSLY C'CASE LH 200	JL541019 JC101077 JG541021 JG541015 39256220 JG541020	CRANKCASE LH PLUG TAPER OIL NOZZLE NEEDLE BEARING HK 1514 RS BEARING - NEEDLE ROLLER JET OIL CRANKCASE RH	1 2 1 1 1 1
11	36JG0004	SHAFT OIL PUMP ASSEMBLY	JG571022 28121008	ROTOR OIL PUMP WITH SHAFT OUTER ROTOR	1 1
12	36DT0028	DCL FENDER ABS-P RED	DT233089 DT233090	FRONT FENDER DECAL ABS LH FRONT FENDER DECAL ABS RH	1 1
13	36DT0029	DCL FENDER ABS-BR YELLOW	DT233091 DT233092	FRONT FENDER DECAL ABS LH FRONT FENDER DECAL ABS RH	1 1
14	36DT0030	DCL FENDER -P RED	DT233085 DT233086	FRONT FENDER DECAL LH FRONT FENDER DECAL RH	1 1
15	36DT0031	DCL FENDER - BR YELLOW	DT233087 DT233088	FRONT FENDER DECAL LH FRONT FENDER DECAL RH	1 1
16	36DT0011	KIT DCL FAIRING-PA RED	DT233015 DT233016 DT233017 DT233018	DECAL FAIRING UPPER LH DECAL FAIRING UPPER RH DECAL FAIRING LOWER LH DECAL FAIRING LOWER RH	1 1 1 1
17	Deleted	KIT DCL TANK-PA RED	DT233043 DT233082	DECAL TANK LH DECAL TANK TOP COVER	2 1
18	36DT0017	KIT DCL SPOILER LH-PA RED	DT233021 DT233023 DT233025	DECAL TANK SPOILER UPPER LH DECAL TANK SPOILER LOW 1 LH DECAL TANK SPOILER LOW 2 LH	1 1 1

Kit List

RS 200 BS VI

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
19	36DT0020	KIT DCL SPOILER RH -PA RED	DT233022 DT233024 DT233026	DECAL TANK SPOILER UPP RH DECAL TANK SPOILER LOW RH DECAL TANK SPOILER LOW RH	1 1 1
20	36DT0014	KIT DCL S COWL-PA RED	DT233027 DT233028	DECAL SEAT COWL LH DECAL SEAT COWL RH	1 1
21	36DT0010	KIT DCL FAIRING -BR YELLOW	DT233029 DT233030 DT233031 DT233032	DECAL FAIRING UPPER LH DECAL FAIRING UPPER RH DECAL FAIRING LOWER LH DECAL FAIRING LOWER RH	1 1 1 1
22	Deleted	KIT DCL TANK-BR YELLOW	DT233079 DT233093	DECAL TANK LH DECAL TANK TOP COVER	2 1
23	36DT0016	KIT DCL SPOILER LH- BR YELLOW	DT233035 DT233037 DT233039	DECAL TANK SPOILER UPP LH DECAL TANK SPOILER LOW LH DECAL TANK SPOILER LOW LH	1 1 1
24	36DT0019	KIT DCL SPOILER RH -BR YELLOW	DT233036 DT233038 DT233040	DECAL TANK SPOILER UPP RH DECAL TANK SPOILER LOW RH DECAL TANK SPOILER LOW RH	1 1 1
25	36DT0013	KIT DCL S COWL- BR YELLOW	DT233041 DT233042	DECAL SEAT COWL LH DECAL SEAT COWL RH	1 1
26	36DT0016	KIT DCL SPOILER LH- BR YELLOW	DT233035 DT233037 DT233039	DECAL TANK SPOILER UPP LH DECAL TANK SPOILER LOW LH DECAL TANK SPOILER LOW LH	1 1 1
27	36DT0019	KIT DCL SPOILER RH -BR YELLOW	DT233036 DT233038 DT233040	DECAL TANK SPOILER UPP RH DECAL TANK SPOILER LOW RH DECAL TANK SPOILER LOW RH	1 1 1
28	36DT0013	KIT DCL S COWL- BR YELLOW	DT233041 DT233042	DECAL SEAT COWL LH DECAL SEAT COWL RH	1 1

Kit List

RS 200 BS VI

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
29	36DT0006	KIT TANK DAMPERS	DT171022 DT171023 DT171024 DT171025 DT171026	DAMPER TANK COVER RES LH DAMPER TANK COVER FR RH DAMPER TNK COVR CENTL LH DAMPER TNK COVR CENTL RH DAMPER TANK COVER REAR	1 1 1 1 1
30	36DT0001	HARDWARE FAIRING +R COWL	DT181273 JW171016 KDBC0613 KBUB0614 KDBC0613 DT181010 39214124 KACB0516 KBUB0614 KDBC0613	STEP BOLT SCREW PLAIN WASHER MUSHROOM HEAD SCREW PLAIN WASHER BOLT NON METALLIC WASHER SOCKET HEAD SCREW MUSHROOM HEAD SCREW PLAIN WASHER	2 2 2 6 6 4 4 2 3 3
31	36DT0002	HARDWARE S COWL+SIDE	JW171016 KDBC0613 KBUB0614 39023911 LBU00023 39214124 LBU00023 39214124 KBUB0614 KDBC0613 39204401	MUSHROOM HEAD SCREW PLAIN WASHER MUSHROOM HEAD SCREW PLAIN WASHER SCREW NON METALLIC WASHER SCREW NON METALLIC WASHER MUSHROOM HEAD SCREW PLAIN WASHER MUSHROOM HEAD SCREW	2 2 4 4 10 10 2 2 6 6 2
32	36DT0003	HARDWARE P TANK COVER	31161078 LAC00033 LBU00024	NON METALLIC WASHER BOLT SCREW	4 2 6
33	36DT0004	TIE BAND-W HARNESS	JD402212 JD402217 PA402204	BAND 200 MM BAND 150 MM BAND 110 MM	8 2 2

Kit List

RS 200 BS VI

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
34	36DT0057	KIT FARING DCL P RED	DT233134 DT233135	DECAL FARING LH RED-WHITE DECAL FARING RH RED-WHITE	1 1
35	36DT0058	KIT SIDE FARING DCL P RED	DT233136 DT233138 DT233140	DECAL SIDE FAI UP LH RED-WH DECAL FLAP SIDE FARING LH DECAL SIDE FARING LO LH RED-WH	1 1 1
36	36DT0059	KIT SIDE FARING DCL RH P RED	DT233141 DT233137 DT233139	DECAL SIDE FARING LO RH RED-WH DECAL SIDE FARING UP RH RED-WH DECAL FLAP SIDE FARING RH	1 1 1
37	36DT0060	KIT T TOP COVER P RED	DT233142 DT233143	DECAL COVER TANK TOP LH RED-WH DECAL COVER TANK TOP RH RED-WH	1 1
38	36DT0061	KIT S COWL DCL 2D P RED	DT233144 DT233145	DECAL COWL SEAT LH RED-WHITE DECAL COWL SEAT RH RED-WHITE	1 1
39	36DT0062	KIT FARING DCL S BLUE	DT233148 DT233149	DECAL FARING LH BLUE-WHITE DECAL FARING RH BLUE-WHITE	1 1
40	36DT0063	KIT SIDE FARING DCL LH S BLUE	DT233150 DT233152 DT233138	DECAL SIDE FARING UP LH BLUE-WH DECAL SIDE FARING LO LH BLUE-WH DECAL FLAP SIDE FARING LH	1 1 1
41	36DT0064	KIT SIDE FARING DCL RH S BLUE	DT233151 DT233153 DT233139	DECAL SIDE FARING UP RH BLUE-WH DECAL SIDE FARING LO RH BLUE-WH DECAL FLAP SIDE FARING RH	1 1 1
42	36DT0065	KIT T TOP COVER S BLUE	DT233154 DT233155	DECAL COVER TANK TOP LH BLUE-WH DECAL COVER TANK TOP RH BLUE-WH	1 1
43	36DT0066	KIT S COWL DCL 2D S BLUE	DT233156 DT233157	DECAL COWL SEAT LH BLUE-WHITE DECAL COWL SEAT RH BLUE-WHITE	1 1
44	36DT0067	KIT SIDE FARING DCL LH B GRAY	DT233162 DT233164 DT233138	DECAL SIDE FARING UP LH BLK-GRY DECAL SIDE FARING LO LH BLK-GRY DECAL FLAP SIDE FARING LH	1 1 1
45	36DT0068	KIT FARING DCL B GRAY	DT233160 DT233161	DECAL FARING LH BLACK-GRAY DECAL FARING RH BLACK-GRAY	1 1

Kit List

RS 200 BS VI

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
46	36DT0069	KIT SIDE FARING DCL RH B GRAY	DT233165 DT233163 DT233139	DECAL SIDE FARING LO RH BLK-GRY DECAL SIDE FARING UP RH BLK-GRY DECAL FLAP SIDE FARING RH	1 1 1
47	36DT0070	KIT T TOP COVER B GRAY	DT233166 DT233167	DECAL COVER TANK TOP LH BLK-GRAY DECAL COVER TANK TOP RH BLK-GRAY	1 1
48	36DT0071	KIT S COWL DCL 2D B GRAY	DT233168 DT233169	DECAL COWL SEAT LH BLACK-GRAY DECAL COWL SEAT RH BLACK-GRAY	1 1
49	36DT0072	KIT F FENDER DCL P RED-ABS	DT233175 DT233176	DECAL FENDER FR LH ABS RED-WHITE DECAL FENDER FR RH ABS RED-WHITE	1 1
50	36DT0073	KIT F FENDER DCL S BLUE-ABS	DT233179 DT233180	DECAL FENDER FRONT LH ABS BL-WH DECAL FENDER FRONT RH ABS BL-WH	1 1
51	36DT0074	KIT F FENDER DCL M BLACK-ABS	DT233183 DT233184	DECAL FENDER FR LH ABS BLACK-GRAY DECAL FENDER FR RH ABS BLACK-GRAY	1 1
52	36DT0075	KIT FENDER DCL RED-N ABS	DT233146 DT233147	DECAL FENDER FRONT LH RED-WHITE DECAL FENDER FRONT RH RED-WHITE	1 1
53	36DT0076	KIT FENDER DCL S BLUE-N ABS	DT233158 DT233159	DECAL FENDER FRONT LH BLUE-WHITE DECAL FENDER FRONT RH BLUE-WHITE	1 1
54	36DT0077	KIT FENDER DCL BLACK-N ABS	DT233171 DT233170	DECAL FENDER FRONT RH BLACK-GRAY DECAL FENDER FRONT LH BLACK-GRAY	1 1
55	36JL0183	Kit Saree Guard RH + Grab + Fitting	DT231408 JL231215 JL181326 LAC00074 JL231209 JL231217 KACA0618	Grab handle front Saree guard RH Grommet Bolt socket M8 x 1.25 x L42 Plug saree guard Plug Bolt master KAC	1 1 1 3 1 2 1

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
01 1009 05	9	20	36 DT00 06	21	96
22 1611 93	12	116	36 DT00 07	25	82
30 1011 95	3	38	36 DT01 12	1	38
30 1510 82	17	82	36 DT00 34	14	78
30 1910 38	14	84	36 DT00 35	14A	78
31 1011 73	12	12	36 DT00 36	9	78
36 0010 55	8	138	36 DT00 39	17	84
36 0010 56	23	140	36 DT00 40	18	84
36 0010 58	2	138	36 DT00 43	3	88
36 0010 60	18	140	36 DT00 44	2	88
36 0010 62	9	138	36 DT00 52	23	84
36 3140 04	10	138	36 DT00 55	10	12
36 DH19 02	4	78	36 DT00 55	3	40
36 DH40 29	11	138	36 DT00 57	15	128
36 DH40 52	4	138	36 DT00 58	16	128
36 DH40 61	3	138	36 DT00 59	17	128
36 DH40 71	12	138	36 DT00 60	19B	128
36 DH40 72	13	140	36 DT00 61	18	128
36 DK00 45	5	138	36 DT00 62	15	128
36 DT00 01	27	34	36 DT00 63	16	128
36 DT00 02	13	102	36 DT00 64	17	128
36 DT00 03	33	100	36 DT00 65	19B	128
36 DT00 04	3	118	36 DT00 66	18	128
			36 DT00 67	16	128

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
36 DT00 68	15	128	36 JL00 41	19	66
36 DT00 69	17	128	36 JL01 81	6	138
36 DT00 70	19B	128	36 JL02 27	1	36
36 DT00 71	18	128	36 JU00 01	8	10
36 DT00 72	20	130	36 JU00 15	21	118
36 DT00 73	20	130	36 JU00 36	1	12
36 DT00 74	20	130	36DT0098	14	134
36 DT00 79	2	22	36DT0100	15	134
36 DT00 85	1	26	36DT0101	15	134
36 DT00 86	16	88	36DT0102	15	134
36 DT00 87	17	88	36DT0103	16	134
36 DT00 88	16	88	36DT0104	16	134
36 Dt00 89	17	88	36DT0105	16	134
36 DT00 90	2	88	36DT0110	14	134
36 DT00 92	3	88	36DT0111	14	134
36 JG00 04	2	30	37 0043 52	16	140
36 JG00 11	2	62	37 0043 53	17	140
36 JG00 83	20	84	37 2240 18	19	140
36 JG00 87	10	138	37 2540 39	24	140
36 JL00 01	15	8	39 0200 11	15	124
36 JL00 07	7	10	39 0230 11	9	118
36 JL00 11	10	6	39 0454 11	11	64
36 JL00 15	10	66	39 0553 02	12	64
36 JL00 39	11	28	39 0999 06	5	30

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
39 0999 06	11	36	39 2158 11	2	14
39 0999 06	4	38	39 2159 11	18	14
39 1041 19	10	36	39 2166 11	13	14
39 1043 19	8	26	39 2181 06	5	10
39 1046 19	15	36	39 2200 11	8	12
39 1053 15	19	64	39 2203 07	15	12
39 1180 11	4	90	39 2425 11	17	50
39 1283 21	15	4	39 2440 11	12	6
39 1665 11	15	28	39 2476 04	15	116
39 1665 11	18	28	39 2535 15	4	110
39 1850 04	16	50	39 2562 20	20	22
39 1907 01	12	70	39 2562 20	3	26
39 1931 20	2	12	39 2601 20	11	22
39 1931 20	3	12	39 2602 20	8	22
39 1931 20	3	22	39 2606 07	3	18
39 1944 04	21	84	39 2606 07	16	28
39 1990 20	2	36	39 2608 01	12	4
39 2017 19	1	6	39 2669 21	10	8
39 2141 24	4	32	39 2704 11	9	32
39 2141 24	13	70	52 DT01 53	10	50
39 2141 24	21	98	52 DT04 54	1	38
39 2141 24	9	104	52 DT04 56	4	126
39 2141 24	20	112	52 DT04 57	3	126
39 2141 24	3	116	52 DT04 58	4	126

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
52 DT04 59	3	126	52 DT11 26	4	132
52 DT04 60	4	126	52 DT11 27	3	132
52 DT04 61	3	126	52 DT11 28	4	132
52 DT04 62	1	126	52 DT11 32	11	132
52 DT04 63	1	126	52 DT11 33	11	132
52 DT04 64	1	126	52 DT11 34	11	132
52 DT04 65	9	128	52 DT1129	12	132
52 DT04 66	8	128	52 DT1130	12	132
52 DT04 67	5	126	52 DT1131	12	132
52 DT04 68	6	126	52 JF03 28	47	120
52 DT04 69	5	126	52 JL01 56	1	60
52 DT04 70	6	126	52 JL01 57	2	60
52 DT04 71	5	126	52 JL08 92	1	36
52 DT04 72	6	126	52 JL09 23	7	126
52 DT04 76	2	126	52 JL09 32	7	126
52 DT04 77	2	126	52 JL09 41	7	126
52 DT04 78	2	126	52 JL09 85	7	126
52 DT04 79	7	126	52 JY01 85	9	54
52 DT04 80	7	126	56 DTE1 4X	22	136
52 DT04 81	7	126	56 DTE2 4X	23	136
52 DT11 06	2	132	56 DT07 4X	7	132
52 DT11 13	3	132	56 DT08 4X	8	132
52 DT11 17	4	132	56 DT09 C8	16	136
52 DT11 25	3	132	56 DT12 4X	10	128

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
56 DT12 4X	9	132	56 DT65 4Y	1	132
56 DT13 4X	11	128	56 DT65 B1	1	132
56 DT13 4X	10	132	56 DT65 B7	1	132
56 DT22 32	5	132	56 DTD7 4X	13	132
56 DT22 42	5	132	56 DTD8 6B	20	136
56 DT22 4Z	5	132	56 DTD9 6B	21	136
56 DT2Z 5N	3	74	56 JF18 1Y	9	66
56 DT31 33	2	90	56 JF19 1Y	11	66
56 DT31 33	17	136	56 JL18 4X	11	136
56 DT32 33	7	90	56 JL19 4X	13	136
56 DT32 33	18	136	56 JL2Z 7S	14	136
56 DT33 33	20	90	56 JL3S 4X	9	136
56 DT33 33	19	136	56 JL8U 7S	15	136
56 DT36 6B	22	112	59 2000 06	11	26
56 DT36 X3	6	132	59 2000 28	14	22
56 DT3T 4X	6	136	59 2100 23	17	26
56 DT3X 1Y	5	66	62 3050 84	22	140
56 DT3X 4X	8	136	75 6802 36	20	140
56 DT3Y 1Y	1	66	76 0109 36	14	140
56 DT3Y 4X	7	136	76 0109 37	15	140
56 DT4J 1Y	8	66	83 0201 73	7	138
56 DT4J 4X	10	136	83 0204 73	5	138
56 DT4K 1Y	12	66	83 0205 50	1	138
56 DT4K 4X	12	136	83 0205 53	1	138

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
AA 1014 37	9	22	DF 1611 02	6	72
AA 1014 37	2	26	DG 1010 29	9	6
AA 1014 37	17	36	DG 1210 02	10	44
AN 1013 48	18	56	DG 1410 28	14	96
AN 1110 15	14	56	DG 1510 05	6	76
BA 1020 04	12	38	DG 1710 16	4	64
BF 5510 37	15	14	DG 1710 18	5	64
BF 5610 20	13	26	DG 1710 19	6	64
BF 6010 13	24	32	DG 1810 03	20	62
BF 6214 02	17	54	DG 1810 04	19	62
CS 1011 28	12	8	DH 10 13 89	13	54
DD 1110 11	16	56	DH 1012 35	12	14
DD 1110 12	12	56	DH 1012 95	11	6
DD 1610 71	20	50	DH 1013 88	22	36
DE 1510 46	2	80	DH 1013 89	6	18
DE 1510 46	10	84	DH 1013 92	14	8
DE 1510 47	3	80	DH 1016 48	13	40
DE 1510 47	9	84	DH 1110 13	9	56
DE 1910 10	10	78	DH 1110 16	15	56
DE 1910 10	8	84	DH 1510 39	8	80
DE 1910 10	10	88	DH 1510 40	19	82
DE 1910 28	7	78	DH 1611 46	5	72
DE 1910 29	6	78	DH 1611 55	19	50
DE 1910 36	4	78	DH 1611 57	18	50

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DJ 1013 12	26	16	DK 1510 74	18	84
DJ 1610 91	15	70	DK 1510 81	23	82
DJ 1810 65	30	52	DK 1510 82	22	82
DJ 1811 26	28	34	DK 1510 85	13	84
DJ 1910 29	2	78	DK 1810 06	4	92
DJ 1910 30	3	78	DK 1810 07	5	92
DJ 1910 31	5	78	DK 1810 09	14A	92
DJ 1910 57	1	78	DK 1810 10	14B	92
DJ 2011 09	9	78	DK 1810 12	14C	92
DJ 2011 73	14	70	DK 1810 13	14D	92
JL 3518 11	5	4	DK 1810 15	11	92
DK 1013 40	6	4	DK 1810 17	9	92
DK 1013 52	24	16	DK 1810 18	7	92
DK 1110 11	8	56	DK 1810 19	8	92
DK 1110 28	17	56	DK 1810 20	10	92
DK 1510 12	7	82	DK 1810 21	6	92
DK 1510 15	11	82	DK 1810 23	17	92
DK 1510 26	2	74	DK 1810 28	20	92
DK 1510 45	19	84	DK 1810 50	17	62
DK 1510 63	7	84	DK 1810 51	8	62
DK 1510 69	11	78	DK 1810 52	12	78
DK 1510 69	4	84	DK 1810 75	24	94
DK 1510 69	11	88	DK 1810 76	25	94
DK 1510 72	20	84	DK 2011 62	18	90

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DK 2011 63	19	90	DT 1112 14	1	62
DK 2011 64	13	76	DT 1130 34	7	86
DK 2011 64	1	82	DT 1130 35	27	68
DK 2110 09	4	58	DT 1132 02	8	72
DK 9026 26	3	108	DT 1132 04	1	72
DP 1011 91	23	24	DT 1132 05	2	72
DP 1611 45	8	116	DT 1134 08	3	60
DS 1011 54	8	28	DT 1138 02	39	120
DS 1012 15	9	36	DT 1138 07	6	116
DS 1211 26	12	44	DT 1138 13	10	116
DS 1611 56	7	42	DT 1138 15	27	100
DS 1611 56	10	58	DT 1138 17	17	116
DS 1612 87	7	58	DT 1138 18	7	116
DS 1910 52	23	90	DT 1138 19	4	114
DS 2110 04	9	58	DT 1138 24	16	116
DS 2110 04	5	62	DT 1138 30	28	100
DS 2210 01	17	108	DT 1138 41	16	46
DT 1111 06	14	62	DT 1138 42	7	60
DT 1111 07	15	62	DT 1138 46	11	62
DT 1112 14	1	62	DT 1138 48	18	64
DT 1130 14	17	66	DT 1138 49	26	120
DT 1130 15	18	66	DT 1138 51	36	120
DT 1130 28	6	66	DT 1138 55	19	56
DT 1130 29	2	66	DT 1138 58	7	62

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DT 1138 60	42	120	DT 1318 49	8	88
DT 1138 62	4	88	DT 1318 53	1	80
DT 1138 64	26	48	DT 1318 72	9	88
DT 1138 65	43	120	DT 1318 72	28	94
DT 1210 31	21	94	DT 1318 75	16	62
DT 1210 32	22	94	DT 1318 75	18	88
DT 1210 35	18	92	DT 1318 78	15	76
DT 1210 36	12	92	DT 1318 78	15	88
DT 1210 37	15	92	DT 1318 91	1	88
DT 1210 49	1	92	DT 1318 92	1	88
DT 1210 52	2	92	DT 1510 10	1	90
DT 1210 53	3	92	DT 1510 12	8	90
DT 1220 19	1	64	DT 1510 39	6	90
DT 1220 29	3	64	DT 1510 40	13	92
DT 1220 32	1	64	DT 1510 42	16	92
DT 1310 17	2	76	DT 1510 43	23	94
DT 1310 18	1	74	DT 1510 46	26	94
DT 1312 22	5	74	DT 1610 00	3	86
DT 1318 02	7	76	DT 1610 01	1	86
DT 1318 17	2	84	DT 1610 04	6	86
DT 1318 26	1	84	DT 1610 05	15	90
DT 1318 31	8	78	DT 1610 07	11	90
DT 1318 37	1	70	DT 1610 10	11A	90
DT 1318 37	14	88	DT 1610 13	2	136

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DT 1612 03	2	106	DT 1718 52	22	48
DT 1612 04	1	106	DT 1810 00	5	108
DT 1710 30	31	100	DT 1810 01	1	32
DT 1710 42	2A	126	DT 1810 10	8	104
DT 1710 53	3	98	DT 1810 11	11	104
DT 1710 55	15	96	DT 1810 11	30	112
DT 1710 61	13	96	DT 1810 13	14	102
DT 1710 73	35	100	DT 1810 22	25	120
DT 1710 75	18	96	DT 1810 28	2	32
DT 1710 76	10	62	DT 1810 30	36	100
DT 1710 78	19	96	DT 1810 30	31	112
DT 1710 80	4	98	DT 1810 34	34	100
DT 1710 82	32	100	DT 1810 42	37	34
DT 1710 87	10	96	DT 1810 43	38	34
DT 1710 89	9	96	DT 1812 07	10	102
DT 1710 92	1	96	DT 1812 10	4	102
DT 1716 11	23	48	DT 1812 10	14	128
DT 1716 12	6	46	DT 1812 14	21	130
DT 1716 13	2	46	DT 1812 15	11	98
DT 1718 14	11	96	DT 1812 21	22	130
DT 1718 21	19	46	DT 1812 28	12	98
DT 1718 39	5	96	DT 1812 32	18	110
DT 1718 46	11	46	DT 1812 33	5	104
DT 1718 47	8	46	DT 1812 42	2	110

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DT 1812 44	23	98	DT 1813 21	12	62
DT 1812 46	24	100	DT 1813 23	9	62
DT 1812 55	6	104	DT 1813 24	13	128
DT 1812 56	11	70	DT 1813 25	28	112
DT 1812 65	3	62	DT 1813 26	38	100
DT 1812 65	29	100	DT 1813 47	36	34
DT 1812 65	11	102	DT 1814 14	4	108
DT 1812 67	23	112	DT 1814 15	6	108
DT 1812 68	24	112	DT 1814 16	18	108
DT 1812 73	22	98	DT 1814 33	2	70
DT 1812 74	7	98	DT 1814 34	8	70
DT 1812 75	25	112	DT 1814 35	3	70
DT 1812 84	9	124	DT 1814 37	4	70
DT 1812 85	26	112	DT 1814 39	9	70
DT 1812 86	12	128	DT 1910 06	1	58
DT 1812 91	15	98	DT 1910 09	8	58
DT 1812 92	16	98	DT 1910 12	6	58
DT 1812 93	17	98	DT 1910 22	15	58
DT 1812 94	27	112	DT 2310 00	2	122
DT 1812 99	10	124	DT 2310 02	1	122
DT 1813 10	5	110	DT 2314 04	1	124
DT 1813 11	6	110	DT 2314 05	2	124
DT 1813 16	45	120	DT 2316 06	13	124
DT 1813 17	46	120	DT 2316 07	11	124

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DT 2316 08	12	124	DT 4010 08	7	110
DT 2316 09	16	124	DT 4010 09	1	110
DT 2316 10	17	124	DT 4010 10	1A	110
DT 2316 11	6	124	DT 4010 11	8	110
DT 2316 12	7	124	DT 4010 12	7A	110
DT 2326 05	12	58	DT 4010 17	9	110
DT 2326 06	13	58	DT 4010 18	11	110
DT 2326 06	17	90	DT 4010 19	12	110
DT 2326 06	2	96	DT 4010 24	8A	110
DT 2328 04	18	116	DT 4014 08	13	90
DT 2328 15	4	116	DT 4020 08	4	118
DT 2328 16	11	116	DT 4020 09	40	120
DT 2331 72	24	130	DT 4022 18	5	118
DT 2331 86	19A	128	DT 4022 23	6	118
DT 2332 43	16	134	DT 4022 26	13	118
DT 2332 44	16	134	DT 4022 27	13	118
DT 3510 15	2	56	DT 4022 34	18	54
DT 3518 03	8	42	DT 4022 46	1	118
DT 3518 06	7	26	DT 4022 56	1	118
DT 4010 01	5	116	DT 4024 15	12	104
DT 4010 02	1	114	DT 4024 23	1	104
DT 4010 03	2	114	DT 5010 30	1	22
DT 4010 04	5	114	DT 5110 97	4	4
DT 4010 05	6	114	DT 5112 61	4	6

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DT 5112 62	5	6	DT 5911 16	7	50
DT 5410 18	13	36	DT 5911 18	8	50
DT 5410 19	5	36	DT 5911 31	23	52
DT 5412 10	11	38	DT 5911 32	24	52
DT 5514 01	9	40	DT 5911 33	31	52
DT 5514 02	5	40	DT 5913 40	6	50
DT 5514 03	10	40	DT 6012 10	16	32
DT 5514 08	7	40	DT 6012 26	14	32
DT 5514 09	1	40	DT 6012 28	15	32
DT 5514 12	2	40	DT 6012 32	6	32
DT 5612 01	7	20	DT 6112 08	3	42
DT 5612 05	6	20	DT 6112 08	8	96
DT 5612 06	11	20	DT 6112 10	1	42
DT 5614 08	1	20	DT171042	24	134
DT 5614 09	2	20	DT181214	22	134
DT 5614 14	4	136	DT181221	23	134
DT 5614 16	3	136	DT181286	20	134
52 DT11 69	5	136	DT181324	21	134
DT 5810 28	4	44	DT233225	18	134
DT 5810 48	5	44	DT233226	18	134
DT 5810 49	6	44	DT233227	17	134
DT 5810 62	3	44	EC 5610 23	2	18
DT 5810 64	1	44	FD 2110 06	3	58
DT 5910 72	11	50	FD 2210 19	10	70

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
GF 1611 43	26	68	JF 2330 36	9	38
GL 1810 43	19	98	JF 4014 05	11	72
GL 1810 43	13	104	JF 5310 07	16	12
JA 1134 03	5	60	JF 5310 14	13	12
JA 3516 27	14	54	JF233310	19	134
JA 5410 48	15	26	JG 1134 07	6	70
JA 5412 33	2	38	JG 1138 06	26	100
JB 1130 07	21	88	JG 1220 28	2	108
JB 1812 23	13	62	JG 1310 01	5	76
JB 2312 08	4	86	JG 1312 20	21	82
JC 1010 34	9	8	JG 1318 21	5	84
JC 1810 20	19	92	JG 1510 22	16	90
JD 1318 11	9	76	JG 1610 08	12	90
JD 1710 18	18	124	JG 1610 10	24	90
JD 1710 59	17	46	JG 1710 29	30	34
JD 3512 07	13	56	JG 1710 29	21	48
JE 3512 56	7	56	JG 1710 31	3	32
JF 1138 42	18	118	JG 1710 31	18	98
JF 1710 64	24	48	JG 1710 31	37	100
JF 1716 07	12	46	JG 1710 31	5	102
JF 1718 07	18	46	JG 1710 31	16	110
JF 1812 73	22	118	JG 1710 86	7	46
JF 1812 82	33	120	JG 1812 36	19	110
JF 1813 08	38	120	JG 1812 38	2	104

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JG 1812 39	22	84	JG 5310 41	6	12
JG 1812 50	31	34	JG 5310 41	4	54
JG 1910 08	2	58	JG 5312 07	7	28
JG 2326 03	16	58	JG 5312 15	5	28
JG 2326 06	17	58	JG 5312 29	4	28
JG 2330 01	7	62	JG 5410 15	12	26
JG 3510 19	10	54	JG 5410 41	16	26
JG 3514 00	7	4	JG 5410 43	20	26
JG 3518 05	6	42	JG 5410 43	15	54
JG 4010 36	9	116	JG 5410 44	5	26
JG 4022 28	13	118	JG 5410 45	22	24
JG 4022 29	13	118	JG 5410 58	18	26
JG 4022 30	14	118	JG 5410 59	10	22
JG 4030 03	12	118	JG 5410 68	1	4
JG 5110 21	2	2	JG 5412 11	5	38
JG 5110 22	1	2	JG 5412 23	5	56
JG 5110 46	8	4	JG 5412 30	7	36
JG 5112 69	7	8	JG 5412 31	16	36
JG 5112 70	13	8	JG 5510 00	22	16
JG 5210 08	6	10	JG 5510 13	3	14
JG 5310 27	9	12	JG 5510 17	4	36
JG 5310 31	11	12	JG 5510 20	5	14
JG 5310 40	4	12	JG 5510 22	10	14
JG 5310 40	6	54	JG 5510 27	1	14

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JG 5510 31	25	16	JG 5612 17	13	20
JG 5512 13	4	14	JG 5612 22	5	18
JG 5512 14	7	14	JG 5612 25	10	18
JG 5512 15	20	14	JG 5612 26	19	22
JG 5512 16	17	12	JG 5612 32	14	20
JG 5512 20	8	14	JG 5710 14	24	24
JG 5512 25	23	16	JG 5710 16	25	24
JG 5512 27	9	14	JG 5710 18	3	30
JG 5514 23	14	40	JG 5810 14	10	32
JG 5514 28	4	40	JG 5810 56	11	44
JG 5514 43	8	40	JG 5814 07	19	4
JG 5514 48	6	40	JG 5814 19	11	42
JG 5514 51	11	40	JG 5814 19	3	106
JG 5514 55	6	40	JG 5814 23	9	42
JG 5610 09	17	22	JG 5814 24	4	42
JG 5610 10	4	18	JG 5910 38	4	50
JG 5610 11	1	18	JG 5910 39	5	50
JG 5610 12	7	18	JG 5910 68	26	52
JG 5610 16	9	18	JG 5910 70	2	50
JG 5612 04	15	22	JG 6010 05	6	28
JG 5612 05	16	22	JG 6010 07	6	22
JG 5612 15	11	18	JG 6010 12	13	28
JG 5612 15	12	20	JG 6012 11	17	32
JG 5612 16	15	20	JG 6012 30	18	32

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JG 6012 34	20	32	JL 1220 26	17	64
JG 6012 35	19	32	JL 1310 00	10	76
JG 6110 06	10	42	JL 1310 01	1	76
JG 6110 07	2	42	JL 1310 04	3	74
JG 5814 21	5	42	JL 1310 04	4	76
JG 6214 12	3	54	JL 1312 03	3	82
JG 6214 13	2	54	JL 1312 09	4	74
JG 6214 17	7	54	JL 1312 09	14	82
JH 4010 31	29	94	JL 1312 11	6	82
JL 1110 54	4	60	JL 1312 16	15	82
JL 1130 06	29	68	JL 1312 20	6	84
JL 1130 12	3	66	JL 1312 25	9	82
JL 1130 36	16	66	JL 1312 32	12	82
JL 1130 37	24	68	JL 1318 07	4	80
JL 1132 09	4	72	JL 1318 31	6	80
JL 1138 18	12	72	JL 1318 31	7	80
JL 1138 25	24	120	JL 1318 32	5	80
JL 1138 41	18	62	JL 1318 41	13	66
JL 1220 01	8	64	JL 1318 78	25	84
JL 1220 02	7	64	JL 1319 30	18	82
JL 1220 03	10	64	JL 1319 51	1	136
JL 1220 04	13	64	JL 1510 35	9	90
JL 1220 08	14	64	JL 1510 38	3	90
JL 1220 09	9	64	JL 1610 03	14	90

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JL 1710 19	12	96	JL 4030 00	2	118
JL 1710 20	4	62	JL 4032 00	7	118
JL 1710 20	20	96	JL 5110 09	3	4
JL 1711 01	20	46	JL 5110 10	2	6
JL 1711 02	5	46	JL 5110 11	3	6
JL 1718 36	14	46	JL 5110 22	16	4
JL 1718 52	6	96	JL 5110 29	10	4
JL 1812 05	1	108	JL 5110 41	3	2
JL 1812 20	16	70	JL 5110 42	4	2
JL 1812 24	15	64	JL 5111 12	13	4
JL 1812 25	16	64	JL 5111 14	6	6
JL 1812 53	13	108	JL 5111 15	7	6
JL 1812 97	16	108	JL 5112 22	8	8
JL 1813 25	5	70	JL 5112 31	6	8
JL 1814 08	7	108	JL 5112 50	5	8
JL 1814 10	12	108	JL 5112 71	1	8
JL 2312 02	4	124	JL 5210 04	1	10
JL 2312 09	19	124	JL 5212 00	2	10
JL 2326 04	14	58	JL 5310 05	16	8
JL 2330 19	20	64	JL 5312 03	3	28
JL 3512 18	10	56	JL 5312 05	7	22
JL 3512 52	11	56	JL 5312 05	1	28
JL 3516 00	1	54	JL 5412 03	7	38
JL 4014 06	5	86	JL 5412 07	12	36

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JL 5412 18	19	36	JL 6012 21	32	34
JL 5412 22	18	36	JL 6012 22	21	32
JL 5412 23	10	38	JL 6012 23	22	32
JL 5412 27	8	36	JL 6012 28	23	32
JL 5412 30	20	36	JL 6012 37	11	4
JL 5412 31	21	36	JL233347	19	134
JL 5514 07	12	40	JN 1810 31	36	112
JL 5614 09	8	20	JP 3514 39	15	118
JL 5614 10	10	20	JP 4030 00	11	118
JL 5710 01	26	24	JP 5510 11	19	14
JL 5810 39	18	4	JP 5510 12	6	14
JL 5810 55	9	44	JP 5512 24	17	14
JL 5810 56	8	44	JP 5512 25	16	14
JL 5910 45	12	50	JP 5512 26	21	16
JL 5911 48	21	52	JP 5610 03	8	18
JL 5911 56	14	50	JP 5910 65	3	50
JL 5911 57	6A	50	JP 6012 35	7	32
JL 5911 65	13	50	JU 1318 01	8	76
JL 5913 24	1	50	JU 1318 02	20	82
JL 6010 05	12	28	JU 1716 06	3	46
JL 6010 10	28	24	JU 2328 00	1	116
JL 6012 12	26	34	JU 5212 10	3	10
JL 6012 16	8	32	JU 5212 12	4	10
JL 6012 19	25	34	JU 5310 21	14	12

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JU 5410 05	13	22	JY 4036 04	17	118
JU 5410 18	4	26	JY 5410 47	4	22
JU 5510 03	11	14	JY 5410 58	10	26
JU 5512 01	14	14	JY 5514 02	11	54
JU 5514 01	6	36	JY 5710 30	14	26
JU 5710 00	1	30	JY 5810 28	7	44
JU 5810 06	13	44	JZ 1130 61	15	66
JW 1710 16	5	98	JZ 1610 28	25	90
JW 1710 16	2	102	JZ 1710 55	15	46
JW 1710 16	33	112	JZ 1812 06	21	112
JW 1710 16	10	98	JZ 1813 22	6	62
JY 1138 42	10	46	JZ 1813 22	12	102
JY 1138 64	27	120	JZ 1910 10	5	58
JY 1138 72	34	120	JZ 4036 01	3	72
JY 1138 73	35	120	KA AD06 10	28	48
JY 1138 74	29	120	KA AD06 18	19	88
JY 1138 77	30	120	KA CA06 18	5	124
JY 1710 07	28	120	KA CA08 30	3	124
JY 1710 69	4	46	KA CC06 50	10	90
JY 1710 70	9	46	KA CD05 16	3	96
JY 1710 77	1	46	KA Cd05 16	7	104
JY 1718 25	13	46	KA CF05 30	7	70
JY 3510 19	1	56	KA CF08 30	21	90
JY 4022 35	7	96	KA DA05 16	10	72

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
KA DA06 08	44	120	KA EA06 22	23	118
KA DA06 12	25	48	KA EA06 22	12	88
KA DA06 12	13	88	KA EA06 25	41	120
KA DA06 22	11	58	KA ED06 08	7	88
KA DA06 30	15	44	KA ED06 12	6	88
KA DA06 30	22	52	KA EQ06 16	27	24
KA DA06 30	16	118	KA EQ06 20	9	4
KA DA08 14	10	118	KA EQ06 20	11	8
KA DD05 08	4	56	KA EQ06 30	14	36
KA DD06 08	35	34	KA EQ06 30	6	38
KA DD06 10	25	100	KA EQ06 40	22	26
KA DD06 10	14	44	KA EQ06 45	8	38
KA DD06 12	14	66	KA EW06 22	14	28
KA DD06 14	2	82	KB BA05 12	3	84
KA DD06 20	6	56	KB RA42 13	7	102
KA DD06 22	3	20	KB UA05 16	6	98
KA DD08 30	2	86	KB UA06 30	2	44
KA DF06 16	29	112	KB UF04 08	8	108
KA DP05 16	6	26	KB UF05 16	20	98
KA DQ06 25	1A	54	KB UF05 16	14	110
KA DT06 14	17	70	KB UF06 12	13	32
KA DT06 14	14	76	KB UF06 12	9	98
KA EA06 12	30	100	KB UF06 14	3	102
KA EA06 12	3	122	KB UF06 14	35	112

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
KC AA05 04	4	104	KE BA35 15	16	76
KC AM06 05	4	20	KE BA37 15	9	26
KC EA06 05	10	110	KE BA42 17	26	82
KC EE05 04	17	110	KE BB35 15	4	8
KC GA05 05	14	116	KE CA60 08	34	112
KC GA06 06	27	48	KH AA20 15	16	84
KC GA06 06	13	116	KH AA25 20	22	68
KC GA06 06	31	120	KJ AA14 24	7A	36
KC GA06 06	37	120	KJ AA14 24	8	86
KC GA10 10	8	114	KJ AC18 24	14	4
KC GD10 10	6	60	KP AC60 05	8	82
KC HC06 08	20	118	KP BC62 02	3	76
KD AA06 11	15	84	KP BC62 02	13	82
KD AA08 16	23	68	KP BC63 02	16	82
KD AB06 11	4	122	KP BF62 03	2	28
KD AD06 11	15	108	LA A000 09	28	68
KD BA06 13	12	32	LA A000 19	10	82
KD BA06 13	9	102	LA C000 03	3	56
KD BA06 13	32	112	LA C000 08	19	118
KD BB08 18	13	72	LA C000 19	2	64
KD BF06 13	8	98	LA C000 20	5	90
KD DB06 12	29	34	LA C000 22	8	124
KD DF08 15	10	108	LA C000 22	1	98
KE AB10 10	4	30	LA C000 37	9	108

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
LA C000 45	4	66	LA E000 42	8	6
LA C000 54	14	108	LA E000 42	21	26
LA C000 62	25	52	LA E000 42	16	54
LA C000 68	27	94	LB B000 06	12	22
LA C000 74	7	66	LB B000 07	21	24
LA C000 86	10	28	LB B000 07	19	26
LA C001 28	11	108	LB C000 02	17	4
LA D000 36	27	52	LB R000 02	14	98
DJ 1910 28	13	78	LB R000 02	15	110
LA D000 77	5	22	LB U000 09	2	116
LA D000 77	24	84	LB U000 12	13A	90
LA D000 77	22	90	LB U000 22	29	52
LA D000 81	24	26	LB U000 23	5	32
LA D001 20	3	110	LB U000 23	6	102
LA D001 35	9	72	LB U000 27	2	98
LA D001 51	17	96	LC B000 03	5	20
LA D001 54	4	96	LC D000 01	7	12
LA E000 06	20	88	LC G000 06	15	50
LA E000 10	23	26	LC G000 29	11	32
LA E000 17	27	16	LC H000 01	7	72
LA E000 17	17	28	LC J000 02	12	76
LA E000 18	6	30	LC J000 02	24	82
LA E000 21	5	88	LC L000 01	3	114
LA E000 41	34	34	LC L000 04	5	82

Parts Index

RS 200 BS VI

Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
LD A000 07	13	98	NA	21	140
LD A000 07	13	110	PA 4016 00	8	118
LD A000 07	8	102	PA 4022 04	7	114
LD A000 08	2	4	PA 4022 04	32	120
LD A000 09	28	52	PD 5911 01	9	50
LD A000 13	25	68	YD T020 02	7B	110
LD B000 07	3	104	YD T020 03	8B	110
LD B000 10	8	54	YD T020 04	10	104
LD B000 15	39	34	YD T020 05	37	112
LD B000 20	3	36	YJ L040 05	11	84
LD B000 23	1	102	YJ L040 06	12	84
LD B000 29	11	76			
LD B000 29	4	82			
LD B000 50	18	22			
LD B000 51	9	28			
LD F000 01	12	54			
LD H000 02	5	12			
LD H000 02	5	54			
LD H000 08	14	124			
LJ A000 04	14A	26			
LJ A000 05	33	34			
LP B000 04	3	8			
LP B000 07	2	8			
NA	20	140			