

CT110 BS VI
ES & KS UG



**THE WORLD'S
FAVOURITE
INDIAN**

CT110 BS VI
ES & KS UG

Bajaj Auto Limited
Akurdi Pune 411 035 India
Tel +91 20 27472851
Fax +91 20 27407385
www.bajajauto.com
CIN L65993PN2007PLC130076

Spare Parts Catalogue



All information contained in this manual is based on the latest product information at the time of publication. Bajaj Auto Limited accepts no liability for any inaccuracies or omissions in this publication, although every possible care has been taken to make it as complete and accurate as possible. All procedures and specifications subject to change without prior notice. The right is reserved to make such changes at any time without prior notice and without incurring an obligation to make such changes to product manufactured previously. Contact your authorized Bajaj Dealer for the latest information on product improvements incorporated after this manual was issued.

DOC. NO.: 71120145

REV. 05 AUG. 21

Copy rights : All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, Or transmitted in any form or by any means, electronic mechanical photocopying, recording or otherwise, without the prior written permission of Bajaj Auto LTD.

We have pleasure in presenting the Spare Parts Catalogue for 'CT 110 BS VI UG' Motorcycle. This catalogue has been specially designed to assist you in selecting the correct parts for procurement to maintain 100% availability.

The Bajaj spares are subjected to the stringent quality control standards to ensure longer life of the vehicle. It is therefore necessary that only the Genuine Bajaj Spares are used.

In a continual effort to improve Performance and Efficiency of the vehicles, Specifications, Diagrams, Illustrations and Part Numbers can change without notice. Consequently, the description in this Spare Parts Catalogue cannot therefore be final and binding on us.

The modifications / alterations which are carried out after the issue of this catalogue, will be conveyed to you through our Service Circulars. You are requested to make necessary corrections in the Parts Catalogue as per the circulars so as to keep your catalogue up-to-date. This will ensure the appropriate and speedy delivery of the Spare Parts as the order placed will bear the latest part numbers.

In case, if you need any technical assistance contact the concerned Regional Office or write to us on the following address :

Bajaj Auto Limited

Service Department

Akurdi, Pune 411 035 India

- 1. How to Read the Catalogue :** Open the catalogue and from the pictorial index locate the group in which the part you want to find is present. Turn over to the concerned page number (as given by pictorial index). Now find out the figure of the part you wish to order. Write down the part number against that particular figure number from the text.

In case, if you have the part number and you need the other details, the part index can be used. The part index (at the end of the catalogue) will give you the figure and page number of the part you wish to order.

- 2. How to Order Spare Parts :** The part number and the description of the part required should be invariably mentioned in the order as per the catalogue text.

The latest part number as conveyed through our service circulars should only appear on the order. In case of ordering painted components, colour shade of the components should be mentioned.

The quantity shown against the part number is the quantity per vehicle for that group so that particular quantity should be multiplied by the number of sets required.

- 3. Part Number System :** We have used 8 digit system for part numbers. The model or hardware item is indicated by first two digits or alphanumeric, the next two or four digits indicate main group and the last four or two digits indicate serial number in main group or serial number or subgroup of fastener respectively. Thus the part numbers will be indicated by 2-2-4 or 2-4-2 digit system. Understanding this system will enable you to identify the spare parts easily.

- 4. Abbreviations :** The following abbreviations are used in this catalogue.

Assly	Assembly	V	Volts
N.I.	Not illustrated	W	Watts
C'case	Crankcase	Accl.	Accelerator
Cyl	Cylinder	Comp.	Complete
O/s	Over size	Fr.	Front
RR	Rear	Std.	Standard
L	Length	A/t.	Alternate
R.H.	Right hand	L.H.	Left hand
Hex.	Hexagonal	AR	As required

Plate No.	Description	Page No.
1	Cover Cylinder Head	2
2	Cylinder Head	4
3	Valve	6
4	Camshaft / Tensioner	8
5	Cylinder and Piston	10
6	Crankshaft	12
7	Transmission	14
8	Change Drum / Shift Fork	16
9	Gear Change Mechanism	18
10	Engine Assembly / Crankcase RH	20
11	Crankcase LH	22
12	Oil Pump	24
13	Kick Starter Mechanism	26
14	Cover Clutch	28
15	Cover Magneto	30
16	Clutch Assembly	32
17	Carburettor Assembly	34
18	Air Cleaner Complete	36
19	EVAP Mechanism	38
20	Silencer Assembly	40
21	Starter Assembly - For ES Only	42
22	Magneto, H.T. Coil & ECU EMS Assembly	44
23	Seat Assembly & Mounting	46
24	Engine Mountings	48
25	Frame and Frame Fitting	50
26	Swing Arm / Rear Shock Absorber	52
27	Foot Rest - Rider / Pillion	54
28	Mudguard - Front & Rear	56
29	Stand Assembly	58

Plate No.	Description	Page No.
30	Tyre / Tube / Rim	60
31	Front Hub	62
32	Rear Hub	64
33	Rear Brake Pedal	66
34	Handle Bar Assembly	68 - 70
35	Front Fork	72 - 74
36	Petrol Tank Cap & Gauge Fuel	76
37	Fittings - Petrol Tank, Side Cover & Seat Cowl	78
38	Speedometer Assembly	80
39	Control Cables	82
40	Chain Case	84
41	Head Lamp & Fairing - For ES Only	86
42	Head Lamp & Fairing - For KS Only	88
43	Indicator Light Assembly	90
44	Tail Lamp Assembly / Number Plate	92
45	Electrical Equipments	94
46	Tool Kit	96
47	Accessories / Grab Handle	98
48	Painted Parts & Decals	100 - 102
49	Consumable Parts	104 - 106
	Kits List	107 - 110
	Part Index	111 - 124

Pictorial Index

GT110 BS VI

PLATE NO. : 1 COVER CYLINDER HEAD	PAGE NO. 1
--------------------------------------	---------------




PLATE NO. : 2 CYLINDER HEAD	PAGE NO. 3
--------------------------------	---------------




PLATE NO. : 3 VALVE	PAGE NO. 5
------------------------	---------------





PLATE NO. : 4 CAMSHAFT / TENSIONER	PAGE NO. 7
---------------------------------------	---------------



Pictorial Index

GT110 BS VI

PLATE NO. : 5 CYLINDER AND PISTON	PAGE NO. 9
--------------------------------------	---------------




PLATE NO. : 6 CRANKSHAFT	PAGE NO. 11
-----------------------------	----------------




PLATE NO. : 7 TRANSMISSION	PAGE NO. 13
-------------------------------	----------------




PLATE NO. : 8 CHANGE DRUM / SHIFT FORK	PAGE NO. 15
---	----------------




PLATE NO. : 9
GEAR CHANGE MECHANISM

PAGE NO.
17




PLATE NO. : 11
CRANKCASE LH

PAGE NO.
21




PLATE NO. : 10
ENGINE ASSEMBLY / CRANKCASE RH

PAGE NO.
19




PLATE NO. : 12
OIL PUMP

PAGE NO.
23




PLATE NO. : 13
KICK STARTER MECHANISM

PAGE NO.
25




PLATE NO. : 15
COVER MAGNETO

PAGE NO.
29




PLATE NO. : 14
COVER CLUTCH

PAGE NO.
27




PLATE NO. : 16
CLUTCH ASSEMBLY

PAGE NO.
31




PLATE NO. : 17 CARBURETTOR ASSEMBLY	PAGE NO. 33
--	----------------




PLATE NO. : 18 AIR CLEANER COMPLETE	PAGE NO. 35
--	----------------




PLATE NO. : 19 EVAP MECHANISM	PAGE NO. 37
----------------------------------	----------------




PLATE NO. : 20 SILENCER ASSEMBLY	PAGE NO. 39
-------------------------------------	----------------




PLATE NO. : 21 STARTER ASSEMBLY - FOR ES ONLY	PAGE NO. 41
--	----------------




PLATE NO. : 22 MAGNETO, H.T. COIL & ECU EMS ASSEMBLY	PAGE NO. 43
--	----------------




PLATE NO. : 23 SEAT ASSEMBLY & MOUNTING	PAGE NO. 45
--	----------------





PLATE NO. : 24 ENGINE MOUNTINGS	PAGE NO. 47
------------------------------------	----------------



Pictorial Index

GT110 BS VI

PLATE NO. : 25
FRAME AND FRAME FITTING

PAGE NO.
49




PLATE NO. : 26
SWING ARM / REAR SHOCK ABSORBER

PAGE NO.
51




PLATE NO. : 27
FOOT REST - RIDER / PILLION

PAGE NO.
53





PLATE NO. : 28
MUDGUARD - FRONT & REAR

PAGE NO.
55



Pictorial Index

GT110 BS VI

PLATE NO. : 29
STAND ASSEMBLY

PAGE NO.
57




PLATE NO. : 30
TYRE / TUBE / RIM

PAGE NO.
59




PLATE NO. : 31
FRONT HUB

PAGE NO.
61





PLATE NO. : 32
REAR HUB

PAGE NO.
63



Pictorial Index

GT110 BS VI

PLATE NO. : 33 REAR BRAKE PEDAL	PAGE NO. 65
------------------------------------	----------------

PLATE NO. : 34 HANDLE BAR ASSEMBLY	PAGE NO. 67 - 69
---------------------------------------	---------------------

PLATE NO. : 35 FRONT FORK	PAGE NO. 71 - 73
------------------------------	---------------------

PLATE NO. : 36 PETROL TANK CAP & GAUGE FUEL	PAGE NO. 75
--	----------------

Pictorial Index

GT110 BS VI

PLATE NO. : 37 FITTINGS - PETROL TANK, SIDE COVER & SEAT COWL	PAGE NO. 77
---	----------------

PLATE NO. : 38 SPEEDOMETER ASSEMBLY	PAGE NO. 79
--	----------------

PLATE NO. : 39 CONTROL CABLES	PAGE NO. 81
----------------------------------	----------------

PLATE NO. : 40 CHAIN CASE	PAGE NO. 83
------------------------------	----------------

Pictorial Index

GT110 BS VI

PLATE NO. : 41
HEAD LAMP & FAIRING - FOR ES ONLY

PAGE NO.
85




PLATE NO. : 43
INDICATOR LIGHT ASSEMBLY

PAGE NO.
89




PLATE NO. : 42
HEAD LAMP & FAIRING - FOR KS ONLY

PAGE NO.
87





PLATE NO. : 44
TAIL LAMP ASSLY / NUMBER PLATE

PAGE NO.
91



Pictorial Index

GT110 BS VI

PLATE NO. : 45
ELECTRICAL EQUIPMENTS

PAGE NO.
93




PLATE NO. : 47
ACCESSORIES / GRAB HANDLE

PAGE NO.
97




PLATE NO. : 46
TOOL KIT

PAGE NO.
95





PLATE NO. : 48
PAINTED PARTS & DECALS

PAGE NO.
99 - 101




PLATE NO. : 49 CONSUMABLE PARTS		PAGE NO. 103
1 	2 	3 
4 	5 	6 
7 	8 	9 
10 	11 	12 

PLATE NO. : 49 CONSUMABLE PARTS		PAGE NO. 105
13 	14 	15 
16 	17 	18 
19 	20 	21 
22 	23 	24 



Cover Cylinder Head


No.	Part No.	Description	Qty.	Remarks
1	JV 5110 13	Cover Cylinder Head Complete	1	
2	59 0400 38	Bolt flanged - M6 x 1 x L35	4	
3	JV 5110 12	Gasket Cylinder Head Cover	1	
4	JV 5110 11	Plate Cylinder Head	1	
5	JB 5110 11	Bolt Head Mounting - M8 x 1.25 x 190L	4	
6	JB 5110 15	Bolt Head Mtg	1	



 Front Wheel Direction


Cylinder Head

No.	Part No.	Description	Qty.	Remarks
1	PF 5115 24	Head Cylinder	1	
2	39 1660 05	Stud - M8	2	
3	PF 5111 11	Gasket head cylinder	1	
4	JB 5814 11	Insulator Manifold	1	
5	52 PF17 37	Manifold Intake	1	
6	39 1283 21	O - Ring	2	
7	KA ED06 25	Bolt flanged small	2	
8	39 1283 21	O Ring	1	
9	DH 1023 29	Sleeve plug spark	1	
10	KJ AC18 24	O - Ring	1	
11	39 2608 01	Grub screw	1	
12	52 PF21 34	Sleeve Carburettor	1	
13	GL 5814 79	Clamp 42	2	




Valve

No.	Part No.	Description	Qty.	Remarks
1	36 DU40 76	Kit Valve Intake + Exhaust	1	Refer Kit List
2	36 JV00 06	Kit Valve Repair	1	Refer Kit List
3	CB 1010 09	Seal - Oil	2	
4	CB 1010 22	Cottor Valve	4	
5	DU 1010 60	Arm Rocker with Roller	2	
6	JH 5112 12	Shaft Rocker Arm	2	




Camshaft / Tensioner

No.	Part No.	Description	Qty.	Remarks
1	PF 5112 55	Assembly camshaft	1	Refer Kit List
2	KE BB35 15	Circlip internal	1	
3	DD 1010 62	Bolt Tensioner	1	
4	JA 5112 16	Spacer Cam Sprocket	1	
5	PF 5112 58	Sprocket camshaft	1	
6	DH 1010 48	Washer- Special: Camshaft	1	
7	DK 1013 86	Precoated Soc Hd Cap Bolt M8 X 40	1	
8	PF 5112 57	Chain	1	
9	36 JZ01 22	Kit Guide Chain Cam	1	
10	DH 1013 92	Tensioner Pivot Bolt	1	
11	CS 1011 28	Gasket	1	
12	JE 5210 16	Chain Tensioner	1	
13	KA ED06 20	Bolt Flange M6	2	
14	39 2669 21	Ring - 'O' (ID 10.15X1.5)	1	
15	JE 3514 07	Sensor Temperature Engine	1	




Cylinder and Piston

No.	Part No.	Description	Qty.	Remarks
1	36 JK01 15	Kit Cylinder Block and Piston	1	Refer Kit List
2	39 1000 06	Pin - Hollow Dowel	2	
3	JH 5210 07	Gasket Cylinder Block	1	
4	PA 5212 14	Pin Snap	2	
5	36 JK00 65	Kit Piston Ring	1	Refer Kit List
6	JE 3514 07	Sensor temperature	1	
7	39 2671 04	Hexagon Bolt With Flange	1	




Crankshaft

No.	Part No.	Description	Qty.	Remarks
1	PF 5310 61	Crankshaft Assembly	1	
2	JE 5310 01	Bearing Ball	2	
3	LD A000 25	Washer plain - ID 14.5 x OD26 x Thik3	2	
4	59 1500 14	Nut Flange	2	
5	JA 5310 15	Pin (C/S Plunger)	1	
6	31 1011 73	Key -Woodruff	1	
7	DS 1011 54	Key	1	
8	JA 5310 12	Spring	1	
9	JB 5310 21	Plunger Oil Crankshaft	1	
10	JE 5410 38	Damper Crankshaft	1	




Transmission

No.	Part No.	Description	Qty.	Remarks
1	PA 5510 02	Shaft Input	1	
2	PA 5512 07	Gear 4th Drive	1	
3	JA 5510 02	Spline Washer	3	
4	39 0987 17	Ring - Snap	5	
5	PF 5512 01	Gear 3rd Drive	1	
6	PF 5512 00	Gear 2nd Drive	1	
7	JA 5510 04	Washer Thrust 2nd Drive	1	
8	PF 5510 03	Shaft Output	1	
9	PF 5512 06	Washer Gear 2nd Driven	1	
10	PF 5512 03	Gear 2nd Driven	1	
11	PF 5512 04	Gear 3rd Driven	1	
12	PA 5512 06	Gear 4th Driven	1	
13	JZ 5512 05	Bush 1st Driven	1	
14	PA 5512 05	Gear 1st Driven	1	
15	JA 5510 08	Washer Thrust	1	
16	JA 5510 09	Collar Sprocket Drive	1	
17	59 2100 24	O-Ring	1	
18	DU 1012 13	Plate Lock-sprocket output	1	
19	DS 1013 55	Bolt Flanged	2	




Change Drum / Shift Fork

No.	Part No.	Description	Qty.	Remarks
1	PF 5610 00	Assly Drum Gear Shift	1	
2	PF 5610 02	Shaft Gear Fork Shift	2	
3	JD 5610 04	Fork Gear Shift Output	1	
4	JZ 5610 02	Fork Input Disco-H	1	
5	JA 5610 02	Cam Drum Change	1	
6	JD 5610 11	Special bolt	1	
7	39 0992 06	Dowel	5	




Gear Change Mechanism

No.	Part No.	Description	Qty.	Remarks
1	PF 5612 00	Lever Comp Gear Shift	1	
2	JW 5612 06	Extension Spring	1	
3	JW 5612 08	Spring Gear Shift Return	1	
4	BF 5612 19	Bolt	1	
5	LD B000 44	Washer (Spring Steel)	1	
6	JH 5612 00	Inhibitor Comp. Gear Shift	1	
7	PF 5612 03	Spring (Inhibitor)	1	
8	39 2354 04	Bolt - Flange : M6	1	
9	DY 5614 00	Lever Gear Shift Assembly	1	
10	JH 5614 04	Damper	1	
11	DH 1015 09	Damper	1	




Engine Assembly / Crankcase RH

No.	Part No.	Description	Qty.	Remarks
1	36 PA02 10	Kit Assembly Crankcase RH	1	Refer Kit List
2	PF 5410 18	Bushing Drum	1	
3	KP BF62 01	Bearing ball C3 clearances	1	
4	KP BF62 03	Bearing ball C3 clearance Hn3	1	
5	JA 5410 10	Stopper plate input bearing	1	
6	JG 1312 20	Screw pan cross - M6	1	
7	52 JA00 29	Bolt shift change	1	
8	JA 5410 12	Guide Kick	1	
9	LA E000 15	Bolt flanged - M6	2	
10	KA ED06 85	Bolt	2	
11	JE 5410 28	Pin	1	
12	59 0400 38	Bolt Flange	1	
13	PF 5011 44	Engine Assembly (ES)	1	
	PF 5011 47	Engine Assembly (KS)	1	




Crankcase LH

No.	Part No.	Description	Qty.	Remarks
1	PF 5410 29	Crankcase assembly LH	1	
	PF 5410 42	Crankcase assembly LH (KS)	1	
2	KP BF62 03	Bearing ball C3 clearance - HN3	1	
3	39 1715 19	Seal - Oil	1	
4	39 2562 20	Bearing - Needle Roller	1	
5	JA 5410 05	Bush Bendix	1	
6	39 2190 19	Seal - Oil	1	
7	31 2010 81	Switch - Neutral	1	
8	DH 1017 84	Gasket Neutral Switch	1	
9	JH 5410 21	Bracket Gear Stopper	1	
10	JG 1312 20	Screw Pan Cross - M6	1	
11	39 0999 06	Pin - Hollow Dowel	4	
12	59 0400 38	Bolt flanged - M6 x 1 x L35	7	
13	JG 5710 24	Strainer assembly	1	
14	LJ A000 04	'O' ring-Strainer	1	
15	JA 5410 21	Cap Strainer	1	
16	59 2100 23	'O' ring	1	




Oil Pump

No.	Part No.	Description	Qty.	Remarks
1	JZ 5710 00	Assembly Oil Pump	1	
2	FD 1010 78	Screw Pan Cross :	3	
3	JA 5410 16	Gasket Case Oil Pump	1	
4	39 0999 06	Pin Dowel	2	
5	JZ 5710 01	Gear Oil Pump Driven	1	




Kick Starter Mechanism

No.	Part No.	Description	Qty.	Remarks
1	PF 6210 03	Kick Shaft	1	
2	JE 6210 04	Sleeve	1	
3	KE AB16 10	Circlip External - DIA 14.7 x THK1	1	
4	DS 1011 17	Spring Kick Starter Ratchet	1	
5	JA 6210 02	Ratchet	1	
6	39 0993 11	Washer Plain	2	
7	PA 6210 05	Gear Pinion Kick	1	
8	KE AB12 10	Circlip External - DIA 11.1 x THK1	1	
9	JE 6210 03	Spring Kick Return	1	
10	DU 1010 50	Assembly Kick Lever	1	
11	36 DU10 07	Kit Boss Kick Lever	1	Refer Kit List
12	30 1011 54	Damper	1	
13	JA 6212 06	Bolt Flange	1	
14	22 1502 41	Plain Washer	1	
15	JA 6210 06	Washer Thrust (16.2 x 25 x 0.5)	1	




Cover Clutch

No.	Part No.	Description	Qty.	Remarks
1	36 PF01 58	Kit Assly Clutch Cover	1	Refer Kit List
2	JV 5412 08	Shaft Clutch Release Assly	1	
3	PF 5412 55	Bracket Clutch Cable	1	
4	59 0400 38	Bolt - Flange : M6	8	
5	LA E000 05	Bolt	3	
6	PF 5412 50	Label Clutch Cover	1	
7	56 PF1X 67	Cap Filter	1	
7A	DP 1210 06	Ring - O	1	
8	DD 1211 81	Element Oil Filter	1	
9	PF 5514 07	Rod-Push	1	
10	39 1041 19	Seal - Oil	1	
11	DS 1012 15	Clip - Wire	1	
12	JL 5412 27	Window Oil Gauge	1	
13	JA 5412 25	O Ring Cap Oil Filler	1	
14	JA 5412 11	Cap Oil Filler	1	
15	JA 5412 12	Gasket Clutch Cover	1	
16	39 2443 11	Washer plain	1	
17	JE 5412 14	Spring Torsion Cl. Cover	1	
18	30 1011 42	Seal - Oil (Kick Shaft)	1	




Cover Magneto

No.	Part No.	Description	Qty.	Remarks
1	52 PF21 05	Cover Assembly Magneto (ES)	1	
	52 PF21 29	Assly Cover Magneto (KS)	1	
2	59 0400 38	Bolt flanged - M6 x 1 x L35	7	
3	PF 5412 49	Label Mag Cover	1	
4	39 0999 06	Dowel	2	
5	JA 5410 05	Bush Bendix	1	
6	JB 5412 24	Gasket Magneto Cover	1	
	JP 5412 08	Gasket Magneto Cover (KS)	1	
7	PF 5413 08	Cover assembly rear LH	1	
	PF 5413 11	Cover assembly rear LH (KS)	1	
8	PF 5412 51	Label gear shift all down 4 speed	1	



Clutch Assembly


No.	Part No.	Description	Qty.	Remarks
1	PF 5514 30	Assembly Clutch	1	
	PF 5514 52	Assembly Clutch	1	Make-Makino
2	JA 5514 06	Collar Clutch	1	
3	36 JZ01 84	Kit Primary Drive & Driven	1	Refer Kit List
	36 DY00 44	Kit Primary Drive & Driven	1	Make-Makino
3A	JG 5514 28	Washer - Plain	2	
4	PF 5514 36	Wheel Clutch	1	
	YD Y040 05	Wheel Clutch	1	Make-Makino
5	36 JZ01 99	Kit Cutch Plate	3	Refer Kit List
	36 DY00 28	Kit Cutch Plate	3	Make-Makino
6	36 JZ01 98	Kit Friction Plate	1	Refer Kit List
	36 PF00 86	Kit Friction Plate	1	Make-Makino
7	PF 5514 33	Hub Clutch	1	
	YD Y040 03	Hub Clutch	1	Make-Makino
8	PF 5514 38	Holder	1	
	YD Y040 04	Holder	1	Make-Makino
9	PF 5514 37	Compression Spring	4	
	YD Y040 01	Compression Spring	4	Make-Makino
10	KA DD06 25	Bolt	4	
	PF 5514 22	Bolt	4	Make-Makino
12	JA 5514 20	Washer Plain	1	
13	39 1001 20	Bearing - Ball	1	
14	52 JA00 28	Nut round - M14	1	LH threading
15	JE 5514 09	Washer Belleville	1	



 Front Wheel Direction


Carburetor Assembly

No.	Part No.	Description	Qty	Remarks
1	PF 5812 73	Carburetor	1	
2	36 PF01 73	Piston Valve Assly	1	
3	36 PF01 66	Pilot Screw Kit	1	
4	36 PF01 67	Idling Adjuster Kit	1	
5	36 PF01 74	Jet Kit	1	
6	36 PF01 69	Float Body Assly	1	
7	36 PF01 70	Top Cap Assly	1	
8	36 PF01 71	O Ring & Gasket Kit	1	
9	36 PF01 72	Starter Kit	1	
10	36 PF01 78	Air Controlled Solenoid Assembly	1	
11	DH 1211 62	Float Assembly	1	
12	DP 1210 65	Drain Hose	1	
13	JE 5812 25	'O' Ring TPS	1	
14	JE 5812 20	Screw TPS	1	
15	DH 1210 64	Screw Float Pin	2	
16	JE 5812 18	Drain Screw	1	
17	JB 3518 00	TPS	1	
18	PF 5813 30	O Ring	1	




Air Cleaner Complete

No.	Part No.	Description	Qty.	Remarks
1	PF 5811 50	Filter Assembly Air	1	
2	JL 1810 26	Clip Nut	2	
3	DY 5810 05	Spacer Battery 3A	1	
4	PF 5811 35	Air Filter Element	1	
5	DU 1210 52	Ring Seal Air Filter Cover	1	
6	DP 1210 25	Clamp	2	
	JP 1710 63	Clamp	2	From July. 2021
7	DM 2210 01	Band - Tool kit	1	
8	DG 1210 40	Clamp	2	
9	DG 1611 21	Screw	1	
10	39 1789 24	Washer (Nylon)	1	
11	DS 1211 26	Plug	1	
12	DY 4018 01	Pad battery	2	
13	DY 5810 10	Tube drain	1	
14	DY 5810 09	Tube Breather	1	
	PF 5811 98	Tube Breather	1	From July. 2021
15	DY 5810 02	Cover air filter	1	
16	LB U000 07	Screw	6	
17	DH 1021 18	Clamp	1	
18	DF 1614 26	Bolt stepped with flange	1	
19	DG 1910 64	Nut Flanged - M6	1	
20	JP 5810 18	Tube Drain	1	
21	DP 1210 18	Clamp	1	
	JL 5810 66	Clamp	1	From July. 2021
22	LD B000 68	Washer Plain	1	
23	KA DA06 10	Bolt Flanged	1	
24	DU 1613 11	Bracket Box Fuse	1	
25	DU 1210 85	Foam Breather	1	From July. 2021
26	DU 1210 84	Plate Breather	1	From July. 2021
27	KB RA48 13	Screw Plate Mounting	1	From July. 2021




EVAP Mechanism

No.	Part No.	Description	Qty.	Remarks
1	JY 1710 77	Canister	1	
2	JY 1710 70	Spring Band Clamp 9 x 8.4	3	
3	DH 1410 70	Tube T Connector To Canister	1	
4	GL 1710 36	Conn. For Breather & Vapor Tube	1	
5	DU 1412 77	Tube Tank To T Connector	1	
6	DH 1410 75	Tube Drain	1	
7	JG 1710 29	Spring Band Clamp 11.5 x 8.4	3	
8	JY 1718 25	Plug Fuel Drain	1	
9	JY 1710 69	Spring Band Clamp 15 x 10	1	
10	DU 1412 78	Tube Inline Connector	1	
11	JH 1710 48	Grommet Purge Valve	1	
12	PD 1716 16	Valve Purge	1	
13	DU 1413 25	Tube Purge Valve To Carburetor	1	
14	DU 1412 72	Tube Canister Drain	1	
15	JZ 1710 55	Strap Canister	2	
16	JL 1711 01	Clamp band spring 9.5 x 8.4	3	
17	JL 1711 02	Clamp band spring 12.5 x 8	1	




Silencer Assembly

No.	Part No.	Description	Qty.	Remarks
1	PF 5914 86	Silencer Assembly	1	
2	JE 5912 80	Gasket exhaust	1	
3	39 2295 15	Nut flanged - EX tube	2	
4	JB 5910 98	Sensor Oxygen	1	
5	PF 5915 07	Shield Catalyst	1	
6	JL 5911 49	Truss Screw (Head Black)	2	
7	PF 5914 65	Shield Muffler	1	
8	JW 5910 28	Truss Screw M5 x 0.8	2	
9	JB 5910 68	Washer Nylon Shield Silencer	2	
10	DD 1013 66	Flanged Bolt	1	



Starter Assembly - For ES Only


No.	Part No.	Description	Qty.	Remarks
1	JH 6214 07	Gear drive starter clutch	1	
2	PF 6214 13	Assembly Gear Starter	1	
3	JH 3516 02	Motor assembly starter	1	
4	KA ED06 25	Bolt Flange St Motor Mtg	2	
5	36 DK00 77	Kit Starter Clutch Spring	1	
6	36 DK00 76	Body Complete Starter Clutch	1	
7	DK 1016 05	Plate Roller Clutch (SS 304)	1	
8	59 1000 02	Spring dowel sleeve	11	
9	LD F000 01	Washer toothed	3	
10	39 0972 04	Bolt Socket	3	



 Front Wheel Direction


Magneto, H.T. Coil & ECU EMS Assembly

No.	Part No.	Description	Qty.	Remarks
1	JB 3510 34	Rotor assembly W/o Clutch (ES)	1	Or
	PF 3510 85	Rotor assembly W/o Clutch (KS)	1	
2	JB 3510 29	Stator assembly (ES)	1	
	JE 3510 05	Stator assembly (KS)	1	
3	PF 3514 26	ECU EMS Assembly	1	
4	DH 2011 58	Regulator - DC	1	
	JZ 4020 02	Regulator Assembly (KS)	1	
5	LA C000 52	Bolt Socket	2	
	JE 5410 42	Bolt Socket (KS)	2	
6	PF 5412 42	Bracket Stator Harness	1	
	JA 5410 28	Lock plate (KS)	1	
8	KB BC06 08	Screw pan cross - M6	1	
9	DY 3512 01	Coil HT with cable	1	
10	DD 1110 12	Grommet HT coil	2	
11	DD 1110 48	Spark Plug Cap	1	
12	DD 1110 11	Grommet Spark Plug Cap	1	Or
13	KA ED06 25	Bolt Flanged	4	
14	CF 1110 19	Plug - Spark BOSCH :	2	
	DD 1110 18	Plug - Spark Champion	2	
15	KA ED06 18	Bolt Flanged Small	1	
16	PF 3512 47	Coil assembly ignition RH	1	
17	DH 1110 15	Cap spark plug	1	
18	JD 3512 06	Grommet sleeve spark plug cap	1	
19	DH 1110 13	Grommet spark plug	1	
20	KA ED06 12	Bolt Flanged Small	1	
	KA EM06 10	Bolt Flanged Small	1	
21	JY 1813 14	Rubber Band	1	




Seat Assembly & Mounting

No.	Part No.	Description	Qty.	Remarks
1	DU 2110 04	Seat assly comp. with Damper	1	
2	DP 2110 09	Damper	9	
3	39 1211 11	Washer plain	2	
4	39 1290 04	Screw - M6	2	
5	DU 1410 14	Seat Lab	1	
6	FD 2110 06	Grommet seat	2	
7	FD 2110 07	Spacer seat	2	




Engine Mountings

No.	Part No.	Description	Qty.	Remarks
1	DM 1611 92	Bracket Engine Hanger LH	1	
2	DM 1611 93	Bracket Engine Hanger RH	1	
3	KA DD08 55	Bolt Flanged	2	
4	KA DD08 65	Bolt Flanged	1	
5	KC GD08 08	Nut Hex Flanged	6	
6	39 2702 04	Hex. Bolt	2	
7	DU 1614 62	Bracket Engine Mtg. Front	1	
8	KA DD08 85	Bolt Flanged	1	
9	KA DD08 80	Bolt Flanged	3	
10	LC L000 01	Nut Hex Flange - M10	2	
11	DU 1614 63	Bracket Belly Pan	1	
12	KA CA06 12	Bolt Master KAC	3	
13	KD AA06 11	Washer Plain Small	3	
14	KA DD08 35	Bolt Flanged	2	
15	DU 1614 44	Belly Pan	1	




Frame & Frame Fittings

No.	Part No.	Description	Qty.	Remarks
1	PF 1610 29	Lever distributor LH	1	Refer Kit List
2	PF 1610 30	Lever distributor RH	1	
3	PF 1138 01	Collar	2	
4	DU 1510 58	Spring	1	
5	KD AB06 11	Washer plain small	1	
6	LE A000 03	Circlip external 6 x 0.7	1	
7	PF 1610 31	Cover unit distributor LH	1	
8	PF 1610 32	Cover unit distributor RH	1	
9	PF 1610 33	Grommet	2	
10	DU 1613 07	Frame assembly	1	
11	LA E000 48	Bolt flange - M6	1	
12	AL 2414 81	Screw stepped M6 x 1 x 11	2	
13	DF 1810 90	Nut	1	
14	DH 1810 14	Cap Steering	1	
15	36 DS18 02	Bearing cone kit	1	
16	DJ 1811 15	Cage Bearing with Steel Ball	2	
17	DU 1611 96	Tape Frame	1	
18	DU 1610 24	Plug	2	
19	DU 1613 91	Hook	1	




Swing Arm / Rear Shock Absorber

No.	Part No.	Description	Qty.	Remarks
1	39 2366 15	Domed Cap Nut	2	
1A	39 0712 15	Domed Cap Nut	1	
2	KD DB12 21	Washer spring thin (Top Mtg.)	2	
3	KD DB10 18	Washer spring thin (Bottom Mtg.)	2	
4	39 0714 11	Washer plain (Top Mtg.)	4	
4A	DG 1810 53	Washer	4	
5	DU 1710 37	Rear Shockabsorber	2	
6	39 0248 11	Plain Washer	2	
7	31 1710 06	Shaft Swing Arm	1	
8	39 0201 11	Plain Washer	2	
9	30 1710 18	Bushing Rubber	2	
10	LC L000 01	Nut hex flange - M10	1	
11	DU 1710 43	Arm Assembly Swing	1	
12	JK 1220 04	Adjuster Assy. Chain - RH	1	
13	39 1309 11	Washer Plain	2	
14	LC A000 11	Nut hexagon - M6 x 1 x A/F 13	2	
14A	39 2122 15	Hex Nut	2	
15	JK 1220 02	Adjuster Assy. Chain - LH	1	
16	31 1710 12	Damper for Swing arm	1	
17	39 0454 11	Plain washer	2	
18	KB RB35 13	Screw tapping pan cross	2	
19	DM 1710 22	Spacer	1	
20	39 1493 15	Nut hexagon - M12 x 1.25	1	




Foot Rest - Rider / Pillion

No.	Part No.	Description	Qty.	Remarks
1	DU 2210 21	Holder assembly step rider	1	
2	DF 1614 13	Rubber Main Step	2	
3	KA DD08 35	Hexagon bolt with flange	4	
4	DU 1612 67	Stay pillion LH	1	
5	DU 1613 72	Holder step pillion RH	1	
6	KA DG08 25	Bolt flange - M8	2	
	LA D001 48	Bolt Flange - M8 x 1.25 x L35 (KS)	2	
7	DG 1612 24	Damper	1	
8	KH AA25 20	Pin cotter	2	
9	DP 1611 70	Step Pillion	2	
10	JK 1130 08	Rubber Pillion	2	
11	DP 1611 63	Washer For Pillion Foot Rest	2	
12	30 1710 22	Pin For Pillion Foot Rest	2	
13	DD 1610 78	Damper	1	




Mudguard - Front & Rear

No.	Part No.	Description	Qty.	Remarks
1	KA DD08 18	Bolt flanged	4	
2	DU 1613 73	Guide cable	1	
3	DU 1610 98	Brace	1	
4	DU 1610 08	Fender Rear	1	
5	DU 1613 64	Fender Rear Front	1	
6	39 1309 11	Plain Washer	4	
7	LC L000 02	Hex. Nut Flanged	4	
8	DD 1610 51	Flap	1	
9	KA DA06 14	Bolt flanged	4	
10	DD 1610 13	Grommet	1	
11	KC GA05 05	Nut	1	
12	DD 2010 02	Reflector Reflex	1	
13	CZ 1814 07	Plug	1	
14	DU 1610 65	Nut clip - M6	2	
15	DU 1613 94	Brace Assembly	1	
16	JB 4010 12	Foam Tail Lamp	4	
17	DU 1613 46	Plug	1	
18	PF 1814 43	Bracket ECU	1	




Stand Assembly

No.	Part No.	Description	Qty.	Remarks
1	DY 1132 00	Stand Side	1	
2	LC H000 01	Nut nyloc - M10	1	
3	DF 1611 02	Bolt	1	
4	DH 1610 66	Spring Side Stand	1	
5	30 1611 58	Spring	1	
6	30 1611 57	Shaft Center Stand	1	
7	DU 1610 32	Center Stand	1	
8	KH AA32 25	Pin cotter	1	
9	DG 1611 24	Damper Center Stand	1	




Tube / Tyre / Rim

No.	Part No.	Description	Qty.	Remarks
1	56 JZ60 7B	Wheel Front Drum - 1.4 x 17	1	
2	DS 1510 49	Tube front - 2.75 x 17	1	
3	JV 1310 24	Tyre 2.75 X 17 semi knobby	1	Not Serviceable
4	56 DU61 33	Wheel Rear 1.85 x 17 Drum (DU151078) Black	1	(Dia 110 mm)
5	DS 1510 53	Tube rear 3 X 17	1	Not Serviceable
6	JV 1312 40	Tyre rear - 3.00 x 17 semi knobby	1	Not Serviceable




Front Hub

No.	Part No.	Description	Qty.	Remarks
1	JK 1310 15	Axle Front	1	
2	DU 1510 44	Lever panel brake front	1	
3	39 0775 04	Bolt	1	
4	LC L000 02	Nut flanged - M6	1	
5	DD 1510 09	Wear Indicator	1	
6	PF 1316 16	Panel Front Brake	1	
7	30 1510 38	O Ring	1	
8	30 1510 04	Cam Brake	2	
9	30 1511 05	Set Shoe Brake	2	
10	30 1510 69	Spring	2	
11	KP BB63 01	Bearing-Ball-C3 Clearance	2	
12	30 1510 32	Collar bearing	1	
13	30 1510 33	Seal - Oil	1	
14	KD AA12 22	Washer plain small	1	
15	59 1500 03	Nut U - M12	1	
16	36 DS15 02	Kit Speedometer Gear	1	
17	39 0242 11	Washer A	2	
18	JA 1316 06	Bushing	1	
19	30 1511 18	Stopper For Bushing	1	
20	39 1013 21	O Ring	1	
21	39 0900 12	Washer Spring	1	
22	KB BA04 08	Screw Pan Cross	1	
23	PA 1310 03	Seal oil	1	
24	DZ 1510 32	Collar assembly	1	



Rear Hub


No.	Part No.	Description	Qty.	Remarks
1	DX 1510 81	Drive Chain Lock	1	
2	36 DU41 44	Kit Chain Sprocket	1	
3	KP BB63 01	Bearing ball - C3 Clearance	1	
4	KP BB62 01	Bearing ball - C3 Clearance	1	
5	31 1510 18	Collar Bearing	1	
6	31 1510 21	Damper	4	
7	DU 1510 10	Coupling	1	
8	KP BC60 04	Ball Bearing	1	
9	56 JK8N 7B	Panel Rear Brake	1	
10	LA A000 34	Bolt D - M10 x 1.25 x L36	4	
11	DU 1510 29	Axle :- M12 x 1.25	1	
12	39 0794 15	Nut Hex Thin - M10 x 1.25	4	
13	31 1510 60	Shoe Brake	2	For 110 Dia Drum
14	30 1510 69	Spring	2	
15	JB 1312 23	Cam brake assly.	1	
16	30 1510 38	'O' Ring	1	
17	30 1510 05	Wear Indicator	1	
18	DU 1510 46	Lever Panel Brake Rear	1	
19	39 1074 04	Hex Bolt with Flange	1	
20	LC L000 02	Flange Nut	1	
21	KC BA18 11	Nut Hex Thin - M18 x 1.5	1	
22	KD AA12 22	Washer Plain Small	1	
23	59 1500 03	Nut U - M12	1	
24	31 1510 26	Collar	1	
25	31 1510 28	Sleeve	1	
26	DU 1510 06	Collar	1	
27	31 1510 29	Washer	2	



 Front Wheel Direction


Rear Brake Pedal

No.	Part No.	Description	Qty.	Remarks
1	DF 1510 16	Rod Torque	1	
2	YD U220 04	Rod End	1	
3	KD DB10 18	Washer spring thin	2	
4	YD U220 03	Adjuster Nut - Long	1	
5	JW 1710 14	Grommet	1	
6	KH BA08 28	Pin snap	2	
7	30 1510 95	Bolt	2	
8	39 0794 15	Nut Hex Thin - M10 x 1.25	2	
9	JA 1610 03	Pad brake lever	1	
10	DU 1510 47	Assembly pedal brake	1	
11	LE A000 03	Circlip external 6 x 0.7	2	
12	LD B000 75	Washer plain	1	
13	DU 1510 61	Grommet	1	
14	LD A000 18	Washer - 6.2 x 20 x 1.5	--	
15	DU 1613 26	Cover link CBS	1	
16	LA A000 49	Bolt - M6	1	
17	JH 1610 38	Collar	1	
18	30 1910 38	Pin	1	
19	39 0198 11	Washer plain	1	
20	KH AA20 18	Pin cotter	1	
21	DY 1610 03	Rod brake	1	
22	JD 1610 02	Spring brake pedal	1	
23	JD 1610 06	Sleeve brake return spring	1	
24	LD A000 69	Plain Washer	2	
	39 0199 11	Plain Washer (KS)	2	
25	30 1910 35	Spring	1	
26	JC 1910 06	Pin brake rear	1	
27	JH 1610 35	Assembly force distribution	1	
28	39 1944 04	Bolt flanged	1	
29	JW 1710 15	Collar central spoiler	1	




Handle Bar Assly

No.	Part No.	Description	Qty.	Remarks
1	DU 1811 55	Handlebar	1	
2	DU 1811 70	Holder Handle Upper	2	
3	KA ED08 30	Bolt Flanged Small	4	
4	PF 4014 17	Control Switch RH	1	
	DU 1910 56	Control Switch RH (KS)	1	
5	JB 4014 00	Control Switch LH	1	
6	PF 1610 15	Lever Clutch	1	
7	PF 1610 05	Hand Grip LH	1	
8	DD 1911 42	Lever grip - Right	1	
9	DD 2011 70	Front brake switch	1	
10	PF 1610 07	Grip Assembly RH	1	
10A	PF 1610 13	Throttle Pipe	1	
11	DS 1910 52	Lever boot LH	1	
12	DS 1910 18	Lever boot RH	1	
13	56 DU6A Y9	Holder Handle Lower	2	
	56 DU9U Y9	Holder Handle Lower	2	
14	DF 1810 91	Damper Handle Upper	2	
15	DF 1810 92	Damper Handle Lower	2	
16	FD 1810 19	Washer Plain Upper	2	
17	FD 1810 20	Washer Plain Lower	2	
18	LC H000 01	Nut nyloc - M10	2	
19	PF 1610 10	Holder lever LH	1	
20	JZ 1610 28	Lever Pivot Bolt	2	




Handle Bar Assy

No.	Part No.	Description	Qty.	Remarks
21	39 1184 15	Nut	2	
22	56 DU9T Y9	Holder Fork Upper	1	
23	PF 1610 11	Assembly Lever Holder RH	1	
24	PF 1610 09	Assembly Lever Holder LH	1	
	PF 1610 16	Assembly Lever LH (KS)	1	
25	JZ 4014 03	Switch Clutch (VB) Diode	1	
26	LB U000 12	Screw (Clutch switch mtg.)	2	
27	PF 1610 12	Holder Lever RH	1	
28	KA DT06 25	Bolt flanged - M6	2	



Front Fork

No.	Part No.	Description	Qty.	Remarks
1	DU 1811 41	Fork front	1	
2	YD U220 01	LH Outer Tube Endurance	1	
3	YD U220 02	RH Outer Tube Endurance	1	
4	KA CF08 30	Bolt Socket Head	2	
5	30 1810 26	Gasket	2	
6	DD 1810 32	Seal Dust	2	
7	DU 1811 08	Seal Oil (SFN)	2	
8	31 1811 08	Ring -Snap: Endu Sys	2	
9	JK 1210 08	Spacer Tube	2	
10	DM 1810 36	Pipe complete - suspension - Inner	2	
11	DE 1810 31	Spring Main	2	
12	30 1810 29	'O' Ring	2	
13	DF 1810 85	Bolt Fork	2	
14	59 0400 06	Bolt	2	
15	DD 1812 07	Fork Under Bracket	1	
16	KD DB10 18	Washer spring thin	2	
17	KA AD10 35	Bolt	2	
18	FD 1810 12	Nut cap special	1	
19	DF 1810 89	Washer - Plain	1	
20	DD 1812 05	Holder Fork Upper	1	
	56 DU9T Y9	Holder Fork Upper Black	1	




Front Fork

No.	Part No.	Description	Qty.	Remarks
21	KA DD06 14	Bolt Ignition Switch Mounting	2	
22	DU 1811 56	Set lock	1	
23	DU 1811 42	Leg assembly LH	1	
24	DU 1811 43	Leg assembly RH	1	
25	PA 1210 41	Seat Pipe	2	
26	30 1810 20	Piston Ring	2	
27	31 1810 19	Cap Oil Lock	2	
28	31 1810 99	Rebound Spring	2	
29	PA 2335 09	Decal anti skid	2	
	JK 2331 57	Decal Anti Skid	2	
30	PF 1210 54	Clamp for bellow	2	
31	DU 1811 44	Bellow fork front	2	
32	36 PA01 21	Kit cylinder complete fork	1	
33	JZ 4010 77	Reflector Reflex	1	
34	DM 1810 10	Washer	2	




No.	Part No.	Description	Qty.	Remarks
1	DU 1811 11	Cap fuel tank EVAP	1	
2	LB B000 06	Screw pan cross - M5	2	
3	LD A000 43	Washer	2	
4	DU 1410 95	Fuel cock assy	1	
5	DD 1412 27	Bolt Flanged	2	
6	39 0740 11	Washer Non Metalic	2	
7	33 1410 08	Clamp Tube	2	
8	PF 1718 03	Pipe fuel - E10 (L185)	1	
9	DU 1811 56	Set Lock	1	
10	DU 1413 01	Bush Vapour	1	
11	DY 4026 00	Gauge Fuel	1	
12	JH 1710 17	O Ring Fuel Gauge	1	
13	KC GA05 05	Nut hex flanged	4	
14	DZ 1410 75	4 Hole washer	1	
15	YD Y070 04	O Ring Fuel cock bowl	1	




Fittings - Petrol Tank, Side Covers & Seat Cowl

No.	Part No.	Description	Qty.	Remarks
1	DF 1411 28	Damper Fuel Tank Mounting	2	
2	KA DD06 25	Bolt flanged	2	
3	DP 2010 37	Collar Assly.	2	
4	DG 1410 19	Damper	2	
5	DU 1611 02	Damper	1	
6	39 1789 24	Washer Nylon	1	
7	DG 1611 21	Screw	1	
8	DU 1811 56	Set Lock	1	
9	DD 1610 22	Damper	2	
10	DH 1611 58	Grommet	2	
11	DU 1611 19	Screw Stepped	4	
12	DU 1413 15	Pad assembly tank LH	1	
13	DU 1413 16	Pad assembly tank RH	1	




Speedometer Assembly

No.	Part No.	Description	Qty.	Remarks
1	DU 1910 70	Speedometer	1	
2	YD U250 01	Housing - Minda	1	Make - Minda
	YD U250 05	Housing - Pricol	1	Make - Pricol
3	CM 2010 54	Lamp 12V 2W	5	
4	YD U250 02	Wiring Harness	1	Make - Minda
	YD U250 06	Wiring Harness	1	Make - Pricol
5	YD U250 03	Fuel Machine with Mtg. Hardware	1	Make - Minda
	YD U250 07	Fuel Machine with Mtg. Hardware	1	Make - Pricol
6	YD U250 04	Dial	1	Make - Minda
	YD U250 08	Dial	1	Make - Pricol
7	YD U160 04	Speedo Machine	1	Make - Minda
	YD U160 08	Speedo Machine	1	Make - Pricol
8	DU 1910 29	Bracket Speedo Mtg.	1	Make - Pricol
9	LC L000 02	Nut flanged - M6	2	
10	YD U100 03	Speedo Meter Back Cover	1	Make - Minda
	DU 1910 23	Speedo Meter Black Cover	1	Make - Pricol
11	YD U100 02	Speedometer Top Cover with Sealing Rings	1	Make - Minda
	YD U100 07	Speedometer Top Cover with Sealing Rings	1	Make - Pricol




Control Cables

No.	Part No.	Description	Qty.	Remarks
1	PF 1612 34	Cable brake front	1	
2	DM 1910 25	Cable Clutch	1	
3	PA 1612 17	Cable speedometer	1	
4	PF 1612 31	Cable Throttle	1	
5	DU 1510 56	Cable unit distributor - Front panel	1	
6	DU 1910 77	Cable pedal - unit distributor	1	N.I.
7	KA DC05 18	Bolt Flanged	1	
8	YD U220 06	Spring	1	
9	YD U220 05	Grommet	1	
10	YD U220 04	Rod End	1	
11	YD U220 03	Adjuster Nut - Long	1	
12	JD 4022 12	Band	1	
13	PA 1318 67	Clip Separator	1	




Chain Case

No.	Part No.	Description	Qty.	Remarks
1	52 DU17 53	Chain case Uppe & Lower	1	
2	30 1612 71	Rubber Pad	1	
3	DF 1614 15	Trim case chain	1	
4	DF 1614 16	Rubber Cap	1	
5	DH 1612 83	Bolt Flanged	4	



Head Lamp & Fairing - For ES Only


No.	Part No.	Description	Qty.	Remarks
1	DU 2011 08	Head Light Assy Without Bulb	1	
	DU 2011 01	Head Light Assy With Bulb	1	
2	CL 2010 23	Lamp 12V-35/35W	1	
3	JK 4010 25	Lamp Assembly - DRL	1	
4	KB RA42 16	Screw Tapping Pan Cross	8	
5	DU 1614 12	Flap Speedometer	1	
6	DU 1811 74	Structure Flap Speedometer	1	
7	DD 1811 86	Collar	2	
8	JW 1710 16	Round head screw	2	
9	JG 1710 31	Clip Nut M5	5	
10	DF 1810 98	M5 x 14L SS Bolts	5	
11	39 2141 24	Washer, Nylon, 5.3 x 11.5 x 1.5	5	
12	KA DD06 14	Hex. Bolt / Flange	3	
13	DU 1811 59	Bracket Assembly Fairing Lower	1	
14	DU 1613 77	Bracket Cowling Lower	1	
15	DU 1811 57	Bracket Front No. Plate HSRP	1	
16	KA CA06 14	Bolt master KAC	2	
17	KD AA06 11	Washer plain small	2	
18	KB BA06 16	Screw pan cross	2	
19	JN 1810 31	Foam fairing	3	
20	PF 1812 46	Foam Tape	1	



 Front Wheel Direction


Head Lamp & Fairing - For KS Only

No.	Part No.	Description	Qty.	Remarks
1	DU 2011 08	Head Light Assy Without Bulb	1	
	DU 2011 01	Head Light Assy With Bulb	1	
2	CL 2010 23	Lamp 12V-35/35W	1	
3	DU 1810 70	Flap Cowling	1	
4	DL 1810 10	Nut Well	4	
5	DF 1810 98	Screw SS	5	
6	39 2141 24	Washer (Non metallic)	9	
7	35 1610 60	Clip Nut	5	
8	DU 1613 77	Bracket Cowling Lower	1	
9	DU 1811 59	Bracket Assembly Fairing Lower	1	
10	KD AA06 11	Washer plain small	2	
11	KA CA06 14	Bolt master KAC	2	
12	KB BA06 16	Screw pan cross	2	
13	KA DD06 14	Hex. Bolt / Flange	2	
14	DU 1810 47	Bracket Cowling Upper	1	
15	DD 1811 86	Collar	2	
16	JW 1710 16	Round head screw	2	
17	39 0813 02	Cross Rec. Pan Hd. Tp Screw	4	
18	DU 1810 31	Wind Shield - Label bajaj	1	
19	DF 1810 98	Bolts - M5 x 14L	4	
20	DD 1812 52	Label "BAJAJ"	1	
21	JN 1810 31	Foam fairing	2	
22	DU 1811 57	Bracket Front No. Plate HSRP	1	




Indicator Light Assembly

No.	Part No.	Description	Qty.	Remarks
1	DJ 2012 07	Blinker front LH with 2P coupler	1	
2	GH 2010 12	Lamp 12V-10W	4	
3	DJ 2012 06	Blinker front RH with 2P coupler	1	
4	LC L000 01	Nut hex flanged - M10	4	
5	DJ 2012 06	blinker RR LH with 2P coupler	1	
6	DJ 2012 07	blinker RR RH with 2P coupler	1	
7	DU 1811 75	Bracket Signal Mounting Front (ES)	1	
	DD 1811 92	Structure Indicator Front (KS)	1	




Tail Lamp Assly / Number Plate

No.	Part No.	Description	Qty.	Remarks
1	DU 2010 23	Tail light assembly with bulb	1	
	DU 2010 24	Tail light assembly without bulb	1	
2	KC GA06 06	Hex Nut / Flange	3	
3	31 2010 01	Collar	3	
4	31 2010 28	Lamp 12 V, 10/5W	1	
5	DD 2010 11	Damper	3	
6	LD B000 15	Plain Washer	3	
7	KC GA05 05	Nut Hex Flanged	1	
8	DD 2010 02	Reflector Reflex	1	
9	DU 1613 84	Bracket plate number rear	1	
10	KC GA06 06	Nut hex flanged	2	
11	DU 1610 65	Nut clip - M6	2	




Electrical Equipments

No.	Part No.	Description	Qty.	Remarks
1	KA DD08 14	Flanged Bolt	1	
2	DZ 2010 38	Horn	1	
3	31 2010 79	Switch Rear Brake	1	
4	DY 4014 00	Spring rear brake switch	1	
5	DU 2011 56	Harness wiring	1	
	DU 2011 58	Harness wiring (KS)	1	
6	PA 4018 10	Battery VRLA 3Ah	1	
7	DU 2011 47	Switch brake - spring	1	
8	AK 2010 12	Fuse 10A	2	
9	DS 2010 25	Assembly DC Flasher	1	
9A	JL 4020 04	Module Light Control (KS)	1	
10	JZ 4022 16	Cap (Starter Motor)	1	
11	JV 4022 04	Cable assly. Starter relay to motor	1	
12	JD 4022 17	Band	3	
13	DY 4022 02	Cable earth	1	
14	DY 1138 03	Clamp Battery	1	
15	60 1114 20	Cable Tie Lock	4	
16	JZ 4022 18	Cable Tie (White Color L200)	2	
17	KA DD06 14	Bolt flanged	1	
18	DK 2010 78	Starter Relay	1	
19	KA DF06 10	Bolt Flanged	1	
20	JL 4022 07	Fuse Box Assembly	1	
21	JD 4022 12	Band Length 200 mm	2	
22	AP 2010 25	FUSE 15A BLADE TYPE	2	



Tool Kit

No.	Part No.	Description	Qty.	Remarks
1	PA 2310 02	Tool Kit	1	
2	DM 2210 01	Band For Tool Kit	1	



Accessories / Grab Handle

No.	Part No.	Description	Qty.	Remarks
1	DU 2210 15	Guard Sari	1	
2	DS 2210 01	Plug	2	
3	DU 2210 41	Guard Leg LH	1	
	DU 2210 39	Guard Leg LH (KS)	1	
4	DU 2210 28	Mirror LH	1	
5	DU 2210 29	Mirror RH	1	
6	LA D001 43	Bolt flanged - M10	1	
7	KA DD08 45	Bolt Flanged	1	
	39 1814 04	Bolt flanged (KS)	1	
8	56 DU70 Y9	Grab Handle	1	
9	KA DD08 14	Bolt Flanged	4	
10	KC GD08 08	Nut Hex Flanged	1	
11	DU 2210 42	Guard Leg RH	1	
	DU 2210 40	Guard Leg RH (KS)	1	
12	KA DD08 12	Bolt	2	

Painted Parts and Decals



No.	Part No.	Description	Qty.	Remarks
1	52 DU14 52	Fuel Tank Black With Blue Decal	1	From Nov 20
	52 DU14 77	Fuel Tank FI Red W Red Dcl	1	
	52 DU14 96	Fuel Tank Mt Grn W Yellow Dcl	1	
	52 DU18 75	Fuel Tank Black With Red Decal	1	
2	52 DU12 57	Front Fender Painted (new) Jet black	1	
	52 DU12 58	Front Fender Painted Flame Red	1	
	52 DU14 98	Fender Front Matte Green	1	
3	52 DU16 51	Cowling Eb Black With Blue Decal	1	From Nov 20
	52 DU16 52	Cowling FI Red W Red Dcl	1	
	52 DU16 53	Cowling Mt Grn W Ylw Dcl	1	
	52 DU18 86	Cowling Eb Black With Red Decal	1	
4	52 DU14 48	Seat Cowl Eb Black With Blue Dcl	1	From Nov 20
	52 DU14 72	Seat Colw FI Red W Red Dcl	1	
	52 DU14 91	Seat Colw Mt Grn W Ylw Dcl	1	
	52 DU18 85	Seat Cowl Eb Black With Red Dcl	1	
5	52 DU14 49	Side Cvr LH Eb Black Wh Blue Dcl	1	From Nov 20
	52 DU14 73	Side Cover LH Red W Red Dcl	1	
	52 DU14 92	Side Cover LH Mt Grn W Ylw Dcl	1	
	52 DU18 77	Side Cvr LH Eb Black Wh Red Dcl	1	
6	52 DU14 50	Side Cvr RH Eb Black Wh Blu Dcl	1	From Nov 20
	52 DU14 74	Side Cover RH FI Red W Red Dcl	1	
	52 DU14 93	Side Cover RH Mt Grn W Ylw Dcl	1	
	52 DU18 78	Side Cvr RH Eb Black Wh Red Dcl	1	
7	DU 0101 56	Decal Cover Side LH E Black-Blue	1	
	DU 0101 66	Decal Cover Side LH E Black-Red	1	
	DU 0101 76	Decal Cover Side LH M G Yellow	1	
8	DU 0101 57	Decal Cover Side RH C Black-Blue	1	
	DU 0101 67	Decal Cover Side RH E Black-Red	1	
	DU 0101 77	Decal Cover Side RH M G Yellow	1	

Painted Parts and Decals



No.	Part No.	Description	Qty.	Remarks
9	36 DU41 45	Kit Fairing Decal Black-Blue	1	From Nov 20
	36 DU41 46	Kit Fairing Decal Red-Red	1	
	36 DU41 47	Kit Fairing Decal Matte G Yellow	1	
	36 DU41 38	Kit Fairing Decal Matte G yellow	1	
	36 DU41 82	Kit Fairing Decal Black Red	1	
10	36 DU41 28	Kit Tank Decal Black-Blue	1	From Nov 20
	36 DU41 32	Kit Tank Decal Red-Red	1	
	36 DU41 36	Kit Tank Decal Matte G Yellow	1	
	36 DU41 71	Kit Tank Decal Black-Red	1	
11	36 DU41 29	Kit Seat Cowl Decal Black-Blue	1	From Nov 20
	36 DU41 33	Kit Seat Cowl Decal Red-Red	1	
	36 DU41 37	Kit Seat Cowl Decal Matte G Yellow	1	
	36 DU41 81	Kit Seat Cowl Decal Black Red	1	
12	36 DU41 40	Kit Wheel Decal Blue	1	From Nov 20
	36 DU41 35	Kit Wheel Decal Red-Red	1	
	36 DU41 39	Kit Wheel Decal Matte G Yellow	1	
	36 DU41 35	Kit Wheel Decal Red	1	
13	36 DU41 35	Kit Decal Side Cover	1	From Nov 20

1		2		3	
4		5		6	
7		8		9	
10		11		12	



Consumable Parts

No.	Part No.	Description	Supply Unit	Application
1	83 0205 52 83 0205 54	Bajaj Genuine Oil 10W30 BS VI Bajaj Genuine Oil 10W30 BS VI	1 Ltr. 100 ML	Top up
2	36 0010 58	Bajaj Coolant Koolux*	1 Ltr.	Coolant Top-up/Replace
3	36 DH40 61	Brake Fluid DOT4	100 ml	Disc Brake Top-up/Replace
4	36 DH40 52	Silicon grease	3 gm	Caliper Pin
5	83 0204 73 36 DK00 45	Grease Petamo GHY 441 Grease Molycoat	3 gm 200 gm	Water Pump Seals For Starter Clutch Lubrication
6	36 JL01 81	Limaplex HTX 3 Grease	10 gm	Steering Race
7	83 0201 73	Multi Purpose Grease* (Local Purchase)	--	Lubrication of Clutch Lever, Brake Lever, Brake Pedal & Side Stand
8	36 0010 55	Chain Lubricant HP Make	1 kg	Non - Sealed Chain Lubrication
9	36 0010 62	Liquid gasket L5910	50 ml	Crankcase Joining
10	36 3140 04 36 JG00 87	Fork oil Fork oil 480 ml (Dominar UG)	160 ml 480 ml	Front Fork Top-up/Replace\ Front Fork Top-up/Replace\
11	36 DH40 29	Kit Spray Chain Lub	100 ml	Sealed Drive Chain
12	36 DH40 71	Wonderfill Chain Spray	100 ml	Sealed Drive Chain

* Marked items to be arrange from vendor or local market. Not applicable against chassis number.

13		14		15	
16		17		18	
19		20		21	
22		23		24	

Consumable Parts

No.	Part No.	Description	Supply Unit	Application
13	36 DH40 72	Rust Remover Spray Make - Zorric 88 & Wonder fill easiner	100 ml	For Removing Rust from Components
14	76 0109 36	Loctite Thread locker 243*	50 ml	For Screws & Bolts
15	76 0109 37	Loctite retaining compound 638*	50 ml	For Screws & Bolts
16	37 0043 52	Touch up paint slate grey*	440 ml	Touch up of Frame, Swing Arm & Step Holder
17	37 0043 53	Touch up paint Matte Silk black*	440 ml	Touch up of Grab Handle, Handle Bar & Handle Holder
18	36 0010 60	Kibatsu touch up paint*	400 cc	Touch up of Cylinder head, Block & Alloy Wheels
19	37 2240 18	Paint Bottle Schwartz Black*	--	P-200NS Frame Touch-up
20	75 6802 36 NA	Petroleum Jelly (Local Purchase) Distilled Water (Local Purchase)	-- 1 Ltr.	For Battery Terminals For Battery Level Top-up
21	NA	SAE 90 oil (Local Purchase)	--	
22	62 3050 84	WD40 Spray (Local Purchase)	400 ml	Electrical Contact Cleaning Spray
23	36 0010 56	Carburetor Cleaning Spray*	--	For Cleaning Carburetor/ Throttle Body
24	37 2540 39	Corrosion Protection Spray* Proto quick LTP902	--	For Preventing vehicle parts from rusting

* Marked items to be arrange from vendor or local market. Not applicable against chassis number.

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
1	36DU4076	Kit valve intake + exhaust	PF511212 PF511213	Valve intake Valve exhaust	1 1
2	36JV0006	Valve repair kit	28101129 CB101009 JA511202 DY511202 CB101022	Seat spring Seal valve stem Spring valve Retainer valve Cotter valve	2 2 2 2 4
3	36JZ0122	Kit guide cam chain	JE521025 JE541037	Guide tight side silent chain Guide slack side silent chain	1 1
4	36JK0064	Kit Cyl. block & piston	PF521224 PF521027	Piston assembly Block cylinder	1 1
5	36JK0065	Kit piston rings	PF521227 PF521228 PF521226	Ring piston second Ring piston oil Ring piston top	1 1 1
6	52PF2105	Assembly magneto Cover	56DU1W67 JA541005	Cover magneto Bush bendix	1 1
7	36PF0158	Kit Assly Clutch Cover	56JK1V67 31101064 BA102004 JE541245 JL541227 DS101215 PF541250	Silver Cover Slick Black Plug Plug Jet Oil Window Clip Wire Label clutch cover	1 1 1 1 1 1 1
8	36PA0210	Kit assly crankcase RH	JH541010 KPBF6203 KPBF6201 PF541018 BA102004	Crankcase RH Bearing-ball-C3 clearance Bearing-ball-C3 clearance Bushing drum BM150 4 Speed Plug	1 1 1 1 1

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
9	36JZ0184	Kit Pri Drive & Driven	PF551431 JZ531006	Clutch Hsg. Assly. Comp Gear Primary Drive	1 1
10	36JZ0198	Kit Friction - D102B&C	JH551402	Plate Clutch Friction	4
11	36JZ0199	Kit clutch plate	PF551435	Plate clutch	3
12	36DS1802	Bearing cone kit	DH181025 DH181023 DH181026	Bearing cone Bearing cone (fork) Bearing race	1 1 2
13	36DU4144	Kit Chain Sprocket	DU151086 JZ551004 DY141001	Sprocket Hub Sprocket Output Chain 108 Links	1 1 1
14	36PA0121	Kit Cyl. comp fork	31181019 PA121041 30181020 DM181008 DE181031	Cap oil lock Seat pipe Piston ring Rebound spring Spring - front fork from ESIPL	1 1 1 1 1
15	36DU1007	Kit Kick Boss Set	30101233 30101234 KMAA0800 22150241 30101235 KECB5006	Boss Spring Ball steel Washer - plain Pin Circlip type e	1 1 1 1 1 1
16	36DS1502	Kit Gear Meter	DL151014 30151041	Gear - Speedometer Gear Meter Screw	1 1
17	36DU4128	Kit tank decal black-blue	DU010154 DU010155	Decal tank LH ebony black-blue Decal tank RH ebony black-blue	1 1
18	36DU4129	Kit seat cowl decal black-blue	DU010158 DU010159	Decal cowl seat LH e black-blue Decal cowl seat RH e black-blue	1 1

GT 110 BS VI

109

GT 110 BS VI

110

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
22 1502 41	14	26	31 1510 29	27	64
30 1011 42	18	28	31 1510 60	13	64
30 1011 54	12	26	31 1710 06	7	52
30 1510 04	8	62	31 1710 12	16	52
30 1510 05	17	64	31 1810 19	27	74
30 1510 32	12	62	31 1810 99	28	74
30 1510 33	13	62	31 1811 08	8	72
30 1510 38	7	62	31 2010 01	3	92
30 1510 38	16	64	31 2010 28	4	92
30 1510 69	10	62	31 2010 79	3	94
30 1510 69	14	64	31 2010 81	7	22
30 1510 95	7	66	33 1410 08	7	76
30 1511 05	9	62	35 1610 60	7	88
30 1511 18	19	62	36 0010 55	8	104
30 1611 57	6	58	36 0010 56	23	106
30 1611 58	5	58	36 0010 58	2	104
30 1612 71	2	84	36 0010 60	18	106
30 1710 18	9	52	36 0010 62	9	104
30 1710 22	12	54	36 3140 04	10	104
30 1810 20	26	74	36 DH40 29	11	104
30 1810 26	5	72	36 DH40 52	4	104
30 1810 29	12	72	36 DH40 61	3	104
30 1910 35	25	66	36 DH40 71	12	104
30 1910 38	18	66	36 DH40 72	13	106
31 1011 73	6	12	36 DK00 45	5	104
31 1510 18	5	64	36 DK00 76	6	42
31 1510 21	6	64	36 DK00 77	5	42
31 1510 26	24	64	36 DS15 02	16	62
31 1510 28	25	64	36 DS18 02	15	50

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
36 DU10 07	11	26	36 PF01 67	4	34
36 DU40 76	1	6	36 PF01 69	6	34
36 DU41 28	10	102	36 PF01 70	7	34
36 DU41 29	11	102	36 PF01 71	8	34
36 DU41 32	10	102	36 PF01 72	9	34
36 DU41 33	11	102	36 PF01 73	2	34
36 DU41 35	12	102	36 PF01 74	5	34
36 DU41 36	10	102	37 0043 52	16	106
36 DU41 37	11	102	37 0043 53	17	106
36 DU41 38	9	102	37 2240 18	19	106
36 DU41 39	12	102	37 2540 39	24	106
36 DU41 40	12	102	39 0198 11	19	66
36 DU41 44	2	64	39 0199 11	24	66
36 DU41 45	9	102	39 0201 11	8	52
36 DU41 46	9	102	39 0242 11	17	62
36 DU41 47	9	102	39 0248 11	6	52
36 JG00 87	10	104	39 0454 11	17	52
36 JK00 64	1	10	39 0712 15	1A	52
36 JK00 65	5	10	39 0714 11	4	52
36 JL01 81	6	104	39 0740 11	6	76
36 JV00 06	2	6	39 0775 04	3	62
36 JZ01 22	9	8	39 0794 15	12	64
36 JZ01 84	3	32	39 0794 15	8	66
36 JZ01 98	6	32	39 0813 02	17	88
36 JZ01 99	5	32	39 0900 12	21	62
36 PA01 21	32	74	39 0972 04	10	42
36 PA02 10	1	20	39 0987 17	4	14
36 PF01 58	1	28	39 0992 06	7	16
36 PF01 66	3	34	39 0993 11	6	26

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
39 0999 06	11	22	39 2443 11	16	28
39 0999 06	4	24	39 2562 20	4	22
39 0999 06	4	30	39 2608 01	11	4
39 1000 06	2	10	39 2669 21	14	8
39 1001 20	13	32	39 2671 04	7	10
39 1013 21	20	62	39 2702 04	6	48
39 1041 19	10	28	52 DU12 57	2	100
39 1074 04	19	64	52 DU12 58	2	100
39 1184 15	21	70	52 DU14 48	4	100
39 1211 11	3	46	52 DU14 49	5	100
39 1283 21	6	4	52 DU14 50	6	100
39 1283 21	8	4	52 DU14 52	1	100
39 1290 04	4	46	52 DU14 72	4	100
39 1309 11	13	52	52 DU14 73	5	100
39 1309 11	6	56	52 DU14 74	6	100
39 1493 15	20	52	52 DU14 77	1	100
39 1660 05	2	4	52 DU14 91	4	100
39 1715 19	3	22	52 DU14 92	5	100
39 1789 24	10	36	52 DU14 93	6	100
39 1789 24	6	78	52 DU14 96	1	100
39 1814 04	7	98	52 DU14 98	2	100
39 1944 04	28	66	52 DU16 51	3	100
39 2122 15	14A	52	52 DU16 52	3	100
39 2141 24	11	86	52 DU16 53	3	100
39 2141 24	6	88	52 DU17 53	1	84
39 2190 19	6	22	52 JA00 28	14	32
39 2295 15	3	40	52 JA00 29	7	20
39 2354 04	8	18	52 PF21 05	1	30
39 2366 15	1	52	52 PF21 29	1	30

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
56 DU61 33	4	60	AK 2010 12	8	94
56 DU6A Y9	13	68	AL 2414 81	12	50
56 DU70 Y9	8	98	AP 2010 25	22	94
56 DU9T Y9	22	70	BF 5612 19	4	18
56 DU9T Y9	20	72	CB 1010 09	3	6
56 DU9U Y9	13	68	CB 1010 22	4	6
56 JK8N 7B	9	64	CF 1110 19	14	44
56 PF1X 67	7	28	CL 2010 23	2	86
59 0400 06	14	72	CL 2010 23	2	88
59 0400 38	2	2	CM 2010 54	3	80
59 0400 38	12	20	CS 1011 28	11	8
59 0400 38	12	22	CZ 1814 07	13	56
59 0400 38	4	28	DD 1010 62	3	8
59 0400 38	2	30	DD 1013 66	10	40
59 1000 02	8	42	DD 1110 11	12	44
59 1500 03	15	62	DD 1110 12	10	44
59 1500 03	23	64	DD 1110 18	14	44
59 1500 14	4	12	DD 1110 48	11	44
59 2100 23	16	22	DD 1211 81	8	28
59 2100 24	17	14	DD 1412 27	5	76
60 1114 20	15	94	DD 1510 09	5	62
62 3050 84	22	106	DD 1610 13	10	56
75 6802 36	20	106	DD 1610 22	9	78
76 0109 36	14	106	DD 1610 51	8	56
76 0109 37	15	106	DD 1610 78	13	54
83 0201 73	7	104	DD 1810 32	6	72
83 0204 73	5	104	DD 1811 86	7	86
83 0205 52	1	104	DD 1811 86	15	88
83 0205 54	1	104	DD 1811 92	7	90

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DD 1812 05	20	72	DG 1612 24	7	54
DD 1812 07	15	72	DG 1810 53	4A	52
DD 1812 52	20	88	DG 1910 64	19	36
DD 1911 42	8	68	DH 1010 48	6	8
DD 2010 02	12	56	DH 1013 92	10	8
DD 2010 02	8	92	DH 1015 09	11	18
DD 2010 11	5	92	DH 1017 84	8	22
DD 2011 70	9	68	DH 1021 18	17	36
DE 1810 31	11	72	DH 1023 29	9	4
DF 1411 28	1	78	DH 1110 13	19	44
DF 1510 16	1	66	DH 1110 15	17	44
DF 1611 02	3	58	DH 1210 64	15	34
DF 1614 13	2	54	DH 1211 62	11	34
DF 1614 15	3	84	DH 1410 70	3	38
DF 1614 16	4	84	DH 1410 75	6	38
DF 1614 26	18	36	DH 1610 66	4	58
DF 1810 85	13	72	DH 1611 58	10	78
DF 1810 89	19	72	DH 1612 83	5	84
DF 1810 90	13	50	DH 1810 14	14	50
DF 1810 91	14	68	DH 2011 58	4	44
DF 1810 92	15	68	DJ 1811 15	16	50
DF 1810 98	10	86	DJ 2012 06	3	90
DF 1810 98	5	88	DJ 2012 06	5	90
DF 1810 98	19	88	DJ 2012 07	1	90
DG 1210 40	8	36	DJ 2012 07	6	90
DG 1410 19	4	78	DK 1013 86	7	8
DG 1611 21	9	36	DK 1016 05	7	42
DG 1611 21	7	78	DK 2010 78	18	94
DG 1611 24	9	58	DL 1810 10	4	88

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DM 1611 92	1	48	DU 0101 66	7	100
DM 1611 93	2	48	DU 0101 67	8	100
DM 1710 22	19	52	DU 0101 76	7	100
DM 1810 10	34	74	DU 0101 77	8	100
DM 1810 36	10	72	DU 1010 50	10	26
DM 1910 25	2	82	DU 1010 60	5	6
DM 2210 01	7	36	DU 1012 13	18	14
DM 2210 01	2	96	DU 1210 52	5	36
DP 1210 06	7A	28	DU 1210 84	26	36
DP 1210 18	21	36	DU 1210 85	25	36
DP 1210 25	6	36	DU 1410 14	5	46
DP 1210 65	17	34	DU 1410 95	4	76
DP 1611 63	11	54	DU 1412 72	14	38
DP 1611 70	9	54	DU 1412 77	5	38
DP 2010 37	3	78	DU 1412 78	10	38
DP 2110 09	2	46	DU 1413 01	10	76
DS 1011 17	4	26	DU 1413 15	12	78
DS 1011 54	7	12	DU 1413 16	13	78
DS 1012 15	11	28	DU 1413 25	13	38
DS 1013 55	19	14	DU 1510 06	26	64
DS 1211 26	11	36	DU 1510 10	7	64
DS 1510 49	2	60	DU 1510 29	11	64
DS 1510 53	5	60	DU 1510 44	2	62
DS 1910 18	12	68	DU 1510 46	18	64
DS 1910 52	11	68	DU 1510 47	10	66
DS 2010 25	9	94	DU 1510 56	5	82
DS 2210 01	2	98	DU 1510 58	4	50
DU 0101 56	7	100	DU 1510 61	13	66
DU 0101 57	8	100	DU 1610 08	4	56

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DU 1610 24	18	50	DU 1810 70	3	88
DU 1610 32	7	58	DU 1811 08	7	72
DU 1610 65	14	56	DU 1811 11	1	76
DU 1610 65	11	92	DU 1811 41	1	72
DU 1610 98	3	56	DU 1811 42	23	74
DU 1611 02	5	78	DU 1811 43	24	74
DU 1611 19	11	78	DU 1811 44	31	74
DU 1611 96	17	50	DU 1811 55	1	68
DU 1612 67	4	54	DU 1811 56	22	74
DU 1613 07	10	50	DU 1811 56	9	76
DU 1613 11	24	36	DU 1811 56	8	78
DU 1613 26	15	66	DU 1811 57	15	86
DU 1613 46	17	56	DU 1811 57	22	88
DU 1613 64	5	56	DU 1811 59	13	86
DU 1613 72	5	54	DU 1811 59	9	88
DU 1613 73	2	56	DU 1811 70	2	68
DU 1613 77	14	86	DU 1811 74	6	86
DU 1613 77	8	88	DU 1811 75	7	90
DU 1613 84	9	92	DU 1910 23	10	80
DU 1613 91	19	50	DU 1910 29	8	80
DU 1613 94	15	56	DU 1910 56	4	68
DU 1614 12	5	86	DU 1910 70	1	80
DU 1614 44	15	48	DU 1910 77	6	82
DU 1614 62	7	48	DU 2010 23	1	92
DU 1614 63	11	48	DU 2010 24	1	92
DU 1710 37	5	52	DU 2011 01	1	86
DU 1710 43	11	52	DU 2011 01	1	88
DU 1810 31	18	88	DU 2011 08	1	86
DU 1810 47	14	88	DU 2011 08	1	88

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DU 2011 47	7	94	FD 1810 12	18	72
DU 2011 56	5	94	FD 1810 19	16	68
DU 2011 58	5	94	FD 1810 20	17	68
DU 2110 04	1	46	FD 2110 06	6	46
DU 2210 15	1	98	FD 2110 07	7	46
DU 2210 21	1	54	GH 2010 12	2	90
DU 2210 28	4	98	GL 1710 36	4	38
DU 2210 29	5	98	GL 5814 79	13	4
DU 2210 39	3	98	JA 1316 06	18	62
DU 2210 40	11	98	JA 1610 03	9	66
DU 2210 41	3	98	JA 5112 16	4	8
DU 2210 42	11	98	JA 5310 12	8	12
DX 1510 81	1	64	JA 5310 15	5	12
DY 1132 00	1	58	JA 5410 05	5	22
DY 1138 03	14	94	JA 5410 05	5	30
DY 1610 03	21	66	JA 5410 10	5	20
DY 3512 01	9	44	JA 5410 12	8	20
DY 4014 00	4	94	JA 5410 16	3	24
DY 4018 01	12	36	JA 5410 21	15	22
DY 4022 02	13	94	JA 5410 28	6	44
DY 4026 00	11	76	JA 5412 11	14	28
DY 5614 00	9	18	JA 5412 12	15	28
DY 5810 02	15	36	JA 5412 25	13	28
DY 5810 05	3	36	JA 5510 02	3	14
DY 5810 09	14	36	JA 5510 04	7	14
DY 5810 10	13	36	JA 5510 08	15	14
DZ 1510 32	24	62	JA 5510 09	16	14
DZ 2010 38	2	94	JA 5514 06	2	32
FD 1010 78	2	24	JA 5514 20	12	32

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JA 5610 02	5	16	JE 3514 07	6	10
JA 6210 02	5	26	JE 5210 16	12	8
JA 6210 06	15	26	JE 5310 01	2	12
JA 6212 06	13	26	JE 5410 28	11	20
JB 1312 23	15	64	JE 5410 38	10	12
JB 3510 34	1	44	JE 5410 42	5	44
JB 4010 12	16	56	JE 5412 14	17	28
JB 4014 00	5	68	JE 5514 09	15	32
JB 5110 11	5	2	JE 5812 18	16	34
JB 5110 15	6	2	JE 5812 20	14	34
JB 5310 21	9	12	JE 5812 25	13	34
JB 5412 24	6	30	JE 5912 80	2	40
JB 5812 97	10	34	JE 6210 03	9	26
JB 5814 10	5	4	JE 6210 04	2	26
JB 5814 11	4	4	JG 1312 20	6	20
JB 5910 68	9	40	JG 1312 20	10	22
JB 5910 98	4	40	JG 1710 29	7	38
JC 1910 06	26	66	JG 1710 31	9	86
JD 1610 02	22	66	JG 5514 28	3A	32
JD 1610 06	23	66	JG 5710 24	13	22
JD 3512 06	18	44	JH 1610 35	27	66
JD 3518 00	12	34	JH 1610 38	17	66
JD 4022 12	12	82	JH 1710 17	12	76
JD 4022 12	21	94	JH 1710 48	11	38
JD 4022 17	12	94	JH 3516 02	3	42
JD 5610 04	3	16	JH 5112 12	6	6
JD 5610 11	6	16	JH 5210 07	3	10
JE 3510 05	2	44	JH 5410 21	9	22
JE 3514 07	15	8	JH 5612 00	6	18

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JH 5614 04	10	18	JW 1710 14	5	66
JH 6214 07	1	42	JW 1710 15	29	66
JK 1130 08	10	54	JW 1710 16	8	86
JK 1210 08	9	72	JW 1710 16	16	88
JK 1220 02	15	52	JW 5612 06	2	18
JK 1220 04	12	52	JW 5612 08	3	18
JK 1310 15	1	62	JW 5910 28	8	40
JK 2331 57	29	74	JY 1710 69	9	38
JK 4010 25	3	86	JY 1710 70	2	38
JL 1711 01	16	38	JY 1710 77	1	38
JL 1711 02	17	38	JY 1718 25	8	38
JL 1810 26	2	36	JY 1813 14	21	44
JL 4020 04	9A	94	JZ 1310 42	1	60
JL 4022 07	20	94	JZ 1610 28	20	68
JL 5412 27	12	28	JZ 1710 55	15	38
JL 5810 66	21	36	JZ 4010 77	33	74
JL 5911 49	6	40	JZ 4014 03	25	70
JN 1810 31	19	86	JZ 4020 02	4	44
JN 1810 31	21	88	JZ 4022 16	10	94
JP 5412 08	6	30	JZ 4022 18	16	94
JP 5810 18	20	36	JZ 5512 05	13	14
JP 1710 63	6	36	JZ 5610 02	4	16
JV 1310 24	3	60	JZ 5710 00	1	24
JV 1312 40	6	60	JZ 5710 01	5	24
JV 4022 04	11	94	KA AD10 35	17	72
JV 5110 11	4	2	KA CA06 12	12	48
JV 5110 12	3	2	KA CA06 14	16	86
JV 5110 13	1	2	KA CA06 14	11	88
JV 5412 08	2	28	KA CF08 30	4	72

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
KA DA06 10	23	36	KA ED06 85	10	20
KA DA06 14	9	56	KA ED08 30	3	68
KA DC05 18	7	82	KA EM06 10	20	44
KA DD06 14	21	74	KB BA04 08	22	62
KA DD06 14	12	86	KB BA06 16	18	86
KA DD06 14	13	88	KB BA06 16	12	88
KA DD06 14	17	94	KB BC06 08	8	44
KA DD06 25	10	32	KB RA42 16	4	86
KA DD06 25	2	78	KB Ra48 13	27	36
KA DD08 12	12	98	KB RB35 13	18	52
KA DD08 14	1	94	KC BA18 11	21	64
KA DD08 14	9	98	KC GA05 05	11	56
KA DD08 18	1	56	KC GA05 05	13	76
KA DD08 35	14	48	KC GA05 05	7	92
KA DD08 35	3	54	KC GA06 06	2	92
KA DD08 45	7	98	KC GA06 06	10	92
KA DD08 55	3	48	KC GD08 08	5	48
KA DD08 65	4	48	KC GD08 08	10	98
KA DD08 80	9	48	KD AA06 11	13	48
KA DD08 85	8	48	KD AA06 11	17	86
KA DF06 10	19	94	KD AA06 11	10	88
KA DG08 25	6	54	KD AA12 22	14	62
KA DT06 25	28	70	KD AA12 22	22	64
KA ED06 12	20	44	KD AB06 11	5	50
KA ED06 18	15	44	KD DB10 18	3	52
KA ED06 20	13	8	KD DB10 18	3	66
KA ED06 25	7	4	KD DB10 18	16	72
KA ED06 25	4	42	KD DB12 21	2	52
KA ED06 25	13	44	KE AB12 10	8	26

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
KE AB16 10	3	26	LC L000 01	10	52
KE BB35 15	2	8	LC L000 01	4	90
KH AA20 18	20	66	LC L000 02	7	56
KH AA25 20	8	54	LC L000 02	4	62
KH AA32 25	8	58	LC L000 02	20	64
KH BA08 28	6	66	LC L000 02	9	80
KJ AC18 24	10	4	LD A000 18	14	66
KP BB62 01	4	64	LD A000 25	3	12
KP BB63 01	11	62	LD A000 43	3	76
KP BB63 01	3	64	LD A000 69	24	66
KP BC60 04	8	64	LD B000 15	6	92
KP BF62 01	3	20	LD B000 44	5	18
KP BF62 03	4	20	LD B000 68	22	36
KP BF62 03	2	22	LD B000 75	12	66
LA A000 34	10	64	LD F000 01	9	42
LA A000 49	16	66	LE A000 03	6	50
LA C000 52	5	44	LE A000 03	11	66
LA D001 43	6	98	LJ A000 04	14	22
LA D001 48	6	54	NA	20	106
LA E000 05	5	28	NA	21	106
LA E000 15	9	20	PA 1210 41	25	74
LA E000 48	11	50	PA 1310 03	23	62
LB B000 06	2	76	PA 1318 67	13	82
LB U000 07	16	36	PA 1612 17	3	82
LB U000 12	26	70	PA 2310 02	1	96
LC A000 11	14	52	PA 2335 09	29	74
LC H000 01	2	58	PA 4018 10	6	94
LC H000 01	18	68	PA 5212 14	4	10
LC L000 01	10	48	PA 5510 02	1	14

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
PA 5512 05	14	14	PF 3512 47	16	44
PA 5512 06	12	14	PF 3514 10	3	44
PA 5512 07	2	14	PF 3514 38	3	44
PA 6210 05	7	26	PF 4014 17	4	68
PD 1716 16	12	38	PF 5011 44	13	20
PF 1138 01	3	50	PF 5011 47	13	20
PF 1210 54	30	74	PF 5111 11	3	4
PF 1316 16	6	62	PF 5112 55	1	8
PF 1610 05	7	68	PF 5112 57	8	8
PF 1610 07	10	68	PF 5112 58	5	8
PF 1610 09	24	70	PF 5115 24	1	4
PF 1610 10	19	68	PF 5310 61	1	12
PF 1610 11	23	70	PF 5410 18	2	20
PF 1610 12	27	70	PF 5410 29	1	22
PF 1610 13	10A	68	PF 5410 42	1	22
PF 1610 15	6	68	PF 5412 42	6	44
PF 1610 16	24	70	PF 5412 49	3	30
PF 1610 29	1	50	PF 5412 50	6	28
PF 1610 30	2	50	PF 5412 51	8	30
PF 1610 31	7	50	PF 5412 55	3	28
PF 1610 32	8	50	PF 5413 08	7	30
PF 1610 33	9	50	PF 5413 11	7	30
PF 1612 31	4	82	PF 5510 03	8	14
PF 1612 34	1	82	PF 5512 00	6	14
PF 1718 03	8	76	PF 5512 01	5	14
PF 1812 46	20	86	PF 5512 03	10	14
PF 1814 43	18	56	PF 5512 04	11	14
JB 3510 29	2	44	PF 5512 06	9	14
PF 3510 85	1	44	PF 5514 07	9	28

Parts Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
PF 5514 30	1	32	YD U220 04	10	82
PF 5514 33	7	32	YD U220 05	9	82
PF 5514 36	4	32	YD U220 06	8	82
PF 5514 37	9	32	YD U250 01	2	80
PF 5514 38	8	32	YD U250 02	4	80
PF 5610 00	1	16	YD U250 03	5	80
PF 5610 02	2	16	YD U250 04	6	80
PF 5612 00	1	18	YD U250 05	2	80
PF 5612 03	7	18	YD U250 06	4	80
PF 5811 35	4	36	YD U250 07	5	80
PF 5811 50	1	36	YD U250 08	6	80
PF 5811 98	14	36			
PF 5812 73	1	34			
PF 5812 74	12	4			
PF 5914 65	7	40			
PF 5914 86	1	40			
PF 5915 07	5	40			
PF 6210 03	1	26			
PF 6214 13	2	42			
YD U100 02	11	80			
YD U100 03	10	80			
YD U100 07	11	80			
YD U160 04	7	80			
YD U160 08	7	80			
YD U220 01	2	72			
YD U220 02	3	72			
YD U220 03	4	66			
YD U220 03	11	82			
YD U220 04	2	66			